


3-Unit Reel Mower

# **Owner's Operating Manual**



Serial No. LM180C : 20001-

"Required reading"

Read this manual and the Owner's Manual for the engine before using the machine.




## Greeting

Thank you for purchasing the Baroness machine. This manual explains proper handling, adjustment, and inspection of your machine. Prior to use, carefully read this manual to thoroughly understand the contents for safe and correct operation.

We hope you will use the machine safely, and take advantage of its best performance.

## Keeping the Owner's Operating Manual

Keep this Owner's Operating Manual in the box on the right side of the seat.



Keeping the Owner's Operating Manual\_001



## Introduction

Read this manual carefully to ensure that you thoroughly understand how to properly operate and maintain this machine, and to avoid causing injury to yourself or others.

The operator is responsible for operating the machine properly and safely.

Do not perform maintenance on the machine other than that described in this manual.

Be sure to also read the Owner's Manual for the engine, battery, etc.

Maintenance should only be performed by a certified specialist.

If you have any questions concerning maintenance or genuine parts, please contact your local Baroness dealer or Kyoeisha.

When making inquiries about this machine, please specify the machine's model designation and serial number.

When loaning or transferring this machine, please also provide this manual together with the machine.

Kyoeisha Co., Ltd.



The information described in this manual is subject to change for improvement without prior notice. When replacing parts, be sure to use genuine Baroness parts or parts designated by Kyoeisha. Note that the Baroness product warranty may not apply to defects caused by the use of parts from other companies.

### Warning Symbols

This manual uses the following warning symbols for handling precautions that are important for your safety.



Warning symbol

696cq5-001

This symbol indicates the articles regarding "Danger," "Warning," or "Caution."

Those articles describe important safety precautions and so read them carefully to understand completely before operating the machine.

Failure to adequately follow these safety precautions may cause an accident.



This symbol indicates that serious injury or death will occur if the warning is ignored.



This symbol indicates that serious injury or death may occur if the warning is ignored.



This symbol indicates that injury or damage to property may occur if the warning is ignored.

#### Important

This symbol indicates precautions on the mechanism of the machine.

## Introduction

## Purpose

This machine is intended for cutting turf grass at golf courses.

Do not use this machine in any way other than its intended purpose, and do not modify the machine.

Operating this machine for other purposes and modifying it may be very dangerous and may cause damage to the machine.

In addition, this machine is not authorized for operation as a special motor vehicle. Do not operate it on public roads.

# Contents

Safety	Page 1-1
Safe Operating Practices	Page 1-2
Disposal	Page 2-1
Recycle and Waste Disposal	Page 2-2
Product Overview	Page 3-1
Specifications	Page 3-2
Names of Each Section	Page 3-3
Safety Signs and Instruction Signs	Page 3-5
Handling Instructions	Page 4-1
Inspection Before Use	Page 4-2
Tightening torques	Page 4-8
Adjustment Before Operating	Page 4-11
Procedure to Start / Stop Engine	Page 4-12
Operation of Each Section	
Travel of Machine	
Cutting Work	Page 4-16
Transporting	Page 4-16
Maintenance	Page 5-1
Maintenance Precautions	Page 5-2
Maintenance Schedule	Page 5-3
Jacking up the machine	Page 5-5
Greasing	Page 5-6
Maintenance (Mower)	Page 5-9
Maintenance (Main Body)	
Long-Term Storage	Page 5-16

## LM180C

# Contents

Safe Operating PracticesF	Page	1-2
TrainingF	Page	1-2
PreparationF	Page	1-2
OperationF	Page	1-3
Maintenance and storageF	Page	1-4

## Safety

Failure to adequately follow these safety precautions may cause an accident resulting in injury or death.

## ♠ Danger

This machine is designed to ensure safe operation and has been tested and inspected thoroughly before shipment from the factory. The machine is equipped with safety devices to prevent accidents.

However, whether the machine demonstrates its original performance level depends on the manner in which it is operated and handled, as well as the manner in which it is managed on a daily basis.

Inappropriate use or management of the machine may result in injury or death. Observe the following safety instructions to ensure safe operation.

## Safe Operating Practices

### **Training**

- 1. Read this manual and other training material carefully. Be familiar with the controls, safety signs, and the proper use of the equipment.
- 2. If the operator or mechanic can not read English it is the owner's responsibility to explain this manual to them.
- All operators and mechanics should seek and obtain professional and practical instruction.

The owner is responsible for training the users.

Such instruction should emphasize.

- [1] The need for care and concentration when working with ride-on machines.
- [2] Control of a ride-on machine sliding on a slope will not be regained by the application of the brake.

The main reasons for loss of control are

- Insufficient wheel grip
- Being driven too fast
- Inadequate braking
- The type of machine is unsuitable for its task
- Lack of awareness of the effect of ground conditions, especially slopes
- Incorrect hitching and load distribution

- 4. Never allow children or people unfamiliar with these instructions to use or service the machine.
  - Local regulations may restrict the age of the operator.
- The owner/user can prevent and is responsible for accidents or injuries occurring to themselves, other people, or property.
- Keep in mind that the owner, operator, and mechanic are responsible for accidents or hazards occurring to other people or their property.
- 7. You can find additional safety information where needed throughout this manual.
- 8. Determine the left and right sides of the machine from the normal operating position.

### **Preparation**

- Evaluate the terrain to determine what accessories and attachments are needed to properly and safety perform the job. Only use accessories and attachments approved by the manufacturer.
- 2. While operating, always wear substantial footwear, long trousers, hard hat, safety glasses, and ear protection. Long hair, loose clothing, or jewelry may get tangled in moving parts. Do not operate the equipment when barefoot or wearing open sandals.
- Inspect the area where the equipment is to be used and remove all objects such as rocks, toys and wire which can be thrown by the machine.
- 4. Keep children out of the operating area and under the watchful care of a responsible adult other than the operator.
- 5. Exercise care in the handling of fuel.

## **▲** Warning

Warning-Fuel is highly flammable. Take the following precautions.

- [1] Store fuel in containers specifically designed for this purpose.
- [2] Add fuel before starting the engine. Never remove the cap of the fuel tank or add fuel while the engine is running or when the engine is hot.
- [3] Refuel outdoors only and do not smoke while refueling.

- [4] If fuel is spilled, do not attempt to start the engine but move the machine away from the area of spillage and avoid creating any source of ignition until petrol vapours have dissipated.
- [5] Replace all fuel tanks and container caps securely.
- 6. Check that operator's presence controls, safety switches and shields are attached and functioning properly. Do not operate unless they are functioning properly.
- 7. If the brake operation is faulty or the parking brake lever has noticeable play, be sure to adjust or repair them before operating the machine.
- 8. Replace faulty mufflers.
- 9. On multi-cylinder/multi-reel machines take care as rotating one cylinder/reel can cause other cylinder/reels to rotate.

### **Operation**

- Do not operate the engine in a confined space where dangerous carbon monoxide fumes can collect.
- 2. Only operate in good light, keeping away from holes and hidden hazards.
- Before attempting to start the engine, disengage all attachments, shift into neutral, and engage the parking brake.
   Only start engine from the operator's position.
  - Use seat belts if provided.
- 4. Remember there is no such thing as a safe slope. Travel on grass slopes requires particular care.
  - To guard against overturning:
  - [1] Do not stop or start suddenly when going up or downhill.
  - [2] Engage clutch slowly, always keep machine in gear, especially when traveling downhill.
  - [3] Machine speeds should be kept low on slopes and during tight turns.
  - [4] Stay alert for humps and hollows and other hidden hazards.
  - [5] Never operate across the face of the slope, unless the machine is designed for this purpose.

- [6] Never drive the machine on a slope with an angle of gradient that is greater than that specified or in a place where there is a danger of the machine slipping.
- Never operate the machine with damaged guards, shields, or without safety protective devices in place.
   Be sure all interlocks are attached, adjusted
- 6. Do not change the engine governor settings or overspeed the engine. Operating the engine at excessive speed may increase the hazard of personal injury.
- 7. Pay attention not to touch hot parts.
- 8. Do the following before leaving the operator's position.
  - [1] Stop on level ground.

and functioning properly.

- [2] Disengage the power take-off and lower the attachments.
- [3] Change into neutral and set the parking brake.
- [4] Stop the engine.
- 9. Stop the engine in the following conditions.
  - [1] Before refueling.
  - [2] Before making height adjustment unless adjustment can be made from the operator's position.
  - [3] Before cleaning blockages.
  - [4] Before checking, cleaning, or working the machine.
  - [5] After striking a foreign object or if an abnormal vibration occurs. Inspect the machine for damage and make repairs before restarting and operating the equipment.
- 10. Keep hands and feet away from the cutting units and the rotating parts.
- 11. Look behind and down before backing up to be sure of a clear path.
- 12. Do not carry passengers.
- 13. Never operate while people, especially children, or pets are nearby.
- 14. Slow down and use caution when making turns and crossing roads and sidewalks.
- 15. Stop the blades rotating before crossing surfaces other than grass.
- 16. Disengage drive to attachments when transporting or not in use.

## Safety

- 17. When using any attachments, never direct discharge of material toward bystanders nor allow anyone near the machine while in operation.
- 18. Do not operate the machine under the influence of alcohol or drugs.
- 19. Take care when loading or unloading the machine into a trailer or a truck. Load or unload the machine in a flat and safe place. Before loading or unloading, set the parking brake on the truck or trailer, stop the engine, and chock the wheels. When transporting the machine on a truck or a trailer, set the parking brake, stop the engine, and fasten the machine to the truck with a rope or other suitable restraining device that has sufficient strength.
  - When using a loading ramp, select one with sufficient strength, length, and width and that will not cause the machine to slip.
- 20. Close the fuel valve before transporting the machine.
- Use care when approaching blind corners, shrubs, trees, or other objects that may obscure vision.
- 22. Do not take your eyes off the road ahead. Do not operate the machine with no hands.
- 23. Reduce the throttle setting during engine run-out and, if the engine is provided with a shut-off valve, turn the fuel off at the conclusion of operation.
- 24. Do not operate the machine when there is the risk of lightning.

### Maintenance and storage

- Disengage drives on level ground, disengage the cutting unit, set parking brake, stop engine and disconnect spark plug wire. Wait for all movement to stop before adjusting, cleaning or repairing.
- When machine is to be parked, stored, or left unattended, lower the cutting units unless a positive machanical lock is provided.
- To reduce the fire hazard, keep the engine, silencer/muffler, compartment fuel storage area, cutting units and drives free of grass, leaves, or excessive grease. Clean up oil or fuel spillage.
- 4. Allow the engine to cool before storing in any enclosure.
- 5. Only cover the machine with a sheet after hot parts have sufficiently cooled down.

- 6. Never store the equipment with fuel in the tank inside a building where fumes may reach an open flame or spark.
- 7. Do not store fuel near flames.
- 8. If the engine is provided with a shut-off valve, shut off valve while storing or transporting.
- 9. Never allow untrained personnel to service machine.
- 10. Allow the engine/muffler to cool before checking/maintenance.
- 11. Appropriately manage and correctly use the tools necessary for servicing or adjusting the machine.
- 12. Use jack stands to support components when required.
- 13. Carefully release pressure from components with stored energy.
- 14. Make sure that parts such as wires are not touching each other and that their covers have not come off.
- 15. Use care when checking the cylinders/reels and bed knives.
  - [1] Wear gloves and use caution when servicing them.
  - [2] Be careful during adjustment of the machine to prevent entrapment of the fingers between moving blades and fixed parts of the machine.
- On multi-cylinder/multi-reel machines take care as rotating one cylinder/reel can cause other cylinder/reels to rotate.
- 17. Keep hands and feet away from moving parts. If possible, do not make adjustments with the engine running.
- Keep all parts in good working condition and all hardware tightened. Replace all worn or damaged decals.
- Keep all nuts, bolts and screws tight to be sure the equipment is in safe working condition.
- 20. If the fuel tank has to be drained, do this outdoors.

# Disposal

	σ	ì
	U	)
	C	)
	$\subseteq$	2
	U	)
- 7	Ξ	╮
(		1

Recycle and Waste Dispos	sal Page 2-2
About Recycle	Page 2-2
About the Waste disposal .	Page 2-2

## Disposal

## Recycle and Waste Disposal

## **About Recycle**

Recycling battery etc. is recommended for environmental conservation and economical use of resources.

It may be required by local laws.

## About the Waste disposal

Make sure that waste generated when servicing or repairing the machine is disposed of in accordance with local regulations. (e.g. waste oil, antifreeze, rubber products, and wires etc.)

Specifications	Page 3-2
Specifications	Page 3-2
Sound pressure level	Page 3-3
Sound power level	Page 3-3
Vibration level	Page 3-3
Names of Each Section	Page 3-3
Serial Number Plate	Page 3-4
Specification Decal	Page 3-4
Noise Emission Decal	Page 3-4
Year of Manufacture Decal	Page 3-4
Safety Signs and Instruction Signs	Page 3-5
About Safety Signs and Instruction Signs	Page 3-5
Positions of Safety Decals and Instruction Decals	Page 3-5
Explanation about Safety Decals and Instruction Decals	Page 3-6

# **Product Overview**

## Specifications

## **Specifications**

Туре			LM180C
	Total length		215 cm
Dimensions	Total width	During operation	208 cm
		During transport	185 cm
	Total height	Seat	107 cm
	Total Height	Steering wheel	102 cm
Total weight (em	pty fuel tank)		383 kg
Minimum turning	radius		230 cm
	Model		Subaru EH30B
Engine	Туре		Air-cooled 4-cycle vertical OHV-type gasoline engine
	Total displacem	ent	291 cm <sup>3</sup> (0.291 L)
	Maximum outpu	ut	6.6 kW (9.0 PS)/1,800 rpm
Fuel tank capacit	:y		Gasoline 6.0 dm <sup>3</sup> (6.0 L)
Fuel consumption	n		310 g/kW • h (rated output)
Engine oil capaci	ty		1.2 dm <sup>3</sup> (1.2 L)
Operating width (	(Mowing width)		188 cm
Operating height	(Mowing height)	ı	13.0 - 15.0 mm
Blades			72
Drive	Traveling		Mechanical
Dilve	Mowing		Mechanical
Speed (HST)			-
		1st	3.1 km/h
Speed	Forward	2nd	6.4 km/h
(Mechanical)		3rd	9.4 km/h
	Reverse	1st	3.1 km/h (1,800 rpm)
Efficiency			9,630 m <sup>2</sup> /h (6.4 km/h x Mowing width x 0.8)
Maximum inclination for operation		1	18 degrees
Tire size	Front wheel		4.00-5
1116 3126	Rear wheel		18 x 8.50-8
Tire pneumatic	Front wheel		200 kPa (2.0 kgf/cm <sup>2</sup> )
pressure	Rear wheel		80 kPa (0.8 kgf/cm <sup>2</sup> )
Battery			-

<sup>\*</sup> The factory default maximum engine rpm is 1,800 rpm.

Page 3-2 Specifications

### Sound pressure level

#### Sound pressure level

This machine was confirmed to have a continuous A-weighted sound pressure level of 93dB by measuring identical machines in accordance with the procedure specified in ISO 5395-1:2013.

### Sound power level

#### Sound power level

This machine was confirmed to have a sound power level of 105dB by measuring identical machines in accordance with the procedure specified in directive 2000/14/EC.

### Vibration level


#### Hand-arm vibration

This machine was confirmed to transmit a vibration level of 3.63 m/s<sup>2</sup> to hands and arms by measuring identical machines in accordance with the procedure specified in ISO 5349-1:2001,ISO 5349-2:2001.

### Whole body vibration

This machine was confirmed to transmit a vibration level of 1.12 m/s<sup>2</sup> to the whole body by measuring identical machines in accordance with the procedure specified in ISO 2631-1:1997,ISO 2631-2:2003.

### Names of Each Section



Names of Each Section\_001


_
Steering wheel
Traveling clutch lever
Change lever
Parking brake lever
Left mower unit
Diff-lock pedal
Reel rotation lever
Engine stop switch
Throttle lever
Вох
Brake pedal
Right mower unit
Rear mower unit
Seat
Serial number plate
Specification Decal
Noise Emission Decal
Year of Manufacture Decal

Names of Each Section Page 3-3

## **Product Overview**

### Serial Number Plate

The serial number plate indicates the model and serial number of the machine.




Serial Number Plate 001

## **Specification Decal**

(For Europe)

The Specification decal indicates the CE marking, model, and weight, etc.




Specification Decal\_001

### Noise Emission Decal

(For Europe)

The noise emission decal indicates the sound power level determined by measuring identical machines in accordance with the procedure specified in the EC directives.




Noise Emission Decal\_001

### Year of Manufacture Decal

(For Europe)

The year of manufacture decal indicates the year when this machine was manufactured.



Year of Manufacture Decal\_001

Page 3-4 Names of Each Section

## Safety Signs and Instruction Signs

## About Safety Signs and Instruction Signs


## **▲** Warning

Safety decals and instruction decals are attached to this machine.

Make sure that they are preserved in their entirety. If they are damaged, become dirty, or peel off, replace them with new ones.

Part numbers for decals that need to be replaced are listed in the parts catalog. Order them from a Baroness dealer or Kyoeisha.


### <u>Positions of Safety Decals and Instruction</u> Decals



Positions of Safety Decals and Instruction Decals\_001

## **Product Overview**

### **Explanation about Safety Decals and Instruction Decals**



		R073-20057-60
		Decal, engine alert
		1. Read the manual.
5		Exhaust gas is poisonous.  Do not operate in an unventilated room or enclosed area.
	HUT OFF FUEL VAI / EWHEN   OSES AND FITTINGS.	3. Stop the engine before refueling.
	1 2 3 4 5 7	4. Fire, open flame and smoking are prohibited.
	qigqnx-013	5. Shut off fuel valve when the engine is not in use.
		6. Stay clear of the hot surface.
		7. Check for leakage from hose and fittings.
6	SPARK PLUG COVER MUST BE IN PLACE WHEN REFUELING.  BE CACHE BOUGE DOT ETREEN PLACE LORS DES PLEINS.	R073-20046-40 Decal, engine alert
	giagny 014	Spark plug cover must be in place when refueling.
7	qigqnx-015	K4205001330 Decal, caution to noise
8	qigqnx-017	K4205001560 Decal, read Owner's manual  Warning Read the manual.

# **Product Overview**

Inspection Before Use	Page 4-2
Reel Cutter (Cutting Cylinder) and	
Bed Knife (Bottom Blade)	Page 4-2
Cover	Page 4-2
Air Cleaner	Page 4-2
Roller	Page 4-3
Tire	Page 4-3
Brake	Page 4-3
Clutch	Page 4-3
Wire	Page 4-4
Belt	Page 4-4
Engine	Page 4-4
Engine Oil	Page 4-4
Transmission	Page 4-6
Fuel	Page 4-7
Oil Leakage	Page 4-7
Tightening torques	Page 4-8
Standard tightening torques	Page 4-8
Principal tightening torques	Page 4-10
Adjustment Before Operating	Page 4-11
Adjustment Before Operating  Adjustment of Seat  Adjustment of Blade Engagement .	Page 4-11
Adjustment of Seat	Page 4-11 Page 4-11
Adjustment of Seat Adjustment of Blade Engagement .	Page 4-11 Page 4-11 Page 4-12
Adjustment of Seat  Adjustment of Blade Engagement .  Adjustment of Cutting Height	Page 4-11 Page 4-11 Page 4-12 Page 4-12
Adjustment of Seat Adjustment of Blade Engagement . Adjustment of Cutting Height  Procedure to Start / Stop Engine	Page 4-11 Page 4-11 Page 4-12 Page 4-12 Page 4-12
Adjustment of Seat  Adjustment of Blade Engagement .  Adjustment of Cutting Height  Procedure to Start / Stop Engine  Start / Stop of Engine  Operation of Each Section	Page 4-11 Page 4-12 Page 4-12 Page 4-12 Page 4-13
Adjustment of Seat Adjustment of Blade Engagement . Adjustment of Cutting Height  Procedure to Start / Stop Engine  Start / Stop of Engine  Operation of Each Section  Precautions for Operating the Machine	Page 4-11 Page 4-12 Page 4-12 Page 4-12 Page 4-13
Adjustment of Seat Adjustment of Blade Engagement . Adjustment of Cutting Height  Procedure to Start / Stop Engine  Start / Stop of Engine  Operation of Each Section  Precautions for Operating the Machine  Cautions for when You Leave the	Page 4-11 Page 4-12 Page 4-12 Page 4-12 Page 4-12 Page 4-13 Page 4-13
Adjustment of Seat Adjustment of Blade Engagement . Adjustment of Cutting Height  Procedure to Start / Stop Engine  Start / Stop of Engine  Operation of Each Section  Precautions for Operating the Machine  Cautions for when You Leave the Machine	Page 4-11 Page 4-12 Page 4-12 Page 4-12 Page 4-12 Page 4-13 Page 4-13
Adjustment of Seat Adjustment of Blade Engagement . Adjustment of Cutting Height  Procedure to Start / Stop Engine  Start / Stop of Engine  Operation of Each Section  Precautions for Operating the Machine  Cautions for when You Leave the Machine	Page 4-11 Page 4-12 Page 4-12 Page 4-12 Page 4-13 Page 4-13 Page 4-13 Page 4-13
Adjustment of Seat Adjustment of Blade Engagement . Adjustment of Cutting Height  Procedure to Start / Stop Engine  Start / Stop of Engine  Operation of Each Section  Precautions for Operating the Machine  Cautions for when You Leave the Machine	Page 4-11 Page 4-12 Page 4-12 Page 4-12 Page 4-12 Page 4-13 Page 4-13 Page 4-13 Page 4-13 Page 4-13
Adjustment of Seat Adjustment of Blade Engagement . Adjustment of Cutting Height  Procedure to Start / Stop Engine  Start / Stop of Engine  Operation of Each Section  Precautions for Operating the Machine  Cautions for when You Leave the Machine  Instruction Decals  Throttle Lever	Page 4-11 Page 4-12 Page 4-12 Page 4-12 Page 4-13 Page 4-13 Page 4-13 Page 4-13 Page 4-13 Page 4-13
Adjustment of Seat	Page 4-11 Page 4-12 Page 4-12 Page 4-12 Page 4-13 Page 4-13 Page 4-13 Page 4-13 Page 4-13 Page 4-13 Page 4-14 Page 4-15
Adjustment of Seat	Page 4-11 Page 4-12 Page 4-12 Page 4-12 Page 4-12 Page 4-13 Page 4-13 Page 4-13 Page 4-13 Page 4-13 Page 4-14 Page 4-15 Page 4-15
Adjustment of Seat	Page 4-11 Page 4-12 Page 4-12 Page 4-12 Page 4-13 Page 4-13 Page 4-13 Page 4-13 Page 4-13 Page 4-14 Page 4-15 Page 4-15

Parking Brake Lever	Page 4-16
Travel of Machine	Page 4-16
Moving the Machine	Page 4-16
Cutting Work	Page 4-16
Cutting Operation	Page 4-16
Transporting	.Page 4-16
Transporting Procedure	.Page 4-16

### Inspection Before Use

Be sure to perform an inspection before you start using the machine so that you will be able to take advantage of its optimum performance for a long period of time.

# Reel Cutter (Cutting Cylinder) and Bed Knife (Bottom Blade)

Inspection of Reel Cutter (Cutting Cylinder) and Bed Knife (Bottom Blade)

The reel cutter (cutting cylinder) and bed knife (bottom blade) may become dull due to frequent use, objects crushed during mowing, or damage caused during transportation. Inspect the reel cutter (cutting cylinder) and bed knife (bottom blade), and if necessary, adjust the blade engagement, perform back lapping, or resharpen or replace the reel cutter (cutting cylinder) and the bed knife (bottom blade).

- 1. Check to see whether or not the edge of the reel cutter (cutting cylinder) and the bed knife (bottom blade) are too blunt to cut.
- 2. Make sure that the reel cutter (cutting cylinder) and the bed knife (bottom blade) are not cracked.
- 3. Check to see how much the reel cutter (cutting cylinder) and the bed knife (bottom blade) are worn.
- Make sure that the reel cutter (cutting cylinder) and the bed knife (bottom blade) have not changed color due to heat from grinding.
- 5. Check to see whether or not the second edge face (relief) remains at the point of reel cutter (cutting cylinder).
- 6. Make sure that the welding between the reel cutter (cutting cylinder) and the disc has not come off.

### Cover

Inspection of Covers

## ▲ Caution

If you have removed the covers during inspection, be sure to securely install them in their original positions.

If a cover remains removed, foreign objects may fly off, possibly resulting in injuries.


- Make sure that there is no wear or deterioration of the reel cover and all other covers.
- 2. Make sure that there is no damage to the reel cover and all other covers.
- 3. Make sure that there is no interference with moving parts due to deformation of the reel cover and all other covers.
- Make sure that the reel cover and all other covers are installed in their appropriate positions.

#### Air Cleaner

Inspection of Air Cleaner

For details on handling the engine, please refer to the separate Engine Handling Manual. The air cleaner is a component that removes dirt from the intake air to prevent wear of the cylinder liners and piston rings so that the engine will always operate smoothly. A contaminated air cleaner element may cause malfunction of the engine.

- 1. Make sure that there is no damage to the air cleaner.
- Make sure that the air cleaner is not contaminated.



Inspection of Air Cleaner 001


1 Air cleaner

Page 4-2 Inspection Before Use

#### Cleaning of Air Cleaner

For details on handling the engine, please refer to the separate Engine Handling Manual. A contaminated air cleaner element may cause malfunction of the engine.


To maximize the life of the engine, clean the air cleaner properly.



Cleaning of Air Cleaner 001

1 Air cleaner

- 1. Follow the steps below to clean the air cleaner.
  - [1] Before installing the element, clean it with white kerosene, immerse it in an admixture of three parts white kerosene to one part engine oil, and then shake/ squeeze it.
  - [2] Before installing the urethane foam, clean it with white kerosene, immerse it in an admixture of three parts white kerosene to one part engine oil, and then firmly squeeze it.



Cleaning of Air Cleaner\_002

1	Element
2	Urethane foam

### Roller

Inspection of Rollers

Bearing wear due to frequent use or bearing damage caused by water infiltration may prevent the roller from rotating smoothly. Inspect the roller and, if necessary, replace parts such as oil seals and bearings.

- 1. Make sure that there is no abrasion nor adhesion of the roller.
- 2. Make sure that there is no wear of the roller shaft.
- 3. Make sure that there is no wear nor damage of the oil seal.
- 4. Make sure that there is no wear nor rust of the bearing.
- 5. Make sure that there is no play in the roller shaft.

#### Tire

Inspection of Tires

- 1. Check the pneumatic pressure of the tires.
- Make sure that there are no cracks, damage or abnormal wear on the tires.

Tire size	Pneumatic pressure
Front wheel (4.00 - 5)	200 kPa (2.0 kgf/cm <sup>2</sup> )
Rear wheel 8.50 - 8	80 kPa (0.8 kgf/cm <sup>2</sup> )

#### Brake

Inspection of Parking Brake

- 1. Make sure that the brake is applied when you pull the parking brake lever.
- 2. Make sure that the brake is not applied even slightly when you press the push button to release the parking brake lever.

#### Inspection of Brake

While traveling, depress the brake pedal until the pedal hits the pedal stopper to make sure that the brake is applied effectively.

#### Clutch

Inspection of Clutch

- 1. Operate the clutch levers and check that the clutch operates perfectly.
- 2. Make sure that the clutch levers function well.

#### Wire

Inspection of Wire

- Make sure that the wire is not cracked or damaged.
- 2. If the wire is cracked or damaged, replace it with a new one immediately.

#### Belt

Inspection of Belt



If you have removed the cover during inspection, make sure that you replace it in the original position securely.

If the cover remains removed, the operator

may come in contact with the rotating objects or belt, possibly resulting in injuries.

### Important

A slacking or damaged belt may cause the cutter rotation speed or operation speed to be insufficient for operation.

- 1. Press the middle of the belt with your finger to check the belt tension.
- 2. Make sure that there are no cracks, damage or abnormal wear.

#### **Engine**

Inspection of Engine

For details on handling the engine, please refer to the separate Engine Handling Manual.

- Check the fuel system parts for loosened or cracked joints and leakage. Replace the parts if necessary.
- Blow the air to clean any grass or flammables attached inside or around the muffler.
- Blow air to clean any grass or flammables attached around the cooling fins or recoil starter.

### **Engine Oil**


Inspection of Engine Oil

For details on handling the engine, please refer to the Engine's Owner's Manual.

Important

Screw the oil level gauge firmly.


- 1. Stop the engine, wait for 10 to 20 minutes for the engine to cool down, then check the oil level.
- Position the machine so that the engine will be level, then check the engine oil level without screwing the oil level gauge into the oil filling port.



Inspection of Engine Oil\_001

1	Oil level gauge	
2	Drain plug	

3. The appropriate engine oil level should be between the upper and lower limit lines on the gauge.



Inspection of Engine Oil\_002

1	Oil level gauge	
2	Upper limit	
3	Lower limit	

#### Filling of Engine Oil

For details on handling the engine, please refer to the Engine's Owner's Manual.

### Important

Do not fill too much engine oil. Otherwise, the engine may be damaged.

### Important

Do not mix different types of engine oil.


### Important

Be sure to use engine oil that is classified as API Service Grade SF or higher, with an SAE Viscosity that is appropriate for the operating environment (ambient temperature).

### Important

Screw the oil level gauge firmly.

- If the engine oil level is lower than the lower limit line on the oil level gauge, supply engine oil through the oil filling port.
   Remove the oil level gauge, and then supply new engine oil until the oil reaches a level in between the upper and lower limit lines on the oil level gauge.
- 2. Screw the oil level gauge firmly.
- 3. Check the oil level again 10 to 20 minutes after supplying the engine oil.



Filling of Engine Oil\_001

1	Oil level gauge
2	Drain plug

#### Change of Engine Oil

For details on handling the engine, please refer to the separate Engine Operating Manual.

## ▲ Warning

When you change the engine oil, be sure to drain it into a bowl and discard it in accordance with regional laws and regulations.

## ▲ Caution

Pay attention to hot oil, which could burn your skin if it gets on you.

### Important

Be sure to use engine oil that is classified as API Service Grade SF or higher, with an SAE Viscosity that is appropriate for the operating environment (ambient temperature).


### Important

Screw the oil level gauge firmly.

Change the engine oil more frequently, if the engine oil is contaminated, and also in case you use the machine in dusty areas or operate the engine at high loads or in high temperatures.

- 1. Move the machine onto a level surface and stop the engine.
- 2. Remove the drain plug while the engine oil is warm, and then drain the oil into a bowl.
- 3. Attach the drain plug to the engine.
- 4. Remove the oil level gauge.
- Pour new engine oil through the oil filling port.
   Engine oil quantity is approximately 1.2 dm<sup>3</sup>(1.2 L).
- Insert the oil gauge straight into the oil filling port all the way, without twisting or turning it, to check the engine oil level.
   Make sure that the engine oil is filled up to the upper limit of the oil gauge.

7. Screw the oil level gauge firmly.



Change of Engine Oil\_001


1	Oil level gauge
2	Drain plug

## **Transmission**

Inspection of Transmission Oil

Place the machine so that its frame will be level, and then make sure that the transmission oil level is at the oil level plug at any time.

The oil level plug is located on the right side of the transmission.



Inspection of Transmission Oil\_001

	1	Oil filling port
2 Oil level plug		Oil level plug
	3 Drain plug	

Filling of Transmission Oil


## Important

Do not mix different types of transmission oil.

## Important

Be sure to pour automobile gear oil that is classified as SAE Viscosity Grade #90 into the transmission.

- 1. Through the oil filling port, fill the transmission oil.
- 2. Check the oil level again 10 to 20 minutes after filling the oil.



Filling of Transmission Oil\_001

1	Oil filling port	
2 Oil level plug		
3	Drain plug	

### Change of Transmission Oil



When you change the transmission oil, be sure to drain it into a bowl and discard it in accordance with regional laws and regulations.



Be careful with hot oil, which could cause burns if it contacts your skin.


### Important

Be sure to pour automobile gear oil that is classified as SAE Viscosity Grade #90 into the transmission.

Change the entire transmission oil according to the maintenance schedule.

- 1. Move the machine onto a level surface and stop the engine.
- 2. Remove the drain plug while the transmission oil is warm, and then drain the oil into a bowl.
- 3. Attach the drain plug to the transmission.
- 4. Remove the oil filling port cap and oil level plug.

- 5. Pour new transmission oil through the oil filling port.
  - The transmission oil quantity is 2.0 dm<sup>3</sup> (2.0 liters).
- 6. Make sure that the transmission oil level is filled up to the tip of the oil level opening.
- 7. Attach the oil filling port cap and oil level plug.




Change of Transmission Oil\_001

1	Oil filling port
2	Oil level plug
3	Drain plug

#### Fuel

Inspection of Fuel Supply

Observe the fuel gauge located on the fuel tank to check the fuel level.



Inspection of Fuel Supply\_001

1	Fuel gauge
---	------------

#### Fuel Supply

## ♠ Danger

Do not supply fuel above F (FULL) level of the fuel gauge.

If you supply too much fuel, it might overflow from the fuel cap when you travel or work on a slope.

## ▲ Warning

Keep fire away while refueling. Do not smoke while refueling.

## **A** Warning

Supply fuel after the engine is stopped and has well cooled down.



Pay attention not to touch hot parts.

If the fuel gauge located on the fuel tank indicates a level close to E (EMPTY), supply lead-free gasoline for automobiles at your earliest convenience.

The fuel tank capacity is approximately 6.0 dm<sup>3</sup> (6.0 L).

### Oil Leakage

Inspection of Oil Leakage

After approximately 50 hours of operation, some joints may be loosened and oil and grease may leak.

Be sure to retighten the parts.

Check the bottom of the machine for oil and grease leakage.

### Tightening torques

### Standard tightening torques

**Bolts and Nuts** 

### Important

A number of bolts are used in each part of this machine.

Be sure to re-tighten the bolts and nuts, because they may be loosened at the earlier stage of the use.

As to the bolts and nuts without any special instruction, tighten them in appropriate tightening torque with proper tool.

Too much tightening may cause the looseness or damage of the screw.

The strength of tightening is determined by types of screws, strength, the friction of thread face or base face and others.

The table below is for the galvanized or parkerized bolts.

In case that the strength of internal thread is weak, it is not applied.

Do not use rusty or sand attached "screw."

Otherwise, it may cause insufficient tightening even if you apply the specified tightening torque.

The friction of the screw face becomes higher and the tightening torque is canceled out by the friction, therefore sufficient tightening cannot be applied.

If "screw" is wet by water or oil, do not tighten it with normal tightening torque.

If the screw is wet, the torque coefficient will get smaller and it may result in too much tightening.

Too much tightening may cause looseness by the screw stretched or result in damage.

Do not use a bolt experienced too much burden.

Using the impact wrench requires the skill.

Do exercise as much as possible for steady tightening.

	General bolt					
	Strength classification 4.8					
Nominal diameter	M 4 T (4.8) tib3yb-001					
	N-m	kgf-cm	lb-in			
M5	3 - 5	30.59 - 50.99	26.55 - 44.26			
M6	7 - 9	71.38 - 91.77	61.96 - 79.66			
M8	14 - 19	142.76 - 193.74	123.91 - 168.17			
M10	29 - 38	295.71 - 387.49	256.68 - 336.34			
M12	52 - 67 530.24 - 683.20 460.25 - 593.02		460.25 - 593.02			
M14	70 - 94 713.79 - 958.52 619.57 -		619.57 - 831.99			
M16	88 - 112	897.34 - 1142.06	778.89 - 991.31			
M18	116 - 144	1,182.85 - 1,468.37	1,026.72 - 1,274.54			
M20	147 - 183	1,498.96 - 1,866.05	1,301.10 - 1,619.73			
M22	295	3,008.12	2,611.05			
M24	370	3,772.89	3,274.87			
M27	550	5,608.35	4,868.05			
M30	740	7,545.78	6,549.74			

Page 4-8 Tightening torques

	Heat-treated bolt						
	Strength classification 8.8				Strength classification	n 10.9	
Nominal diameter	8 8 T (8.8) tib3yb-002				11 (11T) (10.9) tib3yb-003		
	N-m	kgf-cm	lb-in	N-m	kgf-cm	lb-in	
M5	5 - 7	50.99 - 71.38	44.26 - 61.96	7 - 10	71.38 - 101.97	61.96 - 88.51	
M6	8 - 11	81.58 - 112.17	70.81 - 97.36	14 - 18	142.76 - 183.55	123.91 - 159.32	
M8	23 - 29	234.53 - 295.71	203.57 - 256.68	28 - 38	285.52 - 387.49	247.83 - 336.34	
M10	45 - 57	458.87 - 581.23	398.30 - 504.51	58 - 76	591.43 - 774.97	513.36 - 672.68	
M12	67 - 85	683.20 - 866.75	593.02 - 752.34	104 - 134	1,060.49 - 1,366.40	920.50 - 1186.03	
M14	106 - 134	1,080.88 - 1,366.40	938.21 - 1,186.03	140 - 188	1,427.58 - 1,917.04	1,239.14 - 1,663.99	
M16	152 - 188	1,549.94 - 1,917.04	1,345.35 - 1,663.99	210 - 260	2,141.37 - 2,651.22	1,858.71 - 2,301.26	
M18	200 - 240	2,039.40 - 2,447.28	1,770.20 - 2,124.24	280 - 340	2,855.16 - 3,466.98	2,478.28 - 3,009.34	
M20	245 - 295	2,498.27 - 3,008.12	2,168.50 - 2,611.05	370 - 450	3,772.89 - 4,588.65	3,274.87 - 3,982.95	
M22	-	-	-	530	5,404.41	4,691.03	
M24	-	-	-	670	6,831.99	5,930.17	
M27	-	-	-	1,000	10,197.00	8,851.00	
M30	-	-	-	1,340	14,628.78	11,860.34	

Note:

The same values are applied to "fine screw thread."

Tightening torques Page 4-9

## Principal tightening torques

Tightening Torque by Model

LM180C

Tighten the following bolts and nuts at the torque specified in the table.

For thread locking adhesive, apply a mild to high-strength thread locker (ThreeBond 1322 or equivalent anaerobic sealant).

Portion		Code Part name	Tightening Torque			Thread locking	
	PORION	Code	Part name	N-m	kgf-cm	lb-in	adhesive
Fron	Front wheel shaft	K0071000082	Bolt, with nipple hole M12-15	36 - 40	371.13 - 407.92	318.64 - 354.04	_
t whe	Wheel mounting shaft	K0000100252	Bolt, M10-25	29 - 38	295.71 - 387.49	256.68 - 336.34	_
el	Wheel	K0000080202	Bolt, M8-20	14 - 19	142.76 - 193.74	123.91 - 168.17	_
Rea r whe el	Wheel	K0010100252	Bolt, heat-treated M10-25	58 - 76	591.43 - 774.97	513.36 - 672.68	_
Steering		K1604120000	Rod end, spherical bearing LHSA12	52 - 67	530.24 - 683.20	460.25 - 593.02	0
Handle		K0010060202	Bolt, heat-treated M6-20	7 - 9	71.38 - 91.77	61.96 - 79.66	_
Transmission pulley		K0010060151	Bolt, heat-treated M6-15	7 - 9	71.38 - 91.77	61.96 - 79.66	0
Mow	Bed knife (Bottom blade)	K0071000092	Screw, heat-treated flathead M10-20	29 - 38	295.71 - 387.49	256.68 - 336.34	_
er	Front roller	K0010100252	Bolt, heat-treated M10-25	58 - 76	591.43 - 774.97	513.36 - 672.68	_
Engine		K0000100452	Bolt, M10-45	29 - 38	295.71 - 387.49	256.68 - 336.34	0
Seat		K0013101302	Bolt, heat-treated M10-130	29 - 38	295.71 - 387.49	256.68 - 336.34	_

Page 4-10 Tightening torques


### Adjustment Before Operating

## Adjustment of Seat

Use the seat adjustment lever to adjust the seat back and forth.

Adjust the position according to the operator's body size.

The adjustment lever is attached to the left of the seat.



Adjustment of Seat\_001

1 Adjustment lever

## Adjustment of Blade Engagement

## ♠ Danger

Make sure that the parking brake is firmly applied before performing the operation.

## ▲ Danger

Be sure to perform this operation on your own.

## ▲ Caution

When handling the reel cutter (cutting cylinder) or bed knife (bottom blade), wear gloves to protect your hands.


Pay attention not to let the reel cutter (cutting cylinder) catch your gloves. Otherwise, you may injure your hand or fingers.

- 1. Stop the engine.
- 2. With the cutter adjustment nut, adjust the engagement between the reel cutter (cutting cylinder) and the bed knife (bottom blade) so that newspaper (two to three sheets) will be cut by the edge of both blades when the blades in their entirety come slightly into contact with each other.

3. Insert two or three strips of newspaper into the space between the reel cutter (cutting cylinder) and the bed knife (bottom blade) at an angle of 90 degrees. Then, rotate the reel cutter (cutting cylinder) counter-clockwise (when you face the mower unit from the left) by hand to check the sharpness of the blades.

Check the sharpness of the entire range (at three or four points between the left and right ends) of the reel cutter (cutting cylinder).

- · If a gap is created between edges:
  - Loosen the lock nut and slightly loosen nut B.
- Contact the reel cutter (cutting cylinder) and bed knife (bottom blade) slightly, then tighten nut A.
- If the reel cutter (cutting cylinder) is too tight to turn:
  - Loosen the lock nut and slightly loosen nut A.
  - 2. Reduce the contact pressure between the reel cutter (cutting cylinder) and bed knife (bottom blade), then tighten nut B.
- If the blades still cannot cut well: Perform back lapping of the reel cutter (cutting cylinder).



Adjustment of Blade Engagement\_001

	3 3 =
1	Lock nut
2	Nut A
3	Nut B
4	Reel cutter (Cutting cylinder)
5	Bed knife (Bottom blade)

### Adjustment of Cutting Height

#### Important


The front wheel is provided to prevent the reel cutter (cutting cylinder) from damaging a convex portion of the lawn surface.

Adjust the height so that the front wheel will not be grounded but raised by 10-20mm off the ground.

The cutting height is adjusted by moving the roller up or down.

Refer to the cutting height scale plate to decide the height.

- To increase cutting height: Loosen nut A, lower the roller, then tighten nut B.
- 2. To decrease cutting height: Loosen nut B, raise the roller, then tighten nut A.



Adjustment of Cutting Height\_001

-		
	1	Nut A
	2	Nut B
	3	Roller
	4	Front wheel
	5	Cutting height scale plate
	6	Reel cutter (cutting cylinder)

### Procedure to Start / Stop Engine

### Start / Stop of Engine

Procedure to Start Engine



Before starting the engine, make sure that there are no other people or obstacles around the machine.

1. Sit on the seat.

- 2. Make sure that the parking brake is applied.
- Make sure that the traveling clutch lever and reel rotation lever are set to the "OFF" position.
- 4. Make sure that the change lever is set to the neutral position.
- 5. Set the fuel cock to the "Open" position. The fuel cock is located under the fuel tank.
- 6. Shift the throttle lever from the "Low" (turtle icon) position halfway to the "High" (rabbit icon) position.
- Pull the choke knob.
   Pull the knob half way for restarting, as necessary.
- 8. Set the engine switch to the "ON" position.
- 9. Pull the recoil starter to start the engine.
- Make sure that the engine has started, and then slowly return the choke knob to its original position.
- 11. Shift the throttle lever to the "Low" (turtle icon) position, and then warm up the engine for 1 to 2 minutes.
- 12. Gradually move the throttle lever to the "High" (rabbit icon) position.

#### Procedure to Stop Engine

- 1. Depress the brake pedal.
- 2. Apply the parking brake.
- 3. Shift the traveling clutch lever and reel rotation lever to the "OFF" position.
- 4. Shift the change lever to the neutral position.
- 5. Shift the throttle lever to the "Low" (turtle icon) position, and continue idling for 1 to 2 minutes.
- 6. Set the engine switch to the "OFF" position.
- 7. Make sure that the engine has stopped.
- 8. Set the fuel cock to the "Close" position.
  The fuel cock is located under the fuel tank.
- 9. Remove the ignition key.
- 10. Leave the driver's seat.

#### Safety Mechanisms

This machine has the safety device for starting / stopping engine.

- 1. As for starting the engine, the safety device prevents the engine from starting unless it meets each of the following three conditions.
  - · An operator is sitting on the seat.
  - · The parking brake lever is pulled.
  - The traveling clutch lever is in the "OFF" position.
- 2. In the case that the operator leaves the seat with the engine running, the safety device makes the engine stop unless it meets each of the following two conditions.
  - The parking brake lever is pulled.
  - · The traveling clutch lever is in the "OFF" position.

## Operation of Each Section

## Precautions for Operating the Machine




Under any circumstances drive the machine at such a speed that you can stop it immediately for emergencies.

#### Cautions for when You Leave the Machine



If the brakes are not sufficiently effective, use the wheel stoppers to secure the machine.

#### **Instruction Decals**



Instruction Decals\_001

1	Diff-lock pedal
2	Brake pedal
3	Traveling clutch lever
4	Traveling clutch "OFF"
5	Traveling clutch "ON"
6	Reel rotation lever (Left and right mower units)
7	Reel cutter (cutting cylinder) "STOP"
8	Reel cutter (cutting cylinder) "ROTATE"


### Throttle Lever

The throttle lever is located to the right of the steering handle and enables you to adjust the engine rpm.

Move the throttle lever toward "High" (Rabbit icon) to increase the engine rpm, and toward "Low" (Turtle icon) to reduce the rpm.

Note:

The factory default engine rpm is set to 1,800 rpm.



Throttle Lever-001

1	Low (Turtle icon)
2	High (Rabbit icon)

### Lifting lever

Left and Right Mower Units




Before raising or lowering the mower units, make sure that there are no people around the machine.



If the reel rotation lever is set to "On," you will be unable to raise the mower units.


To lower the left and right mower units, squeeze the clutch lever and slowly move the lifting lever down.



Left and Right Mower Units\_001

1	Clutch lever
2	Lifting lever

To raise the left and right mower units, raise the lifting lever slowly until the hook metal fitting is secured by the hook.



Left and Right Mower Units\_002


1 Lifting lever

#### Rear Mower Unit

## ▲ Caution

Before raising or lowering the mower units, make sure that there are no people around the machine.


To lower the rear mower unit, squeeze the clutch lever and slowly move the lifting lever down.



Rear Mower Unit 001

1	Clutch lever
2	Lifting lever

To raise the rear mower units, raise the lifting lever slowly, and then tilt it fully forward.



Rear Mower Unit\_002

1 Lifting lever

## Operation of Change Lever




#### Caution

Do not change the lever position during traveling. Otherwise, the transmission may be damaged.

The change lever is a transmission device. It was adapted from a direct change system. To change the speed, park the machine on level ground, and then engage the lever in the desired position.

	1	3.1 km/h
Forward	2	6.4 km/h
	3	9.4 km/h
Backward	R	3.1 km/h (1,800 rpm)



Operation of Change Lever\_001

Change lever

## Traveling Clutch Lever



### **A** Caution


Be sure not to engage the throttle lever quickly to the "High" (rabbit icon) position, in order to avoid sudden acceleration.

To prevent sudden acceleration, pull the traveling clutch lever slowly.

Start the machine while allowing the belt to slip in the same way as clutch-slipping.

When the traveling clutch is set to the "ON" position, the reel cutter automatically rotates when the rear mower is lowered.

When the traveling clutch is set to the "OFF" position, the reel cutter does not rotate, even if the rear mower is lowered.



Traveling Clutch Lever 001

1	Traveling clutch lever
2	Reel rotation lever


### Operation of Reel Rotation Lever



#### **A** Caution

Unless both left and right mower units have been lowered all the way, you are not able to operate the reel rotation lever.

To rotate the reel cutter (cutting cylinder) for the left and right mower units, pull the reel rotation lever.



Operation of Reel Rotation Lever 001

Reel rotation lever

### Operation of Brake Pedal

The brake pedal is located in the right foot

In order to stop the machine, depress the brake pedal with your right foot until the pedal hits the pedal stopper.

### Operation of Diff-lock Pedal

The diff-lock pedal is located in the left foot area.

If you press the diff-lock pedal, the differential device is locked to enhance linearity, thus preventing slipping.

### Parking Brake Lever



#### **A** Caution

Be sure to release the parking brake before driving.

It may result in the brakes malfunctioning.




#### **A** Caution

Never park the machine on a slope.

The parking brake lever is located on the left side of the saddle.

To park the machine, pull the parking brake lever completely.

To release the parking brake, press the push button while lowering the parking brake lever all the way to its resting position.



Parking Brake Lever 001

1	Push button
2	Parking brake lever
3	Adjustment bolt

### Travel of Machine

## Moving the Machine



#### ▲ Caution

Make sure not to touch rotating tires with your hands or legs.

- 1. Start the engine. "Procedure to Start Engine" (Page 4-12)
- 2. Depress the brake pedal, and release the parking brake.
- 3. Shift the change lever in arbitrary position.
- 4. Slowly pull the traveling clutch lever in the same way as half clutch.
- 5. The machine can start traveling.

## **Cutting Work**

## **Cutting Operation**

### ▲ Caution

Cutting work must be performed at an appropriate speed for the site and location. When cutting bumpy surfaces, keep the engine rpm steady, and slow down the cutting speed.

- 1. Start the engine. "Procedure to Start Engine" (Page 4-12)
- 2. Lower all the mower units.
- 3. Depress the brake pedal, and release the parking brake.
- 4. Shift the throttle lever to the "High" (Rabbit icon) position.
- 5. Shift the change lever in arbitrary position.
- 6. Pull the reel rotation lever to rotate the reel cutters (cutting cylinders) of the left and right mower units.
- 7. Slowly pull the traveling clutch lever in the same way as clutch-slipping to move the machine forward while rotating the reel cutter (cutting cylinder) of the rear mower unit.
- 8. Shift the traveling clutch lever to the "ON" position, and then start the operation.

### Transporting

## Transporting Procedure

When loading the machine into a trailer or a truck to transport it, drive the machine in reverse. When unloading, drive the machine forward.

Page 4-16 Travel of Machine

Maintenance Precautions	Page 5-2
Maintenance Schedule	Page 5-3
Specified Values	Page 5-4
Jacking up the machine	Page 5-5
About the Jacking up the machine  Jack-up Portion	
Greasing	Page 5-6
About Greasing	_
Maintenance (Mower)	Page 5-9
Back Lapping of Reel Cutter (Cutting Cylinder)	Page 5-9
Maintenance (Main Body)	Page 5-10
Removing/Installing Tires	Page 5-11 Page 5-14 Page 5-14 Page 5-15 Page 5-15
Long-Term Storage	Page 5-16
Before Long-Term Storage	Page 5-16

# Maintenance Precautions



# **A** Caution

First, learn well the maintenance operations you plan to perform.



# **A** Caution

Use tools appropriate for each maintenance operation.



# ▲ Caution

For the safe and best performance of your machine, use Baroness genuine parts for replacement and accessories.

Please note that our product warranty may be void if you use non-genuine parts for replacement or accessories.

# Maintenance Schedule

Follow the maintenance schedule below.

Inspect, adjust, supply, cleanReplace (first time)

△ · · · Replace

	$\Delta \cdot \cdot \cdot$ Replace															
	Maintenance Item		After work	Every 8 hrs.	Every 10 hrs.	Every 50 hrs.	Every 100 hrs.	Every 200 hrs.	Every 250 hrs.	Every 400 hrs.	Every 500 hrs.	Every year	Every 2 years	Every 4 years	When Required	Remarks
	Tightening the parts	0														
	Fuel	0														
Engine	Air cleaner	0						Δ								
Eng	Engine oil	0				Δ										8hrs (first time)
	Ignition plug					0	Δ									
	Cleaning the exterior		0													
	Tightening the parts	0														
	Interlock system	0														
	Electrical wiring											0				
	Reel cutter (Cutting cylinder)	0														Refer to "Inspection of Reel Cutter (Cutting Cylinder) and Bed Knife (Bottom Blade)"
	Bedknife (Bottom blade)	0														Refer to "Inspection of Reel Cutter (Cutting Cylinder) and Bed Knife (Bottom Blade)"
ypc	Operating height (Mowing height)	0														
Main body	Blade engagement	0														
Mai	Greasing, oiling					0										Refer to "greasing point"
	Tire	0														Refer to "Inspection of Tires"
	V-belt	0										Δ				
	Brake	0													Δ	Refer to "Inspection of Brake"
	Brake wire														Δ	Refer to "Inspection of Wire"
	Throttle wire	0													Δ	Refer to "Inspection of Wire"
	Reel cover	0														Refer to "Inspection of Covers"
	Belt cover	0														Refer to "Inspection of Covers"

Page 5-3 Maintenance Schedule

Maintenance Item		Before work	After work	Every 8 hrs.	Every 10 hrs.	Every 50 hrs.	Every 100 hrs.	Every 200 hrs.	Every 250 hrs.	Every 400 hrs.	Every 500 hrs.	Every year	Every 2 years	Every 4 years	When Required	Remarks
	Oil leakage	0														
body	Transmission oil	0										Δ				50hrs (first time)
	Fuel strainer						0					Δ				
Main	Fuel pipe	0														
	Cleaning the exterior		0													

For the maintenance schedule of the items unlisted above, refer to the Engine's Owner's Manual.

The values for consumables are not guaranteed.

Air cleaner should be cleaned more often in dusty conditions than in normal conditions.

# **Specified Values**

Fuel ta	nk capacity	6.0 dm <sup>3</sup> (6.0 L)			
Quanti	ty of transmission oil	2.0 dm <sup>3</sup> (2.0 L)	Transmission gear oil #90		
Quanti	ty of engine oil	1.2 dm <sup>3</sup> (1.2 L)	Summer: SAE30, Winter: SAE20		
Front ti	ire	200 kPa (2.0 kgf/cm <sup>2</sup> )	4.00 - 5		
Rear ti	re	80 kPa (0.8 kgf/cm <sup>2</sup> )	18 x 8.50 - 8		
Diff-loc	k wire	Create a slight play			
Brake pedal		5 - 7 mm	Clearance between pedal stopper and brake pedal		
	Traveling clutch	5 mm	Clearance between rod-tension metal fitting and collar		
	Reel rotation lever	5 mm	Clearance between rod-tension metal fitting and collar		
Belt	Left and Right Mower Units	1 mm	Clearance between collar and mower lifting arm		
	Transmission	Approximately 10mm/98N (10kgf)	Belt slack		
	Rear mower tension	1 mm	Clearance of spring		
	Rear Mower Unit	Approximately 10mm/98N (10kgf)	Belt slack		
Left / right mower stopper		90°	Angle against the frame		
Wire to hook the rear mower		The hook metal fitting should contact with the lever mounting bracket slightly.			
Wire to mower	hook the left / right	Create a slight play	The hook metal fitting should contact with the bottom of the hook.		

Page 5-4 Maintenance Schedule

# Jacking up the machine

### About the Jacking up the machine



When replacing a tire or beginning any other maintenance or repairs, be sure to chock the wheels to prevent the machine from moving. Before jacking up the machine, park it on a hard, flat surface such as a concrete floor and remove any obstacles that could prevent you from performing the work safely.

When necessary, use an appropriate chain block, hoist, or jack.

Support the machine securely with jack stands or appropriate blocks.


Failure to do so may cause the machine to move or fall, resulting in injury or death.

Use the jack-up points identified in this manual when jacking up the machine.

Only place a jack under the jack-up points specified.

Placing a jack at any other point could result in damage to the frame or other parts.


# Jack-up Portion



Jack-up Portion\_001


	Jack-up Portion
1	Front axle, center
2	Front axle, right
3	Front axle, left
4	Transmission case, lower
5	Transmission axle case, left
6	Transmission axle case, right

### 1. Front axle, center




Jack-up Portion\_002

### 2. Front axle, right




Jack-up Portion\_003

### 3. Front axle, left




Jack-up Portion\_004

### 4. Transmission case, lower




Jack-up Portion\_005

### 5. Transmission axle case, left



Jack-up Portion\_006

### 6. Transmission axle case, right



Jack-up Portion\_007

# Greasing

# **About Greasing**

Since there may be adhesion or damage due to lack of grease on moving parts, they must be greased.

Add urea-based No. 2 grease in accordance with the Maintenance Schedule.


Other locations where the specified grease or lubricant is used are indicated in "Greasing Points"

Add grease using the specified grease or lubricant.

### **Greasing Points**

Grease nipples are installed in the following locations.

Add grease every 50 hours of operation.




Greasing Points 001

	Portion	No. of Greasing Points
1	Front wheels	2
2	Front wheel front pin	1
3	Reel housing	6
4	Mower frame	2
5	Mower lifting arm	2
6	Diff-lock pedal	1
7	Handle tension	5
8	Brake pedal	1
9	Rear mower oscillating metal part	1
10	Rear roller	6
11	Mower tension	2

Page 5-6 Greasing


### 1. Front wheels

There is one point each on the left and the right wheel.



Greasing Points\_002


### 2. Front wheel front pin



Greasing Points\_003

### 3. Reel housing


There is one point each on the left and the right of each unit.



Greasing Points\_004

### 4. Mower frame


There is one point each on the left and the right mower units.



Greasing Points\_005


### 5. Mower lifting arm

There is one point each on the left and the right mower units.



Greasing Points\_006


### 6. Diff-lock pedal



Greasing Points\_007

Greasing Page 5-7


# 7. Handle tension Supply automobile transmission gear oil #90



Greasing Points\_008


Greasing Points\_009

### 8. Brake pedal



Greasing Points\_010


### 9. Rear mower oscillating metal part



Greasing Points\_011


### 10. Rear roller

There is one point each on the left and the right of each unit.




Greasing Points\_012

#### 11. Mower tension



Greasing Points\_013



Greasing Points\_014

Page 5-8 Greasing

### Maintenance (Mower)

# Back Lapping of Reel Cutter (Cutting Cylinder)

Back lapping is work similar to sharpening a cooking knife. If the edges of the reel cutter (cutting cylinder) and the bed knife (bottom blade) become blunt and make cutting difficult, both the reel cutter (cutting cylinder) and the bed knife (bottom blade) should be simultaneously sharpened by reversing the reel cutter (cutting cylinder) with an abrasive paste applied.

However, back lapping is a temporary measure and would not restore the sharpness completely.

If the edges of the reel cutter (cutting cylinder) and the bed knife (bottom blade) become blunt and difficult to cut, follow the steps below to perform back lapping.



Both the reel cutter (cutting cylinder) and the bed knife (bottom blade) are edged tools. Handle them carefully, since they could cut your hands and feet.

# ▲ Caution

Be careful not to inhale exhaust gas during back lapping.

# ▲ Caution


During back lapping, the reel cutter (cutting cylinder) rotates.

Keep hands and feet away from moving parts.

# ▲ Caution

Do not perform back lapping with any other persons.

 Have the following items ready: Back lapping machine [Baroness RM20B], Strips of newspaper, Abrasive [Back lapping powder mixed with oil; or gel compound (Baroness genuine abrasive)], Brush, Socket (opposite side 27).



Back Lapping of Reel Cutter (Cutting Cylinder)\_001

1	Newspaper
2	Back lapping powder
3	Gel compound
4	Brush
5	Socket (opposite side 27)
Α	27 mm

#### Note:

Mixing ratio for abrasive in volume is one part back lapping powder (#150 - #200) to three or four parts oil.

# ▲ Caution

When handling the reel cutter (cutting cylinder) or bed knife (bottom blade), wear gloves to protect your hands.

Pay attention not to let the reel cutter (cutting cylinder) catch your gloves, etc. Otherwise, you may injure your hand or fingers.

### Important

After cutting grass, adjust the engagement of the blades, before checking the sharpness of the blade.

- 2. Stop the engine.
- 3. Insert two or three strips of newspaper into the space between the reel cutter (cutting cylinder) and the bed knife (bottom blade) at an angle of 90 degrees, then rotate the reel cutter (cutting cylinder) counter-clockwise (when you face the mower unit from the left) by hand to check the sharpness.
- 4. Check the sharpness at entire range (three or four points from left edge to right one) of the reel cutter (cutting cylinder).
- 5. Using a piece of chalk, mark locations on the blade that are sharp.
- 6. Lower all the mower units to the ground.

- Connect the lapping machine and the shaft of reel cutter (cutting cylinder) with the socket (opposite side 27).
- 8. Turn on the switch of the lapping machine to rotate the reel cutter (cutting cylinder) in the direction opposite to the cutting direction.
- Apply the abrasive evenly with the brush on the top side of reel cutter (cutting cylinder) where the newspaper was cut well or of chalk-marked locations. (Never apply to blunt areas.)
- 10. Idle the machine for a while, and then switch off the lapping machine to stop rotation of the reel cutter (cutting cylinder) when contact noise is no longer heard.
- 11. Wash off or wipe off with cloth etc. the abrasive from the reel cutter (cutting cylinder), then check it for sharpness.
- 12. Repeat steps 3 to 11 until the entire range (three or four points from left edge to right one) of the reel cutter (cutting cylinder) will be uniformly sharpened.
- 13. Finally, apply the abrasive on the entire blade width of the reel cutter (cutting cylinder) and perform final back lapping.
- 14. Stop the rotation of the reel cutter (cutting cylinder), and then carefully and thoroughly wash off any remaining abrasive.
- 15. While checking the blade for sharpness, adjust blade engagement.


# Maintenance (Main Body)

# Removing/Installing Tires

#### Front Tires

Follow the steps below to remove the front tires:

1. Loosen the bolts



Front Tires\_001

- Place the tire jack beneath the jack-up point of the front axle area securely, then raise it until the tire lifts off the ground.
  - "Jack-up Portion" (Page 5-5)
- 3. Remove the bolts.
- 4. Remove the tire from the wheel mounting shaft.

# **▲** Caution

Refer to the Tightening Torque table. Note that the Baroness product warranty may not apply to defects caused by incorrect or overtorque tightening.

### Important


Tighten the bolts in the tightening order (crosswise).

For installing the front tires, reverse the removing procedure.

#### Rear Tires

Follow the steps below to remove the rear tires:

1. Loosen the bolts.



Rear Tires\_001

- Place the tire jack beneath the jack-up point of the rear wheel transmission area securely, then raise it until the tire lifts off the ground.
  - "Jack-up Portion" (Page 5-5)
- 3. Remove the bolts.
- Remove the tire from the wheel mounting shaft.



### **A** Caution

Refer to the Tightening Torque table. Note that the Baroness product warranty may not apply to defects caused by incorrect or overtorque tightening.

### Important

Tighten the bolts in the tightening order (crosswise).

For installing the rear tires, reverse the removing procedure.

### Adjustment of Belt Tension



### **A** Caution

Be sure to stop the engine before adjusting the belts.

### **Important**

Make sure that the belt has the specified amount of tension.


If the belt becomes slack due to frequent use, it may jump or slip.

In addition, if it is overtightened, it may wear prematurely.

If necessary, adjust it, and always check the belt for appropriate tension.

#### **Belt Installation Locations**

Belts are installed in this machine at the following locations.




Belt Installation Locations\_001

1	Traveling clutch
2	Reel rotation lever
3	Left and Right Mower Units
4	Transmission
5	Rear mower tension
6	Rear Mower Unit

### **Traveling Clutch**

- 1. Loosen the adjustment bolt, then change the length of the rod.
- 2. Adjust the clearance between the rodtension metal fitting and the collar to be 5mm, when the traveling clutch lever is engaged.
- 3. Tighten the adjustment bolt and make sure that the collar is fixed securely.




Traveling Clutch\_001

1	Adjustment bolt
2	Rod
3	Traveling clutch lever
4	Rod-tension metal fitting
5	Collar

#### Reel Rotation Lever

- 1. Loosen the adjustment bolt, then change the length of the rod.
- 2. Adjust the clearance between the rodtension metal fitting and the collar to be 5mm, when the traveling clutch lever is engaged.
- 3. Tighten the adjustment bolt and make sure that the collar is fixed securely.




Reel	Rotation	Lever	001
1 (00)	Notation		001

1	Adjustment bolt
2	Rod
3	Traveling clutch lever
4	Rod-tension metal fitting
5	Collar

### Left and Right Mower Units

- Belts are always stretched at a constant tension by the springs.
   Loosen the adjustment bolt, then adjust the clearance between the collar and the mower lifting arm to be 1mm.
- 2. Tighten the adjustment bolt and make sure that the collar is fixed securely.
- 3. Follow the same steps to adjust the belts on the mower unit on the opposite side.




Left and Right Mower Units\_001

1	Spring
2	Adjustment bolt
3	Collar
4	Mower lifting arm

### Transmission

- 1. Loosen adjusting nut A.
- 2. Tighten adjusting nut B, then change the length of the rod.
- 3. Adjust the belt tension so that the belt slacks by approximately 10mm when you press the middle of the belt with your finger at 98N (10kgf).
- 4. Tighten adjusting nut A and make sure that the rod is fixed securely.




Transmission\_001

1	Adjusting nut A
2	Adjusting nut B
3	Rod

### **Rear Mower Tension**

- 1. Loosen adjusting nut A.
- 2. Tighten adjusting nut B, then change the length of the rod.
- 3. Lower the rear mower unit on a level surface, then adjust the clearance of the spring to 1mm.
- 4. Tighten adjusting nut A and make sure that the rod is fixed securely.
- 5. Raise the rear mower unit, then make sure that the reel cutter (cutting cylinder) will not rotate when the machine travels.




Rear Mower Tension\_001

1	Adjusting nut A
2	Adjusting nut B
3	Rod
4	Rear mower unit

### Rear Mower Unit

- 1. Loosen adjusting nut A.
- 2. Tighten adjusting nut B, then change the length of the rod.
- Adjust the belt tension so that the belt slacks by approximately 10mm when you press the middle of the belt with your finger at 98N (10kgf).

4. Tighten adjusting nut A and make sure that the rod is fixed securely.




Rear Mower Unit\_001

1	Adjusting nut A
2	Adjusting nut B
3	Rod

### Adjustment of Parking Brake

If the parking brake is not effective enough when you pull the parking brake lever, adjust the brake wire.

- 1. While pressing the push button, return the parking brake lever to its resting position to release the parking brake.
- Loosen the nut on the parking brake lever side.
- 3. Move the wire adjustment bracket toward the rear to increase the wire tension.
- 4. Tighten the nut securely to fix the wire adjustment metal fitting.
- 5. Make sure that the brake is applied properly when you pull the parking brake lever, and that there is no brake dragging when you release the parking brake lever.



Adjustment of Parking Brake\_001

,	-,	
	1	Parking brake lever
	2	Brake wire
	3	Nut
	4	Wire adjustment metal fitting
	5	Brake drum


#### Note

You can also adjust the brake wire on the transmission side.

### Adjustment of Brake

If the brake is not applied effectively even if you depress the pedal up to the stopper, adjust the brake rod.

- Pull the parking brake lever completely and make sure that the brake is effectively applied.
- 2. Loosen the lock nut.
- Remove the cotter pin, washer and pin that affix the brake pedal to the front of the brake rod.
- 4. Screw in the nut on the front of the brake rod, then temporarily affix the brake pedal to the front of the brake rod using the pin.
- 5. Depress the brake pedal lightly, and adjust the clearance between the pedal stopper and brake pedal to 5-7mm.(If the clearance is larger than 7mm, the brake may be damaged.)
- 6. Affix the brake pedal to the front of the brake rod securely using the pin.
- 7. Tighten the lock nut to secure the front of the brake rod firmly.
- 8. Make sure that the brake is not applied any longer when you release the brake pedal.




Adjustment of Brake\_001

1	Brake pedal
2	Pedal stopper
3	Parking brake lever
4	Lock nut
5	Brake rod (front)
6	Cotter pin, washer, pin
7	Brake drum

### Adjustment of Diff-lock Wire

If the diff-lock seems ineffective when you depress the diff-lock pedal, adjust the diff-lock wire.

- 1. Make sure that the diff-lock pedal has completely returned to its resting position.
- 2. Loosen the nut on the transmission side.
- 3. Loosen the wire adjustment bracket upward to increase the wire tension.
- Adjust the wire so that the diff-lock wire and the diff-lock lever show a little play when the lever returns to its resting position under spring tension.
- 5. Tighten the nut and fix the wire adjustment bracket completely.



Adjustment of Diff-lock Wire\_001


-	_
1	Transmission
2	Nut
3	Wire adjustment bracket
4	Wire
5	Spring
6	Diff-lock lever

### Note:

You can also adjust the diff-lock wire on the pedal side.

# Adjustment of Mower Stopper

- 1. Lower the left and right mower units, then engage the reel rotation lever.
- Loosen the nut, then adjust the position of the wire adjustment bracket so that the mower stopper will be positioned at 90 degrees against the frame.
- 3. Tighten the nut securely to fix the wire adjustment bracket.
- 4. Make sure that the mower stopper will spring back when you release the reel rotation lever.




Adjustment of Mower Stopper\_001

1	Nut
2	Wire adjustment bracket
3	Mower stopper
4	Frame
5	Spring
6	Left mower lifting arm
7	Right mower lifting arm

# Adjustment of Wire to Hook Mower

Wire to hook the left / right mower

- 1. Loosen the nuts and move the wire adjustment metal fitting toward the outside of the machine to increase the wire tension.
- 2. Without gripping the lever, raise the right mower unit, then make adjustment so that the hook metal fitting will be in touch with the bottom of the hook and the wire will have a small play.
- 3. Tighten the nuts and fix the wire adjustment metal fitting securely.
- 4. Follow the same steps to adjust the hook wire of left mower.




Wire to hook the left / right mower\_001

1	Nut
2	Wire adjustment bracket
3	Wire (to hook the mower)
4	Right mower unit
5	Hook metal fitting
6	Bottom of the hook

#### Wire to hook the rear mower


- 1. Loosen the nuts and move the wire adjustment metal fitting toward the center of the machine to increase the wire tension.
- Lower the rear mower unit, then adjust the hook metal fitting to come into contact slightly with the lever mounting bracket when you grip the lever completely.
- 3. Tighten the nuts and fix the wire adjustment metal fitting securely.



Wire to hook the rear mower\_001

1	Nut
2	Wire adjustment metal fitting
3	Wire
4	Hook metal fitting
5	Lever mounting bracket

4. When the hook metal fitting returns to its original position by spring tension as soon as you release the lever, raise the rear mower lifting arm and make sure that the hook metal fitting is located closer to the center of the machine than the upper tip of the hook.



Wire to hook the rear mower\_002

1	Hook metal fitting
2	Spring
3	Rear mower lifting arm
4	Hook

# Long-Term Storage

### Before Long-Term Storage

- Remove any dirt, grass, debris, or oil stains completely.
- Supply oil and apply grease to appropriate parts.

Page 5-16 Long-Term Storage

**EU Declaration of Conformity** 

dΒ

Product Identification

Product: Make: Type: Version(s): Starting Serial No. :

Lawnmower **BARONESS** LM180 20263

Measured Sound Power Level: Guaranteed Sound Power Level : LWA 102.37 LWA 105 Kyoeisha Co., Ltd.

Manufacturer

Name: Address: 1-26 Miyuki-cho, Toyokawa, Aichi-pref., Japan

Conforms to the following Directives 2006/42/EC

Machinery (MD)

2014/30/EU 2000/14/EC

Electromagnetic compatability (EMC) Noise emissions from outdoor equipment

We has been designed and manufactured using the following specifications ISO 12100 : 2010 (2006/42/EC)

ISO 5395-1: 2013 (2006/42/EC) ISO 5395-3: 2013 (2006/42/EC) ISO 14982 :1998 (2014/30/EU)

Technical Documentation

Keeper's Name: Keeper's Address : Kyoeisha Co., Ltd.

1-26 Miyuki-cho, Toyokawa, Aichi-pref., Japan

Compiler of the technical file (2006/42/EC)

Address

Kyoeisha U.K.Ltd.

Unit 5 Hatch Industrial Park Grewell Road, Basingstke Hampshire RG24 7NG, the United Kingdom

muya kone ko

Conformity assessment procedures

Internal production control: Module A (2006/42/EC) EC-type examination: Module B (2014/30/EU)

Internal control of production with assessment of technical documentation and periodical checking (2000/14/EC)

Involved Notified Body (2000/14/EC)

Address:

Place: Japan

Certificate / Technical Documentation No. :

11, Route de Sandweiler 5230 Sandweiler Luxembourg SNCH\*2000/14\*2005/88\*1850\*03/TCLM180-03

Signature

Date: 27 February 2018

Name: Kimiya Kaneko Position: Quality Dept. Manager

(fr)

### Déclaration de conformité UE

Identification du produit

Produit: Fabriquant : Type: Version(s):

Tondeuse à gazon BARONESS LM180

20263

LwA

LwA

Numéro de série de début : Niveau de puissance acoustique mesuré :

102.37 dB 105 dB

Niveau de puissance acoustique garanti : Fabricant

Nom:

Kvoeisha Co., Ltd. 1-26. Miyuki-cho, Toyokawa, préfecture d'Aichi, Japon

Adresse: Conforme aux directives suivantes :

2006/42/CE

2014/30/UE 2000/14/CE Machine (MD) Compatibilité électromagnétique (CEM) Émissions sonores de l'équipement de plein air

Conception et fabrication en respect des spécifications suivantes :

ISO 12100 : 2010 (2006/42/CE) ISO 5395-1: 2013 (2006/42/CE) ISO 5395-3: 2013 (2006/42/CE) ISO 14982 :1998 (2014/30/UE)

Fiche technique

Marque:

Kyoeisha Co., Ltd.

Adresse de la marque :

1-26, Miyuki-cho, Toyokawa, préfecture d'Aichi, Japon

Compilateur de la fiche technique (2006/42/CE)

Nom: Adresse

Procédures d'évaluation de la conformité

Unit 5 Hatch Industrial Park Greywell Road, Basingstoke Hampshire RG24 7NG, Royaume-Uni

Contrôle de production interne: module A (2006/42/CE)

Examen de type CE: module B (2014/30/UE)

Contrôle interne de la production avec évaluation de la fiche technique et vérification périodique (2000/14/CE)

Organisme notifié impliqué (2000/14/CE)

Nom:

Adresse :

Nº de certificat/Documentation technique :

11. Route de Sandweiler 5230 Sandweiler, Luxembourg SNCH\*2000/14\*2005/88\*1850\*03/TCLM180-03

EU02 - 1

### Declaración de conformidad de la UE

Identificación del producto

Producto: Marca:

Cortacésped

Tipo:

**BARONESS** LM180

Versión: N.º de serie inicial:

20263

Nivel de potencia sonora medido:

LWA LWA 102.37 dΒ 105 dΒ

Nivel de potencia sonora garantizado: Fabricante

Nombre:

Dirección:

Kyoeisha Co., Ltd. 1-26 Miyuki-cho, Toyokawa, Aichi-pref., Japón

Cumple las siguientes Directivas

2006/42/CE

Maquinaria (MD)

2014/30/UE 2000/14/CE Compatibilidad electromagnética (EMC) Emisiones sonoras de máquinas de uso al aire libre

Se ha diseñado y fabricado utilizando las siguientes especificaciones

ISO 12100 : 2010 (2006/42/CE) ISO 5395-1: 2013 (2006/42/CE) ISO 5395-3: 2013 (2006/42/CE) ISO 14982 :1998 (2014/30/UE)

Documentación técnica

Nombre del responsable:

Kyoeisha Co., Ltd.

Dirección del responsable:

1-26 Miyuki-cho, Toyokawa, Aichi-pref., Japón

Compilador del archivo técnico (2006/42/CE)

Nombre: Dirección: Kyoeisha U.K. Ltd.

Unit 5 Hatch Industrial Park Greywell Road, Basingstoke Hampshire RG24 7NG, Reino Unido

Procedimientos de evaluación de conformidad

Control de fabricación interno: Módulo A (2006/42/CE)

Examen de tipo CE: Módulo B (2014/30/UE)

Control interno de fabricación con evaluación de documentación técnica y comprobaciones periódicas (2000/14/CE)

Organismo notificado implicado (2000/14/CE)

Nombre:

SNCH

Dirección: Certificado/Documentación técnica n.º: 11, Route de Sandweiler 5230 Sandweiler Luxemburgo SNCH\*2000/14\*2005/88\*1850\*03/TCLM180-03

(de)

# **EU-Konformitätserklärung**

ďΒ

Produktbeschreibung

Produkt: Marke: Modell: Version(en): Rasenmäher BARONESS LM180

Nicht zutreffend Startseriennummer: 20263

Gemessener Schallleistungspegel: Garantierter Schallleistungspegel:

102.37 LWA

Hersteller Adresse:

105 Kyoeisha Co., Ltd.

1-26 Miyuki-cho, Toyokawa, Aichi-pref., Japan

Entspricht den folgenden Richtlinien

2006/42/EG

Maschinenrichtlinie

2014/30/EU 2000/14/EG Elektromagnetische Verträglichkeit (EMV) Geräuschemission von im Freien betriebenen Geräten

Unter Anwendung der folgenden Bestimmungen entwickelt und hergestellt ISO 12100 : 2010 (2006/42/EG) ISO 5395-1: 2013 (2006/42/EG)

ISO 5395-3: 2013 (2006/42/EG) ISO 14982 :1998 (2014/30/EU)

Technische Dokumentation

Name des Halters

Kyoeisha Co., Ltd.

Adresse des Halters

1-26 Miyuki-cho, Toyokawa, Aichi-pref., Japan

Technische Unterlagen erstellt von (2006/42/EG)

Name: Adresse: Kyoeisha U.K.Ltd. Unit 5 Hatch Industrial Park Grewell Road, Basingstoke Hampshire RG24 7NG, Großbritannien

Konformitätsbewertungsverfahren

Interne Produktionskontrolle: Modul A (2006/42/EG)

EG-Baumusterprüfung: Modul B (2014/30/EU) Interne Produktionskontrolle mit Bewertung der technischen Unterlagen und regelmäßiger Überprüfung (2000/14/EG)

Beteiligte benannte Stelle (2000/14/EG)

Adresse 11. Route de Sandweiler 5230 Sandweiler Luxemburg Bescheinigung/Technische Dokumentation Nr.: SNCH\*2000/14\*2005/88\*1850\*03/TCLM180-03

EU02 - 2

### EU-försäkran om överensstämmelse

Produktidentifikation

Produkt: Märke:

Gräsklippare BARONESS LM180

Тур: Version(er):

Serienummer startar på:

Uppmätt ljudeffektnivå: Garanterad ljudeffektnivå: 20263 LWA LWA

102.37 105

Tillverkare

Maskindirektivet

Kyoeisha Co., Ltd.

1-26 Miyuki-cho, Toyokawa, Aichi-pref., Japan

Uppfyller följande direktiv

2006/42/EG

2014/30/EU 2000/14/EG

Elektromagnetisk kompabilitet (EMC) Bulleremission från utomhusutrustning Följande kravspecifikationer har följts vid konstruktion och tillverkning

ISO 12100 : 2010 (2006/42/EG) ISO 5395-1: 2013 (2006/42/EG) ISO 5395-3: 2013 (2006/42/EG) ISO 14982: 1998 (2014/30/EU)

Teknisk dokumentation

Innehavarens namn:

Kyoeisha Co., Ltd.

Innehavarens adress:

1-26 Miyuki-cho, Toyokawa, Aichi-pref., Japan

Den tekniska filen(2006/42/EG) har tagits fram av

Namn: Adress:

Unit 5 Hatch Industrial Park Grewell Road, Basingstoke Hampshire RG24 7NG, Storbritannien

Förfarande för bedömning av överensstämmelse

Intern produktionskontroll: Modul A (2006/42/EG)

EG-typprovning: Modul B (2014/30/EU)

Intern kontroll av produktion med fastställande av teknisk dokumentation och periodiska kontroller (2000/14/EG)

Anmält organ (2000/14/EG)

Namn:

Adress: Certifikat/Teknisk dokumentation nummer: 11, Route de Sandweiler 5230 Sandweiler Luxembourg

SNCH\*2000/14\*2005/88\*1850\*03/TCLM180-03



