


5-Unit Rotary Mower

Owner's Operating Manual



Serial No. GM2810A: 11248-

"Required reading"
Read this manual before using the machine.



Regulations

California Proposition 65

(For California, USA)

WARNING:

Operating, servicing and maintaining a passenger vehicle or off-road vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to www.P65Warnings.ca.gov/passenge r-vehicle.

318yi8-005

California Proposition 65_001

California Spark Arrester

(For California, USA)



Operation of this equipment may create sparks that can start fires around dry vegetation.

A spark arrester may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

It is a violation of California Public Resource Code Section 4442 or 4443 to use or operate the engine on any forest-covered, brush-covered, or grass-covered land unless the engine is equipped with a spark arrester, as defined in Section 4442, maintained in effective working order or the engine is constructed, equipped, and maintained for the prevention of fire pursuant to Section 4443.

The DPF installed on the engine of this machine meets requirements of California Public Resource Code Section 4443.

EU Regulations

(For EU)

This product complies with all relevant EU Regulations.

For more information, please refer to the respective Declaration of Conformity attached.

EU Emission Control (Stage V)

(For Europe)

Important


No deliberate tampering with or misuse of the engine emissions control system should take place.

Make repairs immediately if the fault codes of PCD (Particulate Control Diagnostic) and NCD (NOx Control Diagnostic) appear. Tampering with and use without effect of the engine emissions control system are regulatory infringements and they are penalized.

Thank you for purchasing the Baroness product. This manual describes the proper handling, adjustment, and inspection of your product. We hope you will use the product safely, and take advantage of its best performance.

Keeping The Owner's Operating Manual

Keep this Manual in the bag located in the rear of the seat.




Keeping The Owner's Operating Manual_001

1 Bag

QR Code

A QR code label is affixed on the machine.



QR Code_001

QR code label

Scan the QR code with your smartphone for easy access to Baroness Manual Reference Service where you can browse Owner's Operating Manual and Parts Catalog. https://doc.baroness-international.com/manuals/GM2810A



QR Code_002

Introduction

Read this manual carefully to ensure that you thoroughly understand how to properly operate and maintain the product, and to avoid causing injury to yourself or others.

The operator is responsible for operating the product properly and safely.

Maintenance service for this machine should be performed by a mechanic with expertise.

If you have any questions concerning maintenance or genuine parts, please contact a Baroness dealer or Kyoeisha.

When making inquiries about your product, please specify the model and serial number.

When loaning or transferring the product, please also provide this manual together with the product.

Kyoeisha Co., Ltd.

Warning Symbols

This manual uses the following warning symbols for handling precautions that are important for your safety.



Warning symbol

696cq5-001

This symbol indicates the articles regarding "Danger," "Warning," or "Caution."

Those articles describe important safety precautions and so read them carefully to understand completely before operating the machine.

Failure to adequately follow these safety precautions may cause an accident.

♠ Danger

This symbol indicates that serious injury or death will occur if the warning is ignored.



This symbol indicates that serious injury or death may occur if the warning is ignored.



This symbol indicates that injury or damage to property may occur if the warning is ignored.

Important

This symbol indicates precautions on the mechanism of the machine.

Precautionary Statement



The information described in this manual is subject to change for improvement without prior notice.

When replacing parts, be sure to use genuine Baroness parts or parts designated by Kyoeisha.

Note that the Baroness product warranty may not apply to defects caused by the use of parts from other companies.

Prior to use, carefully read the following manuals to thoroughly understand the contents for safe and correct operation.

- · Baroness Owner's Operating Manual
- · The Engine's Owner's Manual
- · The Battery's Owner's Manual

Purpose

This product is intended for cutting turf grass at golf courses.

Do not use this product in any way other than its intended purpose, and do not modify this product.

Operating this product for other purposes and modifying it may be very dangerous and may cause damage to the product.

In addition, this product is not authorized for operation as a special motor vehicle. Do not operate it on public roads.

GM2810A

Introduction

Contents

Safety	Page 1-1
Safe Operating Practices	Page 1-2
Disposal	Page 2-1
Recycle and Waste Disposal	Page 2-2
Product Overview	Page 3-1
Specifications	Page 3-2
Names of Each Section	Page 3-4
Regulation Decals	Page 3-5
Safety Signs and Instruction Signs	Page 3-8
Operation Decals	Page 3-16
Description of Functions	Page 4-1
Proximity Sensors	Page 4-2
Relays	Page 4-2
Knife Rotation Switch	Page 4-3
2WD/4WD Selector Switch	Page 4-3
DPF Auto Regeneration Inhibit Switch	Page 4-4
DPF Parked Regeneration Switch	Page 4-5
Light Switch	Page 4-5
Traction Assist Switch	Page 4-6
Mower Lock Lever (Latch)	Page 4-6
Mower Deck Up/Down Lever	Page 4-6
Throttle Knob	Page 4-7
Diff-Lock Switch	Page 4-7
Traveling Pedal	Page 4-7
Brake Pedal	Page 4-8
Parking Brake Lever	Page 4-9
Safety Mechanisms	Page 4-9
Warning Mechanisms	Page 4-9
Monitor	Page 4-11
Engine	Page 4-31
Handling Instructions	Page 5-1
Operations Before Service	Page 5-2
Opening and Closing of Hood	Page 5-2
Opening and Closing of Underseat Cover	Page 5-3
Inspection and Cleaning	Page 5-3
Adjustment before Work	Page 5-17
Start/Stop of Engine	Page 5-20
Parking and Stopping	Page 5-21
Move	Page 5-22
Cutting Work	Page 5-22

Transporting	Page 5-23
Maintenance	Page 6-1
Precautions for Maintenance	Page 6-2
Jacking Up The Machine	Page 6-2
Greasing	Page 6-3
Lubrication	Page 6-6
Adjustment and Replacement	Page 6-7
Storage	Page 6-22
Repair	Page 7-1
Precautions for Repair	Page 7-2
Adjustment and Replacement	Page 7-2
Adjustment and Replacement Towing	=
	Page 7-5
Towing	Page 7-5
Towing	Page 7-5Page 8-1Page 8-2
Towing Appended Table Tightening Torques	Page 7-5 Page 8-1 Page 8-2 Page 8-7

GM2810A

Contents

Safe Operating Practices	Page	1-2
Training	Page	1-2
Preparation	Page	1-2
Operation	Page	1-3
Maintenance	Page	1-4
Storage	Page	1-5

Safety

Failure to adequately follow these safety precautions may cause an accident resulting in injury or death.

♠ Danger

This product is designed to ensure safe operation and has been tested and inspected thoroughly before shipment from the factory. The product is equipped with safety devices to prevent accidents.

However, whether the product demonstrates its original performance level depends on the manner in which it is operated and handled, as well as the manner in which it is managed on a daily basis.

Inappropriate use or management of the product may result in injury or death.

Observe the following safety instructions to ensure safe operation.

Safe Operating Practices

Training

- 1. Read this manual and other training material carefully.
 - Be familiar with the controls, safety signs, and the proper use of the equipment.
- 2. If the operator or mechanic can not read the language used in this manual, it is the owner's responsibility to explain this material to them.
- 3. All operators and mechanics should seek and obtain professional and practical instruction.

The owner is responsible for training the users

Such instruction should emphasize:

- [1] The need for care and concentration when working with ride-on machines.
- [2] Control of a ride-on machine sliding on a slope will not be regained by the application of the brake.

The main reasons for loss of control are

- Insufficient wheel grip
- Being driven too fast
- Inadequate braking
- The type of machine is unsuitable for its task
- Lack of awareness of the effect of ground conditions, especially slopes
- Incorrect hitching and load distribution

- 4. Never allow children or people unfamiliar with these instructions to use or service the machine.
 - Local regulations may restrict the age of the operator.
- The owner/user can prevent and is responsible for accidents or injuries occurring to themselves, other people, or property.
- Keep in mind that the owner, operator, and mechanic are responsible for accidents or hazards occurring to other people or their property.
- 7. The ROPS is an integral and effective safety device.

Do not remove or alter the ROPS.

- 8. Replace a damaged ROPS. Do not repair or alter.
- 9. You can find additional safety information where needed throughout this manual.
- 10. Determine the left and right sides of the machine from the normal operating position.

Preparation

- Evaluate the terrain to determine what accessories and attachments are needed to properly and safely perform the job. Only use accessories and attachments approved by the manufacturer.
- While operating, always wear substantial footwear, long trousers, hard hat, safety glasses, mask, and ear protection.
 Long hair, loose clothing, or jewelry may get tangled in moving parts.
 Do not operate the equipment when barefoot or wearing open sandals.
- 3. Inspect the area where the equipment is to be used and remove all objects such as rocks, toys and wire which can be thrown by the machine.
- 4. Keep children out of the operating area and under the watchful care of a responsible adult other than the operator.
- 5. Exercise care in the handling of fuel.



Fuel is highly flammable.

Take the following precautions:

[1] Store fuel in containers specifically designed for this purpose.

- [2] Add fuel before starting the engine. Never remove the cap of the fuel tank or add fuel while the engine is running or when the engine is hot.
- [3] Refuel outdoors only and do not smoke while refueling.
- [4] If fuel is spilled, do not attempt to start the engine but move the machine away from the area of spillage and avoid creating any source of ignition until petrol vapours have dissipated;
- [5] Replace all fuel tanks and container caps securely.
- Check that operator's presence controls, safety switches and shields are attached and functioning properly.
 Do not operate unless they are functioning properly.
- 7. If the brake operation is faulty, be sure to adjust or repair them before operating the machine.
- 8. Replace faulty mufflers.
- Before using, always visually inspect to see that the rotary knives, rotary knife bolts, and cutter assembly are not worn or damaged. Replace worn or damaged rotary knives and bolts in sets to preserve balance.
- On multi-rotary knife machines, take care as rotating one rotary knife can cause other rotary knives to rotate.

Operation

- 1. Do not operate the machine under the influence of alcohol or drugs.
- 2. Do not operate the engine in a confined space where dangerous carbon monoxide fumes can collect.
- 3. Be sure all drives and shift are in neutral and parking brake is engaged before starting engine.
 - Only start engine from the operator's position.
 - Use seat belts if provided.
- Do not change the engine governor settings or overspeed the engine.
 Operating the engine at excessive speed may increase the hazard of personal injury.

- Never operate the machine with damaged guards, shields, or without safety protective devices in place.
 Be sure all interlocks are attached, adjusted
 - properly, and functioning properly.

 Keep hands and feet away from the rotating
- 6. Keep hands and feet away from the rotating parts.
- 7. Do not carry passengers.
- 8. Never operate while people, especially children, or pets are nearby.
- 9. Only operate in good light, keeping away from holes and hidden hazards.
- 10. Do not operate the machine when there is the risk of lightning.
- 11. Do not stop or start suddenly.
- 12. Look behind and down before backing up to be sure of a clear path.
- 13. Slow down and use caution when making turns and crossing roads and sidewalks.
- 14. Use care when approaching blind corners, shrubs, trees, or other objects that may obscure vision.
- 15. Do not take your eyes off the road ahead.

 Do not operate the machine with no hands.
- 16. Remember there is no such thing as a safe slope.
 - Travel on grass slopes requires particular
 - To guard against overturning, follow these instructions.
 - [1] Do not stop or start suddenly when going up or downhill.
 - [2] Engage clutch slowly, always keep machine in gear, especially when traveling downhill.
 - [3] Machine speeds should be kept low on slopes and during turns.
 - [4] Stay alert for humps and hollows and other hidden hazards.
- 17. Never use the machine on a slope with an angle of gradient that is greater than that specified or in a place where there is a danger of the machine slipping.
- 18. Use extra care while operating machine with a grass catcher or other attachments.

 They can affect the stability of the machine.
- 19. Disengage drive to the cutting unit(s), when other than operating.

Safety

- 20. Do the following before leaving the operator's position.
 - [1] Stop on level ground.
 - [2] Disengage the all drives.
 - [3] Set the parking brake.
 - [4] Stop the engine.
 - [5] Remove the ignition key.
- 21. Stop the engine in the following conditions.
 - [1] Before refuelling.
 - [2] Before making height or depth adjustment unless adjustment can be made from the operator's position.
 - [3] Before clearing blockages.
 - [4] Before checking, cleaning or working on the machine.
 - [5] After striking a foreign object or if an abnormal vibration occurs. Inspect the machine for damage and make repairs before restarting and operating the equipment.
- 22. Reduce the throttle setting during engine run-out.
- 23. Never raise mower deck with the rotary knives running.
- 24. Do not mow in reverse unless absolutely necessary.
- 25. Do not direct discharge material toward anyone.
 - Avoid discharging material against a wall or obstruction.
 - Material may ricochet back toward the operator.
- 26. Take care when loading or unloading the machine into a trailer or a truck.
 - Load or unload the machine in a flat and safe place.
 - Before loading or unloading, set the parking brake on the truck or trailer, stop the engine, and chock the wheels.
 - When transporting the machine on a truck or a trailer, set the parking brake, stop the engine, and fasten the machine to the truck with a rope or other suitable restraining device that has sufficient strength.
 - When using a running board, select one with sufficient strength, length, and width and that will not cause the machine to slip.
- 27. Close the fuel valve before transporting the machine.

Maintenance

- 1. Never allow untrained personnel to service machine.
- 2. Implement the following work before adjusting, cleaning or repairing.
 - [1] Stop the machine on level ground.
 - [2] Disengage drive to the cutting unit(s).
 - [3] Lower the cutting unit(s) and/or attachment(s).
 - [4] Set the parking brake.
 - [5] Stop the engine.
 - [6] Remove the ignition key.
- [7] Wait for all movement to stop.
- 3. Allow the engine/muffler to cool before checking/maintenance.
- 4. To reduce the fire hazard, keep hot parts such as the engine and silencer/muffler, battery compartment and fuel storage area free of grass, leaves, or excessive grease. Clean up oil or fuel spillage.
- Appropriately manage and correctly use the tools necessary for servicing or adjusting the machine.
- 6. Disconnect battery before making any repairs.
 - Disconnect the negative terminal first and the positive last.
 - Reconnect positive first and negative last.
- 7. Use jack stands to support components when required.
- 8. Keep hands and feet away from moving parts.
 - If possible, do not make adjustments with the engine running.
- 9. Make sure that parts such as wires are not touching each other and that their covers have not come off.
- Keep all parts in good working condition and all hardware tightened.
 - Replace all worn or damaged decals.
- 11. Keep all nuts, bolts and screws tight to be sure the equipment is in safe working condition.
- 12. Carefully release pressure from components with stored energy.
- 13. Be sure to depressurize the hydraulic system before performing maintenance operations on it such as removing hydraulic equipment.

- 14. Check whether line connectors in the hydraulic system are properly tightened. Before applying hydraulic pressure, check the connections of the hydraulic pressure lines and the condition of the hoses.
- 15. When checking the hydraulic circuit for pinhole leaks or oil leakage from nozzles, do not use your hands.
 Use items such as paper or corrugated

cardboard to find leakage points. Be extremely careful with high-pressure oil as it may pierce your skin, resulting in an

injury.

If fluid is injected into the skin it must be surgically removed within a few hours by a doctor familiar with this form of injury or gangrene may result.

- 16. Use care when checking the rotary knives. Wrap the rotary knives or wear gloves, and use caution when servicing them. Only replace rotary knives. Never straighten or weld them.
- 17. On multi-rotary knife machines, take care as rotating one rotary knife can cause other rotary knives to rotate.
- 18. Charge batteries in an open well ventilated area, away from spark and flames. Unplug charger before connecting or disconnecting from battery. Wear protective clothing and use insulated tools.
- 19. If the fuel tank has to be drained, do this outdoors.

Storage

- When machine is to be parked, stored, or left unattended, lower the cutting unit(s) and/or attachment(s) unless a positive mechanical lock is provided.
- 2. Allow the engine to cool before storing in any enclosure.
- 3. Only cover the machine with a sheet after hot parts have sufficiently cooled down.
- 4. Never store the equipment with fuel in the tank inside a building where fumes may reach an open flame or spark.
- 5. If the engine is provided with a shut-off valve, shut off valve while storing or transporting.
- 6. Do not store fuel near flames.

Swallowing engine coolant can cause injury or death; keep out of reach from children and pets.

Safety

Disposal

ũ
S
ğ
:=
ш

Recycle and Waste Dis	sposalPage	2-2
About Recycle	Page	2-2
About Waste Disposal	Page :	2-2

Disposal

Recycle and Waste Disposal

About Recycle

Recycling battery etc. is recommended for environmental conservation and economical use of resources.

It may be required by local laws.

About Waste Disposal

Make sure that waste generated when servicing or repairing the machine is disposed of in accordance with local regulations. (e.g. waste oil, antifreeze, rubber products, and wires etc.)

Specifications	Page 3-2
Specifications	Page 3-2
Sound Pressure Level	Page 3-3
Sound Power Level	Page 3-3
Vibration Level	Page 3-3
Carbon Dioxide (CO2) Emissions	Page 3-3
Names of Each Section	Page 3-4
Regulation Decals	Page 3-5
Positions of Regulation Decals	Page 3-5
Description of Regulation Decals	Page 3-5
Safety Signs and Instruction Signs	Page 3-8
About Safety Signs and Instruction Signs	Page 3-8
Positions of Safety Signs and Instruction Signs	Page 3-8
Description of Safety Decals and Instruction Decals	Page 3-10
Operation Decals	Page 3-16
Positions of Operation Decals	Page 3-16
Description of Operation Decals	Page 3-17

Specifications

Specifications

Model			GM2810A	
Name		5-Unit Rotary Mower		
	Total length		370 cm	145.67 in
Dimensions	Total width	During operation	300 cm	118.11 in
		During transport	230 cm	90.55 in
		Roof	230 cm	90.55 in
	Total height	Steering wheel	165 cm	64.96 in
Weight	Machine (empty fuel tank)	with ROPS, Roof	2,080 kg	4585.54 lb
Minimum turnir	ng radius		320 cm	125.98 in
	Model		Kubota V2403-CR-TE5B	
	Туре		Vertical water-cooled 4-cycle dies	el engine with turbocharger
Engine	Total displacen	nent	2,434 cm ³ (2.434 L)	148.51 cu.in.
	Maximum outpo	ut	-	
	Rated output		43.2 kW (58.7 PS)/2,400 rpm	
Fuel tank capa	city		Diesel 51.0 dm ³ (51.0 L)	Diesel 13.47 U.S.gals
Fuel consumpt	ion		248 g/kW • h (rated output)	182 g/PS · h (rated output)
Engine oil capa	acity		9.7 dm ³ (9.7 L)	2.56 U.S.gals
Coolant volume	e		12.0 dm ³ (12.0 L)	3.17 U.S.gal.
Hydraulic tank	capacity		44.0 dm ³ (44.0 L)	11.62 U.S.gal.
Transmission of			-	
Operating widt	h (Mowing width)	280 cm	110.24 in
Operating heig	ht (Mowing heigl	ht)	20.0 - 91.5 mm	0.787 - 3.602 in
Number of Bla	des		5	
D.:	Traveling		HST (2WD/4WD selectable)	
Drive	Mowing		Hydraulic	
Creed (UCT)	Forward		0 - 16.0 km/h	0 - 9.94 mph
Speed (HST)	Reverse		0 - 6.0 km/h	0 - 3.73 mph
Speed (Mecha	nical)		-	
Efficiency		20,160 m ² /h (9.0 km/h x mowing width x 0.8)	4.98 acres/hour (5.59 mph x mowing width x 0.8)	
Maximum inclination for operation		15 degrees		
Tiro cizo	Front wheel		29 x 14.00 - 15	
Tire size	Rear wheel		20 x 12.00 - 10	
Tire pneumation	Front wheel		150 kPa (1.5 kgf/cm ²)	22 psi
pressure	Rear wheel		140 kPa (1.4 kgf/cm²)	20 psi
Battery		105D31R		
Engine plug -			-	

Page 3-2 Specifications

The factory default maximum engine rpm is 2,600 rpm.

Sound Pressure Level

Sound Pressure Level

This machine was confirmed to have a continuous A-weighted sound pressure level of 90dB by measuring identical machines in accordance with the procedure specified in ISO 5395-1:2013.

Sound Power Level

Sound Power Level

This machine was confirmed to have a sound power level of 105dB by measuring identical machines in accordance with the procedure specified in ISO5395-1:2013.

Vibration Level

Hand-Arm Vibration

This machine was confirmed not to exceed a vibration level of 2.5 m/s² to hands and arms by measuring identical machines in accordance with the procedure specified in ISO 5395-1:2013.

Whole Body Vibration


This machine was confirmed not to exceed a vibration level of 0.5 m/s² to the whole body by measuring identical machines in accordance with the procedure specified in ISO 5395-1:2013.

Carbon Dioxide (CO₂) Emissions

For the CO₂ value on the engine of this machine, refer to the engine's owner's manual.

Specifications Page 3-3

Names of Each Section




Names of Each Section_001

1	Seat	
2	Steering handle	
3	Tilt lever	
4	Diff-lock switch	
5	Parking brake lever	
6	Brake pedal	
7	Forward pedal	
8	Reverse pedal	
9	Mower deck up/down lever	
10	Throttle knob	
11	Knife rotation switch	
12	2WD/4WD selector switch	
13	Fuel tank	
14	Hydraulic tank	
15	Hood	
16	Radiator	
17	Oil cooler	
18	Radiator cover	
19	Light	
20	Mower deck #1	
21	Mower deck #2	
22	Mower deck #3	
23	Mower deck #4	
24	Mower deck #5	

Page 3-4 Names of Each Section

Regulation Decals

Positions of Regulation Decals




Positions of Regulation Decals 001

Α	Serial number plate
В	Specification decal
С	CE mark
D	UKCA mark (#11152 - 11355)
Е	Noise emission decal
F	Year of manufacture decal
G	ROPS compliance decal
Н	ROPS caution decal
I	Battery capacity decal
J	Recycle decal
K	Battery danger decal
	California proposition 65 decal (riding
_	type)
М	Spark arrester warning decal

Description of Regulation Decals

Serial Number Plate

The serial number plate indicates the model and serial number of the machine.




Serial Number Plate_001

Specification Decal

(For EU/UK)

The Specification decal indicates the model and weight, etc.




Specification Decal_001

CE Mark

(For EU)

CE mark indicates that the machine sold in the EU nations complies with the EU requirements.



CE Mark_001

UKCA Mark

(For UK)

UKCA mark indicates that the machine sold in the UK complies with the UK requirements.




UKCA Mark_001

Regulation Decals Page 3-5

Noise Emission Decal

(For EU/UK)

The noise emission decal indicates the sound power level determined by measuring identical machines in accordance with the procedure specified in the regulations of EU or UK.



Noise Emission Decal_001

Year of Manufacture Decal

(For EU/UK)


The year of manufacture decal indicates the year when this machine was manufactured.



Year of Manufacture Decal_001

ROPS Compliance Decal

The ROPS compliance decal indicates the manufacturer, model, etc., in accordance with International Standard ISO 21299:2009.



ROPS Compliance Decal_001

ROPS Caution Decal

ROPS caution decal describes the following caution messages.

- · Replace damaged ROPS.
- · Do not repair or revise.




ROPS Caution Decal_001

Battery Capacity Decal

(For Europe)

The battery capacity decal indicates the capacity by 20HR and CCA.




Battery Capacity Decal_001

Page 3-6 Regulation Decals

Recycle Decal

Recycle Decal illustrates Recycle Mark in accordance with local regulation. (For Europe)



Recycle Decal_001

(For USA)




Recycle Decal_002

Battery Danger Decal

(For USA)


Battery Danger Decal describes handling precautions for battery.



Battery Danger Decal_001

California Proposition 65 Decal (Riding Type)


(For the State of California, USA) California Proposition 65 decal describes the warning messages as required by California Proposition 65.



California Proposition 65 Decal (Riding Type)_001

Spark Arrester Warning Decal

(For the State of California, USA) Spark arrester warning decal describes the warning messages as required by California Public Resources Code.



Spark Arrester Warning Decal_001

Regulation Decals Page 3-7

Safety Signs and Instruction Signs

About Safety Signs and Instruction Signs


Important

Safety decals and instruction decals are attached to this product.


Make sure that they are preserved in their entirety. If they are damaged, become dirty, or peel off, replace them with new ones.

Part numbers for decals that need to be replaced are listed in the parts catalog. Order them from a Baroness dealer or Kyoeisha.


<u>Positions of Safety Signs and Instruction Signs</u>




Positions of Safety Signs and Instruction Signs_001




Positions of Safety Signs and Instruction Signs_002




Positions of Safety Signs and Instruction Signs_003




Positions of Safety Signs and Instruction Signs_004




Positions of Safety Signs and Instruction Signs_005




Positions of Safety Signs and Instruction Signs_006




Positions of Safety Signs and Instruction Signs_007



Positions of Safety Signs and Instruction Signs_008



Positions of Safety Signs and Instruction Signs_009



Positions of Safety Signs and Instruction Signs_010

,	Todalety Olgris and matruction Olgris_010				
	1	Operation decal			
	2	Engine start/stop decal			
	3	Caution to mutilation decal			
	4	Caution for high temperatures decal			
	5	Caution to injury decal			
	6	Caution to rotating object decal			
	7	Hydraulic oil icon			
	8	Diesel fuel icon			
	9	Fire prohibited decal			
	10	Caution for mower lock decal			
	11	Caution for spouting coolant decal			
	12	Caution to getting pinched decal			
	13	Caution to flying object decal			
	14	Caution for hand or leg injury decal			
	15	Caution exhaust gas decal			
	16	Engine warning lamp decal (EN)			
	17	Caution to noise decal			
	18	Maintenance decal			
	19	2WD/4WD selector important decal			
	20	Knife rotation important decal			
	21	Indicating diesel fuel decal			

<u>Description of Safety Decals and</u> Instruction Decals

Operation Decal

GM2810A0902Z0 Decal, operation

1.



Read the Owner's Operating Manual.

2.



Apply the parking brake, stop the engine, remove the ignition key, and then leave the machine.

3.

▲ Caution

Flying objects - Be sure that people around the machine keep a safe distance away.

4.

▲ Warning

May cut your hand or leg - Keep hands and feet away from moving parts.


5.

▲ Caution

Rollover - Do not work on slopes of 15 degrees or more.

When you descend a slope, lower the mower decks and then drive at low speed.

For ROPS equipped machine, fasten your seatbelt.



Operation Decal_001

Engine Start/Stop Decal


K4205001630 Decal, start/stop engine

1

▲ Warning

Read the Owner's Operating Manual.

- 2. Procedure to Start Engine Read the Owner's Operating Manual.
 - [1] Sit on the seat.
 - [2] Turn the key to the "ON (GLOW)" position, and then wait for the logo "BARONESS" to be turned off.
 - [3] Turn the key to the "START" position.
 - [4] Depress the brake pedal to release the parking brake.
- Procedure to Stop Engine Read the Owner's Operating Manual.
 - [1] Set the knife rotation switch to the "Stop" position, and then raise the mower decks.
 - [2] Apply the parking brake.
 - [3] Turn the key to the "STOP" position, and then remove it.




Engine Start/Stop Decal_001

Caution to Mutilation Decal

K4205001600 DECAL, CAUTION TO MUTILATION

▲ Warning

May cut your hand or leg - Stop the cutter rotation and engine. Otherwise you may get injured.



Caution to Mutilation Decal_001


Caution for High Temperatures Decal

K4205001920

Decal, caution for high temperatures



High temperature - Do not touch. Otherwise, you will get burned.



Caution for High Temperatures Decal_001


Caution to Injury Decal

K4205001580

Decal, caution to injure



May pinch - There is a risk of being pinched.



Caution to Injury Decal_001


Caution to Rotating Object Decal

K4205001530

Decal, caution to rotating object



Watch for rotating parts - Keep your hands away from the belts while the engine is running.




Caution to Rotating Object Decal 001

Hydraulic Oil Icon

K4209000980 Hydraulic oil icon


Read the Owner's Operating Manual.



Hydraulic Oil Icon_001

Diesel Fuel Icon

K4209001000 Diesel fuel icon Use diesel fuel.




Diesel Fuel Icon_001

Fire Prohibited Decal

K4205001940 Decal, fire prohibited



Keep away from fire.



Fire Prohibited Decal 001

Caution for Mower Lock Decal

K4205001900

Decal, caution for mower lock Lock the mower decks when traveling or storing with the mower decks #4 and 5 raised.



Caution for Mower Lock Decal_001

Caution for Spouting Coolant Decal


K4205001970

Decal, caution for spouting coolant



Caution for spouting coolant - Do not open while hot.

High temperature - Do not touch. Otherwise, you will get burned.



Caution for Spouting Coolant Decal_001


Caution to Getting Pinched Decal

K4205001930

Decal, caution to getting pinched



May pinch - There is a risk of being pinched.



Caution to Getting Pinched Decal_001


Caution to Flying Object Decal

K4205001650

Decal, caution to flying object

▲ Caution

Caution to flying object - Be sure that people around the machine keep a safe distance away.



Caution to Flying Object Decal_001


Caution for Hand or Leg Injury Decal

K4205001780

Decal, caution for hand or leg injury



May cut your hand or leg - When the blades are rotating, keep away from the machine.



Caution for Hand or Leg Injury Decal_001


Caution Exhaust Gas Decal

K4205001950

Decal, caution exhaust gas




Caution for exhaust gas



Engine Warning Lamp Decal

K4205002270

Decal, Engine Warning Lamp




Engine Warning Lamp Decal_001

Caution to Noise Decal

K4205002090

Decal, caution to noise




Caution to Noise Decal_001

Maintenance Decal

K4209001940

Maintenance decal

The maintenance decal indicates the necessary inspection and maintenance items for this machine.



Maintenance Decal_001

2WD/4WD Selector Important Decal


K4205002330

DECAL, IMPORTANT 2WD/4WD SELECTOR

Important

Be sure to operate the 2WD/4WD selector switch when the machine stops.

Otherwise, the hydraulic system will malfunction.



2WD/4WD Selector Important Decal_001

Knife Rotation Important Decal


K4205002340

DECAL, IMPORTANT KNIFE ROTATION

Important

Be sure to operate the knife rotation switch when the machine stops.

Otherwise, the hydraulic system will malfunction.



Knife Rotation Important Decal_001


Indicating Diesel Fuel Decal

K4209001530

DECAL, INDICATING DIESEL FUEL

Indicating diesel fuel decal describes the type of fuel to be used.


Use Ultra Low Sulfur Diesel Fuel (sulfur-free diesel).




Indicating Diesel Fuel Decal_001

Operation Decals


Positions of Operation Decals



Positions of Operation Decals_001



Positions of Operation Decals_002



Positions of Operation Decals_003


1	Key switch decal	
2	Knife rotation mark	
3	Traction assist mark	
4	2WD/4WD selector mark	
5	DPF regeneration mark (EN)	
6	Mower deck up/down mark	
7	Light switch mark	
8	Engine rotation mark	
9	Tilt Steering decal	
10	Parking brake decal	
11	Differential lock decal	
12	FORWARD decal	
13	BACKWARD decal	
14	BRAKE Decal	

Page 3-16 Operation Decals

Description of Operation Decals

Key Switch Decal

Decal, key switch This indicates the key switch positions.




Key Switch Decal_001

1	OFF
2	ON (GLOW)
3	START

Knife Rotation Mark

Knife rotation mark It illustrates Rotation/Stop of the rotary knife.




Knife Rotation Mark_001

1	Rotation
2	Stop

Traction Assist Mark

Traction assist mark
It illustrates Activate/ Deactivate of the traction assist.




Traction Assist Mark_001

1	Activate
2	Deactivate

2WD/4WD Selector Mark

2WD/4WD selector mark

This indicates the 2WD/4WD positions.



2WD/4WD Selector Mark_001


1	4WD
2	2WD

Operation Decals Page 3-17

DPF Regeneration Mark (EN)

-


DPF regeneration mark (EN) This indicates the changeover of DPF regeneration.



DPF Regeneration Mark (EN)_001

Mower Deck Up/Down Mark

Mower deck up/down mark
This indicates the Up/Down positions of the mower deck.



Mower Deck Up/Down Mark_001

1	Down
2	Up


Light Switch Mark

Note:

Depending on the specifications, this function may not be available.

Light switch mark

It illustrates ON/OFF of the light.




Light Switch Mark_001

1	ON
2	OFF

Engine Rotation Mark

Engine rotation mark
This indicates low/high speed of engine rotation.



Engine Rotation Mark_001

1	Low speed
2	High speed


Page 3-18 Operation Decals

Differential Lock Decal

K4203001420

Decal, differential lock

This indicates the positions for engaging or releasing the differential lock.



Differential Lock Decal_001


1	Engage
2	Release

Tilt Steering Decal

K4203001350

Decal, tilt steering

This illustrates the tilt directions of the steering wheel and the locked/free positions.




Tilt Steering Decal_001

Parking Brake Decal

K4203001340

Parking brake decal

This shows how to lock and release the parking brake.



Parking Brake Decal_001

1	Lock
2	Release

FORWARD Decal

K4203001430

Decal, FORWARD

This indicates forward travel.




FORWARD Decal 001

Operation Decals Page 3-19

BACKWARD Decal

K4203001440 Decal, BACKWARD

This indicates backward travel.



BACKWARD Decal_001

BRAKE Decal

K4203001450 Decal, BRAKE This indicates brake.



BRAKE Decal_001

Page 3-20 Operation Decals


Proximity Sensors	Page 4-2	
Relays	Page 4-2	
Knife Rotation Switch	Page 4-3	
2WD/4WD Selector Switch	Page 4-3	
OPF Auto Regeneration Inhibit	Page 4-4	
OPF Parked Regeneration Switch .	Page 4-5	
_ight Switch	Page 4-5	
Fraction Assist Switch	Page 4-6	
Mower Lock Lever (Latch)	Page 4-6	
Mower Deck Up/Down Lever	Page 4-6	
Γhrottle Knob	Page 4-7	
Diff-Lock Switch	Page 4-7	
المامية		
Brake Pedal	Page 4-8	
Change of Braking Method	Page 4-8	
Parking Brake Lever	Page 4-9	
Safety Mechanisms	Page 4-9	
Warning Mechanisms	Page 4-9	
Warning Buzzer Engine Warning Lamp Monitor LED	Page 4-10	
Monitor	Page 4-11	
Displayed Icon	_	
Engine	Page 4-31	
Handling Tier 4 Emission Control Compliant Engine	_	

Proximity Sensors

There are two proximity sensors on mower arm fulcrums #4 and #5.

These sensors detect the raised or lowered positions of mower decks #4 and #5.

The information is related to controlling rotation and stop of the rotary knives.




Relays

The relay box is at the front of the right hood. These relays control operation of the diff-lock valve, rotation of the rotary knives, 2WD/4WD selection and traction assist selection.

The operating condition can be checked by the illumination of the LEDs.

- · LEDs ①, ② and ③ light up when the diff-lock valve is in the "ON" position.
- · LED ④ lights up when the traction assist switch is in the "ON" position.
- LEDs ⑤ and ⑥ light up when the knife rotation switch is in the "ON" position and the mower deck is lowered.
- LED ⑦ lights up when the knife rotation switch is in the "ON" position, and then the machine enters 4WD.
- LED ® lights up when the 2WD/4WD selector switch is in the "4WD" position, and then the machine enters 4WD.



Relays_001

1 Relay box

Page 4-2 Proximity Sensors

Knife Rotation Switch



Set the knife rotation switch to the "Rotation" position immediately before starting cutting work. At all other times, be sure to leave the knife rotation switch set to the "Stop" position.

Important


Be sure to switch when the machine stops. Otherwise, the hydraulic system will malfunction.

The knife rotation switch is located in the operation panel and operates rotation of the rotary knives of the mower decks.

When the knife rotation switch is set to the "Rotation" position, the rotary knives of all mower decks will rotate.

When the knife rotation switch is set to the "Stop" position, the rotary knives will stop. Note:

When the mower decks are raised, the rotary knives do not rotate, even if the switch is set to the "Rotation" position.



Knife Rotation Switch_001

-		
1	Knife rotation switch	
Α	Rotation	
В	Stop	

2WD/4WD Selector Switch



When working on a slope, be sure to use the machine in 4WD.

▲ Caution

When traveling, be sure to stop the rotation of the rotary knives and raise the mower decks.


Important

Be sure to switch when the machine stops. Otherwise, the hydraulic system will malfunction.

The 2WD/4WD selector switch is located in the operation panel.

When the switch is set to the "2WD" position, the machine will be in two-wheel drive (front-wheel drive). When it is set to the "4WD" position, the machine will be in four-wheel drive. Note:

When the knife rotation switch is set to the "Rotation" position, the machine enters 4WD, regardless of the position that the 2WD/4WD selector switch is set to.



2WD/4WD Selector Switch 001

_	
1	2WD/4WD selector switch
Α	4WD
В	2WD

Knife Rotation Switch Page 4-3

DPF Auto Regeneration Inhibit Switch



Normally, set the DPF auto regeneration inhibit switch to "Auto regeneration mode". However, when operating in a location where fires may occur, set the DPF auto regeneration inhibit switch to "Auto regeneration inhibit mode".

Important

The DPF auto regeneration inhibit switch is reset to "Auto regeneration mode" when the engine is started even if the engine was stopped with the DPF auto regeneration inhibit switch set to "Auto regeneration inhibit mode".

Important

In "Auto regeneration inhibit mode" any DPF regeneration of "Auto regeneration", "Parked regeneration" and "Manual regeneration" is inhibited.

For DPF regeneration, deactivate "Auto regeneration inhibit mode".


The DPF auto regeneration inhibit switch is located in the operation panel.

The DPF auto regeneration inhibit switch is the switch for shifting between "Auto regeneration mode" and "Auto regeneration inhibit mode". With the engine running, press this switch to shift between "Auto regeneration mode" and "Auto regeneration inhibit mode".

- · Auto regeneration mode:
 - The DPF auto regeneration inhibit switch is reset to "Auto regeneration mode" when the engine is started.
 - In "Auto regeneration mode" regeneration is automatically performed regardless of the main vehicle's travel and stop on the condition that a specific amount of PM is accumulated and the requirements for DPF regeneration are fulfilled.
- Auto regeneration inhibit mode: In order to set to "Auto regeneration inhibit mode", press the DPF auto regeneration inhibit switch after the engine is started.

In "Auto regeneration inhibit mode" PM accumulates in the DPF and PM accumulation level increases.


Unless the operator implements regeneration on his own will, regeneration is not performed.



DPF Auto Regeneration Inhibit Switch_001

1 DPF auto regeneration inhibit switch

When the DPF auto regeneration inhibit switch is pressed and set to "Auto regeneration inhibit mode", the monitor displays Auto regeneration inhibit icon.



DPF Auto Regeneration Inhibit Switch_002

1 Auto regeneration inhibit icon

DPF Parked Regeneration Switch

▲ Danger


Do not perform DPF regeneration in a location where fires may occur since it will become extremely hot around the exhaust outlet during DPF regeneration.

Important

If parked regeneration is not required, it will not start even if the switch is pressed.

The DPF parked regeneration switch is located in the operation panel.


The DPF parked regeneration switch is the switch for actuating parked regeneration. When the regeneration icon is blinking, press the switch to start parked regeneration.



DPF Parked Regeneration Switch_001

DPF parked regeneration switch

When parked regeneration starts, Regeneration icon in the monitor display changes from blinking to lighting.



DPF Parked Regeneration Switch_002

Regeneration icon

Light Switch

Note:


Depending on the specifications, this function may not be available.



The lights provide auxiliary lighting. Do not travel or operate the machine at night or under poor visibility.

The light switch is located in the operation panel.

When the switch is set to the "ON" position, the lights turn on. When it is set to the "OFF" position, the lights turn off.



Light Switch_001

1	Light switch
Α	ON (turn on)
В	OFF (turn off)

Traction Assist Switch


The traction assist switch is located in the operation panel.

This switch is effective to increase climbing ability when this machine is in cutting operation (4WD).

- The cylinders are pressurized even with the switch set to the "OFF" position and so the mower decks are a little raised.
- When the switch is set to the "ON" position and the machine is in cutting operation on a slope of 13 degrees or more, the power lifting the mower decks and climbing ability are further increased.

Note:

Tracking may be impaired if the machine is used with the switch set to the "ON" position in an area with many undulations.



Traction Assist Switch_001


	-
1	Traction assist switch
Α	ON
В	OFF

Mower Lock Lever (Latch)

The mower lock levers (latches) are located in the foot area on the left and right sides. Hook the mower lock levers (latches) on the arms to keep the mower decks #4 and #5 raised.

The mower lock levers (latches) may be used for the following operations.

- Moving by the machine
- · Transporting the machine
- · Storing the machine



Mower Lock Lever (Latch) 001

Mower lock lever (latch)

Mower Deck Up/Down Lever



Before raising or lowering the mower decks, make sure that there are no people around the machine.

Important

When the mower lock levers (latches) are engaged, do not operate the mower deck up/down lever.


The mower deck up/down lever is located in the operation panel and raises or lowers the mower decks.

When the lever is shifted to the "Lower" position, the mower decks are lowered. When the lever is shifted to the "Raise" position, the mower decks are raised.

Release the lever to return it to the neutral position.

Note:

When the mower decks are raised, the rotary knives stop rotating, even if the knife rotation switch is set to the "Rotation" position.



Mower Deck Up/Down Lever_001


Page 4-6 Traction Assist Switch

1	Mower deck up/down lever
Α	Raise
В	Neutral
С	Lower

Throttle Knob

The throttle knob is located to the right of the driver's seat and enables you to adjust the engine rpm.

Move the throttle knob toward the "High speed" position to increase the engine rpm, and toward the "Low speed" to reduce the rpm.



Throttle Knob_001


1	Throttle knob
Α	High speed
В	Low speed

Diff-Lock Switch

Important

Do not operate the diff-lock switch unless it is necessary.

The diff-lock switch is located below the right side of the steering wheel and engages the differential lock for the left and right front wheels. Tilt the switch lever up or down to turn "ON" to engage the differential lock for the front wheels. Release the switch lever to return it to the neutral position ("OFF" position) and disengage the differential lock.



Diff-Lock Switch_001

1	Diff-lock switch
Α	ON (Lock)
В	OFF (Release)

Traveling Pedal

▲ Caution


When the machine is traveling at a high speed, it will not stop immediately after you take your foot off the traveling pedal.

The traveling pedals are located in the right foot area and control forward and reverse operation of the machine.

When the forward pedal (inside) is depressed, the machine travels forward. When the reverse pedal (outside) is depressed, the machine travels in reverse.

The speed changes in accordance with how much the pedal is depressed.

When you take your foot off the pedal, the machine stops automatically.



Traveling Pedal_001

1	Forward pedal
2	Reverse pedal

Throttle Knob Page 4-7

Brake Pedal



Link the brake pedals, except when operating the machine.

Using the brake pedals without linking them may result in the machine overturning.


Important

When depressing the brake pedals to make turns with a small radius, obtain a sufficient awareness of the lawn and ground conditions. This will damage the lawn.

The brake pedals are located in the left foot area and operate the left and right brakes independently.

By depressing the brake pedal on the side in which the turn will be made, the machine can make turns with a small radius.

If the front wheel on the upward side of a slope slips, depress the brake pedal for the wheel on the upward side in order to increase the traction of the wheel on the downward side and stabilize travel.




Brake Pedal_001

1	Brake pedals
2	Parking brake lever

Change of Braking Method

Follow the procedure below to change the braking method from linked to independent.


1. Swing up the pedal link bar, and then pull it out from the right brake pedal.



Change of Braking Method_001

1	Pedal link bar
Α	Swing up
В	Pull out

2. Secure the pedal link bar in the holder on the left brake pedal.



Change of Braking Method_002

	1	Holder
	Α	Secure

Page 4-8 Brake Pedal

Parking Brake Lever



Never park the machine on a slope.

Important


Be sure to release the parking brake before driving.

It may result in the brakes or hydraulic system malfunction.

The parking brake lever is located to the left of the front cover.

When parking, link the left and right brake pedals by using the pedal link bar, depress both brake pedals, and then pull the parking brake lever completely.

To release the parking brake, depress the brake pedals.



Parking Brake Lever_001

1	Brake pedals	
2	Parking brake lever	

Safety Mechanisms

This machine features a safety device for starting/stopping the engine.

- 1. As for starting the engine, the safety device prevents the engine from starting unless it meets each of the following four conditions.
 - · An operator is sitting on the seat.
 - · The parking brake is applied.
 - The knife rotation switch is set to the "Stop" position.
 - The traveling pedal is set to the neutral position.

Important

When you restart the engine after the safety device stops the engine, be sure to return the ignition key to the "OFF" position first, and then restart it.

Otherwise the engine does not start.

- 2. In the event the operator leaves the seat with the parking brake applied and the engine running, the safety device will be activated and will stop the engine under any of the following conditions:
 - The traveling pedal is not set to the neutral position. (The operator has depressed the traveling pedal.)
 - The knife rotation switch is set to the "Rotation" position.

Warning Mechanisms

Warning Buzzer

Important

When the buzzer (intermittent tone) sounds, be sure to stop operation since the engine is overheated.

Do not stop the engine without idling. Allow the engine to cool down, first. Keep the engine idling for about 5 minutes before stopping. Remove dust that is jamming in the radiator, air cleaner, and etc.

This machine features warning mechanisms for overheating, the hydraulic oil and the engine.

- 1. Overheat Warning Buzzer
 If the engine water temperature exceeds 110
 °C (230 °F), a buzzer will sound. (intermittent tone)
 - When the buzzer sounds, stop the engine immediately, and then inspect the machine and perform any necessary maintenance.
- Hydraulic Oil Level Warning Buzzer
 If the oil level in the hydraulic tank declines
 from the specified level by approximately 2.0
 dm³ (2.0 L), a buzzer will sound. (continuous
 tone)

When the buzzer sounds, stop the engine immediately, and then inspect the machine and perform any necessary maintenance.


Parking Brake Lever Page 4-9

Engine Warning Lamp

Important

Make repairs immediately if the fault codes of PCD (Particulate Control Diagnostic) and NCD (NOx Control Diagnostic) appear.

Engine warning lamp (LED) lights up or blinks when a failure occurs on the function of engine. Check the fault code (DTC) in the monitor display.



Engine Warning Lamp_001

1 Engine warning lamp


The lighting patterns of engine warning lamp are as follows.

Note:

PCD means fault codes relevant to Particulate Control Diagnostic.

NCD means fault codes relevant to NOx Control Diagnostic.


1. Engine warning lamp lights up when only DTC other than PCD/NCD come up.



Engine Warning Lamp_002

1	Fault detected
2	Recovery
Α	Lighting


2. Engine warning lamp blinks when only DTC relevant to PCD/NCD come up.



Engine Warning Lamp_003

1	Fault detected
2	Recovery
Α	Blinking

 Engine warning lamp repeats blinking and lighting alternately when DTC relevant to/ other than PCD/NCD come up at the same time. (It repeats blinking three times and lighting three seconds.)



Engine Warning Lamp_004

1	Fault detected
2	Recovery
Α	Blinking
В	Lighting

Monitor LED

Monitor (LED) turns on when a failure occurs on the function of engine.

Check the fault code (DTC) in the monitor display when Monitor (LED) turns on.


1. LED (yellow)

Lights up when a malfunction is detected, indicating warning and/or caution on the engine.

Page 4-10 Warning Mechanisms

2. LED (red)

Lights up when a critical malfunction on the engine is detected.




Monitor LED 001

1	LED (yellow)
2	LED (red)
3	Monitor display

Monitor

The monitor displays various information about the machine, such as the operating status and fault conditions.

The information of desired items can be confirmed according to operating the keys.



Monitor_001

1	Monitor display	
2	LED (yellow)	
3	LED (red)	
4	Enter key	
5	Right arrow key	
6	Left arrow key	
7	Menu key	

1. Monitor display

Displays machine conditions and items.

2. LED (yellow)

Lights up when a malfunction is detected, indicating warning and/or caution on the engine.

3. LED (red)

Lights up when a critical malfunction on the engine is detected.

4. Enter key

Selects the menu or parameter. Switches between displaying/hiding the current fault code.

5. Right arrow key

Scrolls the screen.

Move the parameter selection to the right or down.

6. Left arrow key

Scrolls the screen.


Move the parameter selection to the left or up.

7. Menu key

Opens or exits the menu.

Displayed Icon

The icon appears at the top of the monitor display.



Displayed Icon_001

1	Regeneration icon
2 Auto regeneration inhibit icon	
3	High exhaust temperature icon
4	Warning mark

1. Regeneration icon

The regeneration icon appears with DPF regeneration request or during DPF regeneration.

- DPF regeneration request: Blinking
- · During DPF regeneration: Lighting

2. Auto regeneration inhibit icon

The auto regeneration inhibit icon lights up when the DPF auto regeneration inhibit switch is set to the "Auto regeneration inhibit mode".

3. High exhaust temperature icon
The high exhaust temperature icon lights up
when the exhaust temperature reaches 450
°C during DPF regeneration.

4. Warning mark


The warning mark continues to be displayed in the upper right corner of the monitor display if the warning message ignored and the Enter key pressed to hide the message.

- · Service reminders
- · Low fuel level
- · Fault codes

Main Menu Items

While any parameter is displayed, press the menu key to display the main menu with the following 11 items.

- · GO TO 1-UP DISPLAY / GO TO 4-UP DISPLAY
- · LANGUAGES
- · STORED CODES
- · ENGINE CONFIGURATION
- · SETUP 1-UP DISPLAY
- · SETUP 4-UP DISPLAY
- · SERVICE REMINDERS
- · SELECT UNITS
- · ADJUST BACKLIGHT
- · ADJUST CONTRAST
- · UTILITIES



Main Menu Items_001


Menu key

1-Up Display / 4-Up Display

"GO TO 1-UP DISPLAY" / "GO TO 4-UP DISPLAY" are used to set whether to display parameters individually in a screen or in groups of four per screen.

1. 1-up display

One parameter is displayed individually in the monitor display.




1-Up Display / 4-Up Display_001

2. 4-up display

Four parameters are displayed in the monitor display.

With the 4-up display, a total of 8 parameters are displayed over 2 pages.



1-Up Display / 4-Up Display_002

Note:

The factory default display is the 4-up display. "GO TO 1-UP DISPLAY" appears in the main menu.

When the 1-up display is set, "GO TO 4-UP DISPLAY" appears in the main menu.

Page 4-12 Monitor

■Parameter Items

The parameters and corresponding information that appear in the monitor display are listed below.

No.	Monitor display L	Monitor display S	Description
1	ENGINE SPEED	ENG RPM	Displays the engine rpm.
2	DRIVERS DEMAND ENGINE TORQUE	DEMAND TQ	Displays the torque required by the ECU.
3	ACTUAL ENGINE TORQUE	ENG TORQ	Displays the actual torque.
4	PERCENT LOAD AT CURRENT RPM	LOAD@RPM	Displays the engine load factor.
5	ACCELERATOR PEDAL POSITION 1	ACCEL PED1	Displays the accelerator sensor opening.
6	ENGINE DESIRED OP SPEED	DES ENG SP	Displays the engine rpm required by the ECU.
7	ENGINE COOLANT TEMPERATURE	COOL TEMP	Displays the temperature measured by the coolant temperature sensor.
8	FUEL RATE	FUEL RATE	Displays the engine fuel consumption rate.
9	THROTTLE POSITION	THROTTLE	Displays the engine throttle opening.
10	BOOST PRESSURE	BST PRES	Displays the pressure measured by the intake pressure sensor.
11	INTAKE MANIFOLD TEMPERATURE	MANI TEMP	Displays the temperature measured by the intake temperature sensor built into the air flow sensor.
12	BATTERY POTENTIAL	BAT VOLT	Displays the battery voltage.
13	BAROMETRIC PRESSURE	BARO PRES	Displays the atmospheric pressure measured by the atmospheric pressure sensor.
14	AMBIENT AIR TEMP	AMB TEMP	Displays the ambient temperature.
15	AIR INLET TEMPERATURE	AIR IN TP	Displays the intake air temperature measured by the air flow sensor.
16	TOTAL FUEL USED	FUEL USED	Displays the total fuel consumption of the engine.
17	TOTAL ENGINE HOURS	ENG HRS	Displays the total time that the ECU is on (time that the key is in the "ON" position).
18	ENGINE OIL PRESSURE	OIL PRES	Displays the engine oil pressure measured by the oil pressure switch. While the engine is running: Normal=200 kPa, Abnormal=0 kPa
19	INJECTOR METERRING RAIL PRESS	RAIL PRES	Displays the fuel pressure in the rail, measured by the rail pressure sensor.
20	ENGINE INLET AIR MASS FLOW RATE	AIR RATE	Displays the intake air volume measured by the air flow sensor.
21	DOC INTAKE GAS TEMP	DOC TEMP	Displays the DOC inlet gas temperature measured by the exhaust temperature sensor.
22	EXHAUST FILTER INLET TEMP	EF IN T	Displays the DPF inlet gas temperature measured by the exhaust temperature sensor.
23	DPF DIFFERENCE PRESSURE	DIFF PRES	Displays the pressure difference before and after the DPF, measured by the differential pressure sensor.

No.	Monitor display L	Monitor display S	Description
24	EXHAUST FILTER OUTLET TEMP	EF OUT T	Displays the DPF outlet gas temperature measured by the exhaust temperature sensor.
	PARTICUATE TRAP LAMP	PT LAMP	Shows the status of the regeneration icon.
25			Icon not displayed="OFF", Icon blinking="ON BLINK", Icon solid="ON SOLID"
			Shows the status of the DPF.
			DPF regeneration not needed="REGEN NOT NEEDED"
26	DPF STATUS	DPF ST	DPF regeneration needed=(Level 1="NEEDED LOWEST", Level 2-3="NEEDED MODERATE", Level 4="NEEDED HIGHEST")
			Shows the DPF regeneration status.
27	DPF ACTIVE REGEN STATUS	DPF AR ST	Regeneration not needed="INACTIVE", Regeneration needed="NEEDED", Regenerating="ACTIVE"
	DPF REGEN INHIBIT STATUS	INHIBIT ST	Shows the ECU auto regeneration inhibited status.
28			Auto regeneration inhibit switch off="OFF", Auto regeneration inhibit switch on="ON"
	DDE DECEMEDATION		Shows the status of auto regeneration inhibit switch.
29	DPF REGENERATION INHIBITED SW	DPF INHIB SW	Auto regeneration inhibit switch off="OFF", Auto regeneration inhibit switch on="ON"
30	EXHAUST HIGH TEMP	EXH T LAMP	Displays the condition of the exhaust temperature.
30	LAMP	EAR I LAWIP	450 °C or more="ON", 450 °C or less="OFF"
31	%SOOT	%SOOT	Displays the amount of soot accumulated in the DPF.
31	703UUT	/03UU I	100%= PM accumulation Level 1
32	MACHINE HOURS	MACH HRS	Displays the total operating time of the machine (time that the engine was actually running).
33	FUEL LEVEL	FUEL LEVEL	Displays the quantity of fuel remaining in the fuel tank.

Note:

When display settings are being specified, the parameters appear on "Monitor display L". At all other times, the parameters appear on "Monitor display S".


Page 4-14 Monitor

Language

With "LANGUAGES", the language used in the monitor display can be set to either of the following two.

- · ENGLISH
- JAPANESE

An asterisk appears at the right of the currently selected language.



Language_001

1 Asterisk

Note:

The factory default language is "ENGLISH".


Fault Code Log

With "STORED CODES", a log of past fault codes can be checked.

When there is a fault code log, each fault is displayed over two pages.

Use the arrow keys to change the page.

· Text 1



Fault Code Log_001

Arrow keys

· Text 2



Fault Code Log_002

If there is no fault code log, "NO STORED FAULT CODES" appears.

Engine Configuration

This function is not supported.

1-Up Display Setup


With "SETUP 1-UP DISPLAY", the displayed parameters can be reset to the factory defaults, or the monitor display of selected, necessary parameters can be set up.
The following 3 items appear when "SETUP 1-UP DISPLAY" is selected.

- · USE DEFAULTS
- · CUSTOM SETUP
- · AUTOMATIC SCAN

■Use Defaults

With "USE DEFAULTS", the 1-up display parameters return to the factory defaults.


 Press the menu key. After the main menu appears, use the arrow keys to highlight "SETUP 1-UP DISPLAY", and then press the Enter key.



Use Defaults_001

1	Menu key
2	Arrow keys
3	Enter key

2. Highlight "USE DEFAULTS", and then press the Enter key.




Use Defaults_002

- "RESTORED TO DEFAULTS" appears in the monitor display, and the parameters are reset to the factory defaults of the following 8 items.
 - [1] ENGINE SPEED
 - [2] ENGINE COOLANT TEMPERATURE
 - [3] %SOOT
 - [4] FUEL LEVEL
 - [5] ENGINE OIL PRESSURE
 - [6] MACHINE HOURS
 - [7] BATTERY POTENTIAL
 - [8] DPF STATUS
- 4. After the settings have been applied, pressing the menu key once returns to the main menu, and pressing the key again returns to the 1-up/4-up display screen.

■Custom Setup

With "CUSTOM SETUP", the type and number of parameters as well as their display order can be specified.

 Press the menu key. After the main menu appears, use the arrow keys to highlight "SETUP 1-UP DISPLAY", and then press the Enter key.




Custom Setup_001

	1	Menu key
2 Arrow k		Arrow keys
	3	Enter key

2. Highlight "CUSTOM SETUP", and then press the Enter key.


The list of parameters appears.



Custom Setup_002


Page 4-16 Monitor

- 3. Change the parameters.
 - [1] To add a parameter
 - a. Use the arrow keys to highlight the parameter to be added, and then press the Enter key.




Custom Setup_003

 A number appears at the right of the selected parameter. This number indicates the display order for the parameter




Custom Setup_004

- [2] To deselect a parameter and remove it from the list of displayed parameters
 - a. Highlight the parameter, and then press the Enter key.



Custom Setup_005

b. Check that the number at the right of the parameter disappeared.




Custom Setup_006

- 4. After the settings have been applied, pressing the menu key once returns to the main menu, and pressing the key again returns to the 1-up/4-up display screen.
- ■Automatic Scan

With "AUTOMATIC SCAN", the 1-up display can be set to automatically scroll through the selected parameters one by one.

Press the menu key.
 After the main menu appears, use the arrow keys to highlight "SETUP 1-UP DISPLAY", and then press the Enter key.




Automatic Scan 001

1	Menu key
2	Arrow keys
3	Enter key

2. When "AUTOMATIC SCAN ON" appears, the parameters are scrolled automatically. For manual scrolling, highlight "AUTOMATIC SCAN ON", and then press the Enter key.

It turns into "AUTOMATIC SCAN OFF" and the parameters will be scrolled manually.



Automatic Scan_002

 After the settings have been applied, pressing the menu key once returns to the main menu, and pressing the key again returns to the 1-up/4-up display screen.

Note:

When the parameters are scrolled automatically, press the Enter key once to pause scrolling.

When scrolling is paused, press the Enter key once to restart scrolling.

4-Up Display Setup


With "SETUP 4-UP DISPLAY", the displayed parameters can be reset to the factory defaults, or the monitor display of selected, necessary parameters can be set up. The following 2 items appear when "SETUP 4-UP DISPLAY" is selected.

- · USE DEFAULTS
- · CUSTOM SETUP

■Use Defaults

With "USE DEFAULTS", the 4-up display parameters return to the factory defaults.


Press the menu key.
 After the main menu appears, use the arrow keys to highlight "SETUP 4-UP DISPLAY", and then press the Enter key.



Use Defaults_001

1	Menu key
2	Arrow keys
3	Enter key

2. Highlight "USE DEFAULTS", and then press the Enter key.




Use Defaults_002

Page 4-18 Monitor

- "RESTORED TO DEFAULTS" appears in the monitor display, and the parameters are reset to the factory defaults of the following 8 items.
 - · First page
 - [1] ENGINE SPEED
 - [2] ENGINE COOLANT TEMPERATURE
 - [3] %SOOT
 - [4] FUEL LEVEL
 - · Second page
 - [1] ENGINE OIL PRESSURE
 - [2] MACHINE HOURS
 - [3] BATTERY POTENTIAL
 - [4] DPF STATUS
- 4. After the settings have been applied, pressing the menu key once returns to the main menu, and pressing the key again returns to the 1-up/4-up display screen.
- ■Custom Setup

With "CUSTOM SETUP", the type and number of parameters as well as their display order can be specified.


 Press the menu key. After the main menu appears, use the arrow keys to highlight "SETUP 4-UP DISPLAY", and then press the Enter key.



Custom Setup 001


1	Menu key
2	Arrow keys
3	Enter key

2. Highlight "CUSTOM SETUP", and then press the Enter key.



Custom Setup_002


- 3. Select the page.
 - [1] Check that the values for the four parameters are highlighted.



Custom Setup_003

1 Parameter values


- [2] Use the arrow keys to display the page to be changed, and then press the Enter key.
- 4. Change the parameters.
 - [1] Check that the value for one parameter is highlighted.




Custom Setup_004

[2] Use the arrow keys to highlight the value of the parameter to be changed, and then press the Enter key.

- [3] The parameters appear.
 - The number at the right of the parameter indicates the location in the
 - 4-up display.
 - 1=Upper left
 - 2=Lower left
 - 3=Upper right
 - 4=Lower right




Custom Setup_005




Custom Setup_006

- [4] To change to a different parameter
 - a. Use the arrow keys to highlight the parameter to be selected, and then press the Enter key.




Custom Setup_007

b. Check that a number appeared to the right of the selected parameter.




Custom Setup_008

c. Press the menu key and check that the parameter has changed.



Custom Setup_009


- [5] To deselect a parameter and remove it from the list of displayed parameters
 - a. Highlight the parameter to be removed, and then press the Enter key.



Custom Setup_010


Page 4-20 Monitor

b. Check that the number at the right of the parameter disappeared.



Custom Setup_011

c. Press the menu key and check that the parameter has changed to "EMPTY".



Custom Setup_012

- 5. Pressing the menu key once returns to the display for selecting the page.
- 6. To change other parameters, repeat steps 3 to 5.

Service Reminders

With "SERVICE REMINDERS", the notification of replacement time for the following 5 consumables can be specified.

- · Engine oil
- · Engine oil filter
- · Hydraulic oil
- · Hydraulic oil filter
- · Air cleaner


The following 2 items appear when "SERVICE REMINDERS" is selected.

- · RESET REMINDERS
- · MODIFY REMINDERS

■Reset Reminders

With "RESET REMINDER", displayed remaining time can be reset to the time specified with "MODIFY REMINDERS".


Press the menu key.
 After the main menu appears, use the arrow keys to highlight "SERVICE REMINDERS", and then press the Enter key.



Reset Reminders_001


1	Menu key
2	Arrow keys
3	Enter key

2. Highlight "RESET REMINDER", and then press the Enter key.



Reset Reminders 002

Use the arrow keys to highlight the item to be changed, and then press the Enter key. A plus appears at the right of the currently selected items.



Reset Reminders_003


4. The remaining time for the selected item appears.



Reset Reminders_004

- [1] To reset the remaining time to the specified time, press the Enter key.
- [2] "RESET SERVICE REMINDER?" appears.

To reset, press the Enter key.
To cancel resetting, press the menu key.



Reset Reminders 005

5. The screen for selecting the item appears.

■Modify Reminders


With "MODIFY REMINDERS", the replacement time period for consumables can be specified.

The replacement time period is not configured at the factory.

Configure as necessary.

The replacement time period should be in accordance with the maintenance schedule.


Press the menu key.
 After the main menu appears, use the arrow keys to highlight "SERVICE REMINDERS", and then press the Enter key.



Modify Reminders_001

1	Menu key
2	Arrow keys
3	Enter key


2. Highlight "MODIFY REMINDERS", and then press the Enter key.



Modify Reminders_002


Page 4-22 Monitor

3. Use the arrow keys to highlight the item to be changed, and then press the Enter key.




Modify Reminders_003

4. The replacement time period for the selected item appears.



Modify Reminders_004

 Highlight the digit to be changed.
 Press the right arrow key to increase the number. Press the left arrow key to change the digit.




Modify Reminders_005

1	Right arrow key
2	Left arrow key

6. To save the specified time period, press the Enter key.


"MODIFY SERVICE REMINDER?" appears.

To save the changes, press the Enter key. To cancel the changes, press the menu key.



Modify Reminders_006

 The display for selecting the item appears.
 A plus sign appears on the right side of the item with the replacement time period configured.



Modify Reminders_007


1 Plus sign

■Reminder Display

Important

If a warning message appears, immediately stop operation, and then perform the replacement procedure.


 When the specified replacement time period for a consumable has passed, a warning message appears in the monitor display and the LED (yellow) lights up.



Reminder Display_001

1	LED (yellow)
2	Enter key

- 2. Pressing the Enter key changes the screen from the warning message to the parameter display.
- 3. A warning mark appears in the upper-right corner of the monitor display.



Reminder Display_002

1 Warning mark


 Change the replacement time period of consumables with "RESET REMINDERS" or "MODIFY REMINDERS".
 When the replacement time period is changed, the warning message and mark disappear.

Select Units

With "SELECT UNITS", the units of parameter values can be set to any of the following three formats.

- · ENGLISH
- · METRIC KPA
- · METRIC BAR

An asterisk appears at the right of the currently selected unit.



Select Units 001

1 Asterisk

Page 4-24 Monitor


		Units	
Monitor display S	ENGLIS H	METRI C KPA	METRI C BAR
ENG RPM	RPM	RPM	RPM
DEMAND TQ	%	%	%
ENG TORQ	%	%	%
LOAD@RPM	%	%	%
ACCEL PED1	%	%	%
DES ENG SP	RPM	RPM	RPM
COOL TEMP	F	С	С
FUEL RATE	G/HR	L/HR	L/HR
THROTTLE	%	%	%
BST PRES	PSI	kPa	BAR
MANI TEMP	F	С	С
BAT VOLT	VDC	VDC	VDC
BARO PRES	PSI	kPa	BAR
AMB TEMP	F	С	С
AIR IN TP	F	С	С
FUEL USED	Gal	L	L
ENG HRS	Н	Н	Н
OIL PRES	PSI	kPa	BAR
RAIL PRES	PSI	kPa	BAR
AIR RATE	Gal	L	L
DOC TEMP	F	С	С
EF IN T	F	С	С
DIFF PRES	PSI	kPa	BAR
EF OUT T	F	С	С
%SOOT	%	%	%
MACH HRS	Н	Н	Н
FUEL LEVEL	%	%	%

Note:

The factory default unit is "METRIC KPA".

Adjust Backlight

With "ADJUST BACKLIGHT", the brightness of the monitor display can be adjusted. Press the right arrow key to make the display brighter. Press the left arrow key to make the display darker.




Adjust Backlight_001

1	Right arrow key
2	Left arrow key

Adjust Contrast

With "ADJUST CONTRAST", the contrast of the monitor display can be adjusted. Press the right arrow key to decrease the contrast. Press the left arrow key to increase the contrast.



Adjust Contrast_001

1	Right arrow key
2	Left arrow key

Utilities

With "UTILITIES", the remaining fuel volume can be specified and the monitor configuration can be displayed.

The following 6 items appear when "UTILITIES" is selected.

- · GAGE DATA
- · REMOVE ALL GAGES
- · SOFTWARE VERSION
- · FAULT CONVERSION
- ANALOG INPUT
- · OEM

Note:

"GAGE DATA" and "REMOVE ALL GAGES" are not supported on this machine.

■Software Version

With "SOFTWARE VERSION", the software version of the monitor can be displayed.

■Fault Conversion

With "FAULT CONVERSION", the J1939 fault code conversion method can be specified.

The monitor normally detects J1939 version 4

Since the engine ECU of this machine uses J1939 version 4, no adjustments are necessary.

Analog Input

With "ANALOG INPUT", remaining fuel volume information can be specified. The following 2 items appear when "ANALOG INPUT" is selected.


- · BACKLIGHT DIMMER
- · FUEL LEVEL

Important

"BACKLIGHT DIMMER" is not supported on this machine.

Always select "FUEL LEVEL".

If "BACKLIGHT DIMMER" is selected, "NO DATA" appears as the value for the fuel level parameter.



Analog Input_001


Note:

The factory default analog input is "FUEL LEVEL".

1. Fuel Level

With "FUEL LEVEL", the low fuel level can be specified.

Press the menu key.
 After the main menu appears, use the arrow keys to highlight "UTILITIES", and then press the Enter key.




Fuel Level_001

	_
1	Menu key
2	Arrow keys
3	Enter key


Page 4-26 Monitor

2. Highlight "ANALOG INPUT", and then press the Enter key.




Fuel Level_002

3. Highlight "FUEL LEVEL", and then press the Enter key.




Fuel Level_003

4. Highlight "SET LOW FUEL LEVEL", and then press the Enter key.



Fuel Level_004

5. "LOW FUEL" appears.



Fuel Level_005

- 6. Press the right arrow key to increase the value. Press the left arrow key to decrease the value.
 - The value can be set between 10% and 80% in 5% increments.
- 7. To save the specified value, press the Enter key.

Note:

The factory default low fuel level is 10%.

2. Low Fuel Level Display


Important

If a warning message appears, immediately stop operation, and then supply fuel.

 When the fuel level falls below the specified low fuel level, a warning message appears in the monitor display and the LED (yellow) lights up. The warning message appears on two pages.

Use the arrow keys to change the page.

· Text 1



Low Fuel Level Display_001

1	LED (yellow)
2	Enter key
3	Arrow keys


· Text 2



Low Fuel Level Display_002

2. Pressing the Enter key changes the screen from the warning message to the parameter display.

3. A warning mark appears in the upperright corner of the monitor display.



Low Fuel Level Display_003

1 Warning mark

4. When fuel is supplied to bring the fuel level above the specified low fuel level, the warning message and mark disappear.

■OEM

"OEM" is used when the manufacturer specifies factory default settings.

Important

No adjustments by the operator are necessary.

Page 4-28 Monitor

Fault Code Displays


Important

When the fault code (DTC) appears in the monitor display, contact your dealer.

A fault code (DTC) appears in the monitor display when a failure occurs on the function of engine.

Each fault code is displayed over two pages. Use the arrow keys to change the page.

Text 1
 The fault code name appears.



1 Arrow keys

Text 2
 The corrective action appears.



Fault Code Displays_002

Pressing the Enter key changes the screen from the fault code to the parameter display.

Important


If the service reminders are configured, the notices of the replacement time period for consumables and the fault code may appear all together.

If the low fuel level is specified, the notices of fuel level low and the fault code may appear all together.

If "ACTIVE FAULTS - ECU" message appears, check both the service reminder warning message and the fault code (DTC).

To check the service reminder warning message:


Highlight the service reminder notice, and then press the Enter key.



Fault Code Displays_003

1	Service reminder notice
2	Fault code notice

Text 1
 The item of requiring replacement of consumables appears.



Fault Code Displays_004


Text 2
 The corrective action appears.



Fault Code Displays_005

To check the fault code (DTC):


Highlight the fault code notice, and then press the Enter key.



Fault Code Displays_006

1	Service reminder notice
2	Fault code notice

Text 1
 The fault code (DTC) name appears.



Fault Code Displays 007

Text 2
 The corrective action appears.



Fault Code Displays_008


Note:

If the warning message of service reminder ignored and the Enter key pressed to hide the message, the monitor will display "ACTIVE FAULTS - ECU".

If the fault code (DTC) ignored and the Enter key pressed, the monitor will also display "ACTIVE FAULTS - ECU".

If the notice ignored and the menu key pressed when the monitor displays "ACTIVE FAULTS - ECU", the warning mark continues to be displayed in the upper right corner of the monitor display.

To check the warning message and the fault code (DTC) again, press the Enter key to return to the display of "ACTIVE FAULTS - ECU".



Fault Code Displays_009

1 Warning mark

Page 4-30 Monitor

Engine

Handling Tier 4 Emission Control Compliant Engine

The engine installed in this vehicle meets Tier 4 emission control for "non-road emission regulation."

When performing maintenance or repairs on this engine, only use dedicated replacement parts specified in the relevant Kubota "Illustrated Parts List," and only perform the maintenance work described in the Kubota "Operator's Manual," " Workshop Manual" or "Diagnosis Manual."

Using incorrect replacement parts or parts that comply with different levels of emission control may result in incompliance with Tier 4 emission control.

DPF

About DPF

The DPF is a purifying filter that collects PM (soot) from exhaust gas.

When a certain amount of PM (soot) has accumulated, DPF regeneration must be performed automatically or manually in order to restore the filtering function.

DPF Regeneration

▲ Danger

Since it will become extremely hot around the exhaust outlet during DPF regeneration, do not perform the regeneration in a location where fires may occur.

Important

When the system enters the level where DPF regeneration is required, perform the regeneration immediately.

Interrupting the regeneration or ignoring the warning and continuing traveling or cutting work may cause the engine and DPF to malfunction.

Important

Do not repeat unnecessary regeneration or interrupting regeneration.

If repeating them, the measured level of engine oil may increase since the engine oil is mixed with a slight amount of fuel, accompanied by quality degradation.

Important

Perform DPF regeneration when the engine sufficiently warmed up.

DPF regeneration is burning PM (soot) collected in DPF with the exhaust temperature heated up to high temperature by the engine ECU control of intake air mass and fuel injection.

■Automatic Regeneration

⚠ Danger

Since it will become extremely hot around the exhaust outlet during DPF regeneration, do not perform the regeneration in a location where fires may occur.

▲ Caution

Normally, set the DPF auto regeneration inhibit switch to the "Auto regeneration mode". However, when operating in a location where fires may occur, set the DPF auto regeneration inhibit switch to the "Auto regeneration inhibit mode".

Important

When the system enters the level where DPF regeneration is required, perform the regeneration immediately. Interrupting the regeneration can cause the engine and DPF to malfunction.

Automatic regeneration is the automatic control of increasing the exhaust temperature for DPF regeneration.

 You can continue to use this machine for traveling and cutting work during DPF regeneration.

Engine Page 4-31

- You can operate this machine to perform the regeneration. (The fault diagnostic tool is not required.)
- Automatic regeneration is activated only when the auto regeneration inhibit switch set to the "Auto regeneration mode".
- Automatic regeneration is activated when PM accumulation level is "Level 1" or "Level 2".


However, it may be activated in "Level 0" depending on the other condition.

Important

If the regeneration remains uncompleted even after 30 minutes have passed since the start of automatic regeneration in PM accumulation "Level 1", PM accumulation level enters "Level 2".

These are the procedures of automatic regeneration.

- ■When the DPF auto regeneration inhibit switch set to the "Auto regeneration mode":
- 1. When the conditions for automatic regeneration are met, the automatic regeneration starts with the regeneration icon lighting.
- 2. When the regeneration completed, the regeneration icon disappears.




Automatic Regeneration_001

Regeneration icon

- ■When the DPF auto regeneration inhibit switch set to the "Auto regeneration inhibit mode":
- When PM accumulation level enters "Level 1" or "Level 2", the blinking regeneration icon appears.
- 2. Set the DPF auto regeneration inhibit switch to the "Auto regeneration mode".

- 3. When the conditions for automatic regeneration are met, the automatic regeneration starts and the regeneration icon changes from blinking to lighting.
- 4. When the regeneration completed, the regeneration icon disappears.



Automatic Regeneration_002

1 Regeneration icon

Page 4-32 Engine

■Parked Regeneration

▲ Danger

Since it will become extremely hot around the exhaust outlet during DPF regeneration, do not perform the regeneration in a location where fires may occur.

Important

When the system enters the level where DPF regeneration is required, perform the regeneration immediately.

Interrupting the regeneration or ignoring the warning and continuing traveling or cutting work may cause the engine and DPF to malfunction.

Important

Parked regeneration can not be performed as long as the DPF auto regeneration inhibit switch set to the "Auto regeneration inhibit mode".

Set it to the "Auto regeneration mode" to perform regeneration.

Parked regeneration is the DPF regeneration forcibly performed, parking this machine in a safe location, when auto regeneration does not reduce the amount of accumulated PM to the specified value.

- You can not continue to use this machine for traveling and cutting work during DPF regeneration.
- You can operate this machine to perform the regeneration. (The fault diagnostic tool is not required.)
- These are the conditions for activating parked regeneration.
- 1. The parking brake is applied.
- 2. The traveling pedal is in neutral.
- 3. The throttle opening is 0% (idling).
- Parked regeneration is activated when PM accumulation level is "Level 1", "Level 2" or "Level 3".

Important


If the regeneration remains uncompleted in automatic regeneration, parked regeneration is required with the blinking regeneration icon. ■In PM accumulation "Level 1" or "Level 2":

Important

If ignoring the parked regeneration requirement and continuing traveling or cutting work in PM accumulation "Level 1" or "Level 2", PM accumulation level enters "Level 2" or "Level 3".

Follow the steps below for parked regeneration.


When PM accumulation level enters
 "Level 1" or "Level 2", the blinking
 regeneration icon appears.
 When the DPF auto regeneration inhibit
 switch set to the "Auto regeneration
 mode":



Parked Regeneration_001

Regeneration icon

When the DPF auto regeneration inhibit switch set to the "Auto regeneration inhibit mode":



Parked Regeneration_002

Regeneration icon

- 2. Stop traveling and cutting work.
- 3. Park this machine in a safe location.
- 4. Apply the parking brake.
- 5. Set the throttle opening to 0% (idling).

Engine Page 4-33

- If the DPF auto regeneration inhibit switch set to the "Auto regeneration inhibit mode," set it to the "Auto regeneration mode."
- 7. Press the DPF parked regeneration switch.
 - Parked regeneration starts and the regeneration icon changes from blinking to lighting.
- 8. When the regeneration completed, the regeneration icon disappears.
- ■In PM accumulation "Level 3":

Important


If ignoring the parked regeneration requirement and continuing traveling or cutting work in PM accumulation "Level 3", PM accumulation level enters "Level 4". If still continuing traveling or cutting work, you will not be able to operate this machine for regeneration.

Important

Automatic regeneration can not be activated in PM accumulation "Level 3".

Perform parked regeneration immediately.

- 1. These are the statuses in PM accumulation "Level 3".
 - "Excessive PM3" appears in the monitor display.
 - Pressing an arrow key changes the display to "CORRECTIVE ACTION: Start DPF Parked Regeneration immediately".
 - The LED (yellow) lights up.
 - The engine output is limited at 50%.



Parked Regeneration_003

1	LED (yellow)
2	Arrow key

- 2. Stop traveling and cutting work.
- 3. Park this machine in a safe location.
- 4. Apply the parking brake.
- 5. Set the throttle opening to 0% (idling).
- 6. Press the DPF parked regeneration switch.
 - Parked regeneration starts and the regeneration icon changes from blinking to lighting.
- 7. When the regeneration completed, the regeneration icon disappears.

Page 4-34 Engine

■Manual Regeneration

▲ Danger

Since it will become extremely hot around the exhaust outlet during DPF regeneration, do not perform the regeneration in a location where fires may occur.

Important

When the system enters the level where DPF regeneration is required, perform the regeneration immediately.

Interrupting the regeneration or ignoring the warning and continuing traveling or cutting work may cause the engine and DPF to malfunction.

Important

Manual regeneration can not be performed as long as the DPF auto regeneration inhibit switch set to the "Auto regeneration inhibit mode".

Set it to the "Auto regeneration mode" to perform regeneration.

Manual regeneration is the DPF regeneration performed only by the expert with the fault diagnostic tool. Normal automatic regeneration or parked regeneration can not complete regeneration since large amount of PM accumulates. Manual regeneration can be activated in any PM accumulation level.

- You can not continue to use this machine for traveling and cutting work during DPF regeneration.
- You can not perform the regeneration.
 (The fault diagnostic tool is required.)
- Manual regeneration is activated in PM accumulation "Level 4".
- Manual regeneration is activated in any PM accumulation level when the following condition met.
 - 1. when replacing DPF
 - 2. when replacing ECU

■In PM accumulation "Level 4":


Important

If ignoring the manual regeneration requirement and continuing traveling or cutting work in PM accumulation "Level 4", PM accumulation level enters "Level 5". If still continuing traveling or cutting work, fatal trouble will occur on the engine and DPF.

- 1. These are the statuses in PM accumulation "Level 4".
 - "Excessive PM4" appears in the monitor display.
 Pressing an arrow key changes the display to "CORRECTIVE ACTION:

display to "CORRECTIVE ACTION Stop engine!! Contact dealer immediately".

- · The LED (yellow) lights up.
- The engine output is limited at 50%.



Manual Regeneration_001

1	LED (yellow)
2	Arrow key

- 2. Stop traveling and cutting work.
- 3. Park this machine in a safe location.
- 4. Apply the parking brake.
- 5. Stop the engine.


Engine Page 4-35

Contact your dealer for manual regeneration.

Replacement of DPF

When PM accumulates excessively in the DPF or ash accumulates, replace the DPF since the regeneration in that case is prohibited.


- You can not continue to use this machine for traveling and cutting work.
- · The regeneration is impossible.
- · Replace every 3,000 hours.
- Replace DPF in PM accumulation "Level 5" or "High frequency of regeneration".
- ■In PM accumulation "Level 5":
- 1. These are the statuses in PM accumulation "Level 5".
 - "Excessive PM5" appears in the monitor display.
 - Pressing an arrow key changes the display to "CORRECTIVE ACTION: Stop engine!! Contact dealer immediately".
 - · The LED (red) lights up.
 - The engine output is limited at 50%.



Replacement of DPF_001

1	LED (red)
2	Arrow key

- 2. Stop traveling and cutting work.
- 3. Park this machine in a safe location.
- 4. Apply the parking brake.
- 5. Stop the engine.
- 6. Contact your dealer for DPF replacement.
- ■In the case of "High frequency of regeneration" :
- 1. These are the statuses in the case of "High frequency of regeneration".
 - "High frequency of regeneration" appears in the monitor display.
 - Pressing an arrow key changes the display to description of corrective action.
 - · The LED (yellow) lights up.
 - The engine output is limited at 50%.



Replacement of DPF 002

	-
1	LED (yellow)
2	Arrow key

- 2. Stop traveling and cutting work.
- 3. Park this machine in a safe location.
- 4. Apply the parking brake.
- 5. Stop the engine.
- 6. Contact your dealer for DPF replacement.

Page 4-36 Engine

Conditions for DPF Regeneration

▲ Danger

Since it will become extremely hot around the exhaust outlet during DPF regeneration, do not perform the regeneration in a location where fires may occur.

Important

If DPF regeneration is interrupted before it is completed, the next regeneration may be requested soon since not all of the PM (soot) was removed.

Important

Perform DPF regeneration when the engine sufficiently warmed up.

- DPF auto regeneration does not begin unless both of the following two conditions are met.
 - The DPF auto regeneration inhibit switch is set to the "Auto regeneration mode". (Auto regeneration inhibit icon is turned off.)
 - The coolant temperature is 50 °C or more.
- 2. DPF parked regeneration and manual regeneration do not begin unless all of the following five conditions are met.
 - The DPF auto regeneration inhibit switch is set to the "Auto regeneration mode". (Auto regeneration inhibit icon is turned off.)
 - The parking brake is applied.
 - The traveling pedal is in the neutral position.
 - The throttle opening is 0% (idling).
 - The coolant temperature is 50 °C or more.
- During DPF regeneration, the operation is canceled if any of the following conditions occur.
 - Any condition for starting regeneration is violated.
 - The ignition key is switched to the "OFF" position.

PM Accumulation Level

■Level 0

DPF regeneration is not necessary.

■Level 1

⚠ Danger

Since it will become extremely hot around the exhaust outlet during DPF regeneration, do not perform the regeneration in a location where fires may occur.

▲ Caution

Normally, set the DPF auto regeneration inhibit switch to the "Auto regeneration mode". However, when operating in a location where fires may occur, set the DPF auto regeneration inhibit switch to the "Auto regeneration inhibit mode".

Important

When the system enters the level where DPF regeneration is required, perform the regeneration immediately.

Interrupting the regeneration or ignoring the warning and continuing traveling or cutting work may cause the engine and DPF to malfunction.

Important


If the regeneration remains uncompleted even after 30 minutes have passed since the start of automatic regeneration in PM accumulation "Level 1", PM accumulation level enters "Level 2".

- You can continue to use this machine for traveling and cutting work during DPF auto regeneration.
- You cannot continue to use this machine for traveling and cutting work during DPF parked regeneration.
- You can operate this machine to perform the regeneration. (The fault diagnostic tool is not required.)

Engine Page 4-37

<Automatic regeneration>


- ■When the DPF auto regeneration inhibit switch set to the "Auto regeneration mode":
- When the conditions for automatic regeneration are met, the automatic regeneration starts with the regeneration icon lighting.
- 2. When the regeneration completed, the regeneration icon disappears.



Level 1_001

1 Regeneration icon

- ■When the DPF auto regeneration inhibit switch set to the "Auto regeneration inhibit mode":
- 1. The blinking regeneration icon appears.
- 2. Set the DPF auto regeneration inhibit switch to the "Auto regeneration mode".
- 3. When the conditions for automatic regeneration are met, the automatic regeneration starts and the regeneration icon changes from blinking to lighting.
- 4. When the regeneration completed, the regeneration icon disappears.




Level 1_002

1 Regeneration icon

<Parked regeneration>


- These are the conditions for activating parked regeneration.
 - 1. The parking brake is applied.
 - 2. The traveling pedal is in neutral.
 - 3. The throttle opening is 0% (idling).
 - 4. The DPF auto regeneration inhibit switch is set to the "Auto regeneration mode". (Auto regeneration inhibit icon disappears.)
- The blinking regeneration icon appears. When the DPF auto regeneration inhibit switch set to the "Auto regeneration mode":



Level 1_003

Regeneration icon

When the DPF auto regeneration inhibit switch set to the "Auto regeneration inhibit mode":



Level 1_004

1 Regeneration icon

- 2. Stop traveling and cutting work.
- 3. Park this machine in a safe location.
- 4. Apply the parking brake.
- 5. Set the throttle opening to 0% (idling).

Page 4-38 Engine

- 6. Press the DPF parked regeneration switch.
 - Parked regeneration starts and the regeneration icon changes from blinking to lighting.
- 7. When the regeneration completed, the regeneration icon disappears.

■Level 2

♠ Danger

Since it will become extremely hot around the exhaust outlet during DPF regeneration, do not perform the regeneration in a location where fires may occur.

▲ Caution

Normally, set the DPF auto regeneration inhibit switch to the "Auto regeneration mode". However, when operating in a location where fires may occur, set the DPF auto regeneration inhibit switch to the "Auto regeneration inhibit mode".

Important

When the system enters the level where DPF regeneration is required, perform the regeneration immediately.

Interrupting the regeneration or ignoring the warning and continuing traveling or cutting work may cause the engine and DPF to malfunction.


Important

If ignoring the parked regeneration requirement and continuing traveling or cutting work in PM accumulation "Level 2", PM accumulation level enters "Level 3".

- You can continue to use this machine for traveling and cutting work during DPF auto regeneration.
- You can not continue to use this machine for traveling and cutting work during DPF parked regeneration.
- You can operate this machine to perform the regeneration. (The fault diagnostic tool is not required.)

<Automatic regeneration>


- ■When the DPF auto regeneration inhibit switch set to the "Auto regeneration mode":
- When the conditions for automatic regeneration are met, the automatic regeneration starts with the regeneration icon lighting.
- 2. When the regeneration completed, the regeneration icon disappears.



Level 2_001

Regeneration icon

- ■When the DPF auto regeneration inhibit switch set to the "Auto regeneration inhibit mode":
- 1. The blinking regeneration icon appears.
- 2. Set the DPF auto regeneration inhibit switch to the "Auto regeneration mode".
- When the conditions for automatic regeneration are met, the automatic regeneration starts and the regeneration icon changes from blinking to lighting.
- 4. When the regeneration completed, the regeneration icon disappears.




Level 2_002

Regeneration icon

Engine Page 4-39

<Parked regeneration>


- These are the conditions for activating parked regeneration.
 - 1. The parking brake is applied.
 - 2. The traveling pedal is in neutral.
 - 3. The throttle opening is 0% (idling).
 - 4. The DPF auto regeneration inhibit switch is set to the "Auto regeneration mode". (Auto regeneration inhibit icon disappears.)
- The blinking regeneration icon appears.
 When the DPF auto regeneration inhibit switch set to the "Auto regeneration mode":



Level 2_003

Regeneration icon

When the DPF auto regeneration inhibit switch set to the "Auto regeneration inhibit mode":



Level 2_004

1 Regeneration icon

- 2. Stop traveling and cutting work.
- 3. Park this machine in a safe location.
- 4. Apply the parking brake.
- 5. Set the throttle opening to 0% (idling).

- 6. Press the DPF parked regeneration switch.
 - Parked regeneration starts and the regeneration icon changes from blinking to lighting.
- 7. When the regeneration completed, the regeneration icon disappears.

■Level 3

♠ Danger

Since it will become extremely hot around the exhaust outlet during DPF regeneration, do not perform the regeneration in a location where fires may occur.

Important

When the system enters the level where DPF regeneration is required, perform the regeneration immediately.

Interrupting the regeneration or ignoring the warning and continuing traveling or cutting work may cause the engine and DPF to malfunction.

Important

If ignoring the parked regeneration requirement and continuing traveling or cutting work in PM accumulation "Level 3", PM accumulation level enters "Level 4". If still continuing traveling or cutting work, you will not be able to operate this machine for regeneration.

Important


Automatic regeneration can not be activated in PM accumulation "Level 3".

Perform parked regeneration immediately.

- You can not continue to use this machine for traveling and cutting work during DPF regeneration.
- You can operate this machine to perform the regeneration. (The fault diagnostic tool is not required.)

Page 4-40 Engine

1. These are the statuses in PM accumulation "Level 3".



Level 3_001

1	LED (yellow)
2	Arrow key

 "Excessive PM3" appears in the monitor display.

Pressing an arrow key changes the display to "CORRECTIVE ACTION: Start DPF Parked Regeneration immediately".

- The LED (yellow) lights up.
- The engine output is limited at 50%.
- 2. Stop traveling and cutting work.
- 3. Park this machine in a safe location.
- 4. Apply the parking brake.
- 5. Set the throttle opening to 0% (idling).
- If the DPF auto regeneration inhibit switch set to the "Auto regeneration inhibit mode," set it to the "Auto regeneration mode."
- 7. Press the DPF parked regeneration switch.

Parked regeneration starts and the regeneration icon changes from blinking to lighting.

8. When the regeneration completed, the regeneration icon disappears.

■Level 4

♠ Danger

Since it will become extremely hot around the exhaust outlet during DPF regeneration, do not perform the regeneration in a location where fires may occur.

Important

When the system enters the level where DPF regeneration is required, perform the regeneration immediately.

Interrupting the regeneration or ignoring the warning and continuing traveling or cutting work may cause the engine and DPF to malfunction.

Important


If ignoring the manual regeneration requirement and continuing traveling or cutting work in PM accumulation "Level 4", PM accumulation level enters "Level 5".

If still continuing traveling or cutting work, fatal trouble will occur on the engine and DPF.

- You can not continue to use this machine for traveling and cutting work during DPF regeneration.
- You can not perform the regeneration.
 (The fault diagnostic tool is required.)

Engine Page 4-41

1. These are the statuses in PM accumulation "Level 4".



Level 4_001


1	LED (yellow)
2	Arrow key

- "Excessive PM4" appears in the monitor display.
 - Pressing an arrow key changes the display to "CORRECTIVE ACTION: Stop engine!! Contact dealer immediately".
- · The LED (yellow) lights up.
- The engine output is limited at 50%.
- 2. Stop traveling and cutting work.
- 3. Park this machine in a safe location.
- 4. Apply the parking brake.
- 5. Stop the engine.
- 6. Contact your dealer for manual regeneration.
- ■Level 5

When PM accumulates excessively in the DPF or ash accumulates, replace the DPF since the regeneration in that case is prohibited.

 You can not continue to use this machine for traveling and cutting work.

- · The regeneration is impossible.
- 1. These are the statuses in PM accumulation "Level 5".



- "Excessive PM5" appears in the monitor display.
 - Pressing an arrow key changes the display to "CORRECTIVE ACTION: Stop engine!! Contact dealer immediately".
- · The LED (red) lights up.
- The engine output is limited at 50%.
- 2. Stop traveling and cutting work.
- 3. Park this machine in a safe location.
- 4. Apply the parking brake.
- 5. Stop the engine.
- 6. Contact your dealer for DPF replacement.

Page 4-42 Engine

Operations Before Service	Page 5-2
Opening and Closing of Hood	Page 5-2
Opening and Closing of Underseat Cover	Page 5-3
Inspection and Cleaning	Page 5-3
Rotary Knife Radiator Cover Radiator Coolant Oil Cooler Hydraulic Oil Hydraulic Hoses Air Cleaner Battery Electrical Wiring Tire Brake Belt Wire Safety Device Around The Engine Engine Oil Fuel Water Separator Fuel Filter	Page 5-4Page 5-4Page 5-5Page 5-6Page 5-6Page 5-7Page 5-7Page 5-8Page 5-11Page 5-11Page 5-11Page 5-11Page 5-12Page 5-12Page 5-12Page 5-13Page 5-14Page 5-15
Liquid Leakage Bolts and Nuts	•
Mower Deck	_
Adjustment before Work	Page 5-17
Adjustment of Steering Wheel Position Adjustment of Seat Position Adjustment of Cutting Height	Page 5-17
Start/Stop of Engine	Page 5-20
Procedure to Start Engine Procedure to Stop Engine	_

Leaving the machine	Page 5-21
Move	.Page 5-22
Traveling Procedure	Page 5-22
Cutting WorkPage	
Cutting Operation	Page 5-22
Transporting	.Page 5-23
Transporting Procedure	. Page 5-23

Operations Before Service

The following sections describe the preparatory works required before performing the services including inspection, adjustment, cleaning. maintenance and repair.

Opening and Closing of Hood




Do not open the hood in strong winds.



Be careful not to pinch your fingers when you open or close the hood.


1. Remove the nuts and bolts locking the catch clips on the left and right sides of the hood.



Opening and Closing of Hood_001

1	Hood
2	Rubber catch
3	Catch clip
4	Nut
5	Bolt

2. Release the rubber catches on the left and right sides.




Opening and Closing of Hood_002

1	Rubber catch
2	Catch clip
3	Nut
4	Bolt

- 3. Lift up the hood.
- 4. Hook the hood stay on the receiver on the back side of the hood.

Make sure that the hood is fixed, and then release your hands.



Opening and Closing of Hood_003

1	Hood stay
2	Hood cover (LH)
3	Hood cover (RH)


- 5. Release the hood stay, and then close the hood slowly.
- 6. Securely engage the left and right rubber catches.
- 7. Install the nuts and bolts locking the left and right catch clips.

Opening and Closing of Underseat Cover



Be careful not to pinch your fingers when you open or close the underseat cover.

- 1. Make sure that the steering wheel is raised completely.
- 2. Bring the seat to the backmost position.
- 3. Pull up the lever behind the seat to unlock it.



Opening and Closing of Underseat Cover_001

1	Lever
2	Seat
Д	Pull up
В	Tilt forward
	4

4. Tilt the seat forward to open the cover. To close the cover, slowly lower the seat.

Inspection and Cleaning

Inspect and clean the machine with the goals of the followings.

- Accident prevention
- · Failure prevention
- · Performance retention

Make efforts for early detection of the machine failure and prevention of the sudden occurrence of trouble.

Perform maintenance and repair works immediately if any abnormality is found in the machine.

Rotary Knife

Inspection of Rotary Knife




When touching edged tools, wear gloves, since they could cut your hands.

Important

Frequently inspect the rotary knife since it may become dull quickly if the machine is operated in an environment of dry soil or sand.

- 1. Make sure that the rotary knife is not bent.
- 2. Make sure that the rotary knife is not chipped.
- 3. Check to see how much the rotary knife is worn.
- 4. Make sure that the rotary knife is not worn asymmetrically.
- 5. Make sure that the mounting bolt for the rotary knife is not loose.

Make sure that there are no cracks or tears between the sail and flat part of the rotary knife.



Inspection of Rotary Knife 001

1	Sail
2	Flat part

Radiator Cover

Inspection of Radiator Cover

- 1. Make sure that there is no damage to the radiator cover.
- 2. Make sure that the radiator cover is not contaminated.

Cleaning of Radiator Cover


Important

An unclean radiator cover may cause overheating or damage to the engine. It may also cause malfunction of the hydraulic system.

If the radiator cover has been contaminated with dust, be sure to clean it.

After operating the machine in a dusty environment, it is important to remove dust from the cover as soon as possible.

1. Open the radiator cover.



Cleaning of Radiator Cover_001

Radiator cover

2. Carefully clean the front and back of the radiator cover with water or compressed air.

Radiator

Inspection of Radiator

- 1. Make sure that there is no damage to the radiator.
- 2. Make sure that the radiator is not contaminated.

Cleaning of Radiator

Important

An unclean radiator may cause overheating or damage to the engine.

It may also cause malfunction of the hydraulic system.

Important


Do not use solid objects, such as a spatula or screwdriver, or high-pressure water to clean the radiator or oil cooler.

Otherwise, special fins or tubes may be damaged, possibly resulting in reduced cooling performance or coolant leakage.

If the radiator has been contaminated with dust, be sure to clean it.

After operating the machine in a dusty environment, it is important to remove dust as soon as possible.

- 1. Open the radiator cover.
- 2. Unlock the rubber catches on the left and right of the oil cooler, and then tilt the oil cooler.



Cleaning of Radiator_001

1	Oil cooler
2	Rubber catch
3	Radiator

3. Carefully clean the front and back of the radiator with water or compressed air.

Coolant

Inspection of Coolant



Caution

Do not touch the radiator or coolant during engine operation or immediately after the engine has been turned off.


Otherwise, you may get burned.



▲ Caution

Inspection should take place after the engine has well cooled down.

Make sure that the coolant level in the reserve tank is between "FULL" and "LOW". If the coolant level is lower than the "LOW" mark, supply clean water.



Inspection of Coolant 001

	_
1	Reserve tank
Α	Full
В	Low

Coolant Supply



A Caution

Do not touch the radiator or coolant during engine operation or right after the engine has been turned off.

Due to high temperatures, doing so could cause burns.

A Caution

Supply coolant after the engine has well cooled down.



⚠ Caution

The radiator cap is pressurized.

If you remove the radiator cap while the engine is overheated, hot steam will burst out, possibly resulting in burns.

Make sure that the water temperature and pressure are reduced, and then grab the cap with a thick cloth and gradually open the cap.


Important

When you supply coolant, be sure to use clean water, such as tap water.

Important

Tightly close the radiator cap. If the cap is loose or incorrectly installed, the engine will be overheated due to water leakage, resulting in engine damage.

1. If the coolant level in the reserve tank is lower than the "LOW" mark, open the reserve tank cap and fill the tank with clean water up to the "FULL" mark.




Coolant Supply 001

Reserve tank

- 2. If no coolant is in the reserve tank, follow the steps below to fill the tank with clean water.
 - [1] Open the radiator cap, and then supply clean water up to the opening.

[2] Open the reserve tank cap, and then supply clean water up to the "FULL" mark.



Coolant Supply_002

1 Radiator cap

Oil Cooler

Inspection of Oil Cooler for Hydraulic Oil

- 1. Make sure that there is no damage to the oil cooler.
- 2. Make sure that the oil cooler is not contaminated.

Cleaning of Oil Cooler

Important

An unclean oil cooler may cause malfunction of the hydraulic system.

Important

Do not use solid objects, such as a spatula or screwdriver, or high-pressure water to clean the radiator or oil cooler.


Otherwise, special fins or tubes may be damaged, possibly resulting in reduced cooling performance or coolant leakage.

If the oil cooler has been contaminated with dust, be sure to clean it.

After operating the machine in a dusty environment, it is important to remove dust as soon as possible.

1. Open the radiator cover.

2. Unlock the rubber catches on the left and right of the oil cooler, and then tilt the oil cooler.



Cleaning of Oil Cooler 001

1	Oil cooler
2	Rubber catch
3	Radiator


3. Carefully clean the front and back of the oil cooler with water or compressed air.

Hydraulic Oil

Inspection of Hydraulic Oil

The oil gauge is on the side of the hydraulic tank.

- 1. Lower the mower decks and maintain that position on a level surface.
- 2. Make sure that the oil level is at the middle of the oil gauge.



Inspection of Hydraulic Oil_001

1 Oil gauge

3. Check underneath the machine for oil leakage.

Hydraulic Oil Supply

Important

Do not mix different types of oil.

Important


Use Shell Tellus S2M46 (or equivalent) as hydraulic oil.

In case of an equivalent, consult
Characteristics of Hydraulic Oil and use
hydraulic oil whose characteristics are
superior to those of the specific hydraulic oil.
Especially regarding kinematic viscosity and
viscosity index, use of hydraulic oil whose
figures are less than those of the specified
hydraulic oil will cause a malfunction in the
hydraulic circuit.

Note: Characteristics of Hydraulic Oil

Specified Hydraulic Oil		Shell Tellus S2M46
ISO Viscosity Grade		ISO VG46
Density	15 °C (59 °F)	0.873 g/cm ³
Delisity		(0.0315 lb/in ³)
API Gravity		30.6
Flash Point (Open Cup)		230 °C (446 °F)
Pour Point	Pour Point	
Kinematic	40 °C (104 °F)	46 mm ² /s (46 cSt)
Viscosity	100 °C (212 °F)	7 mm ² /s (7 cSt)
Viscosity Index		109

1. If the oil level is low, remove the left tank cover, and then open the tank cap and supply oil.



Hydraulic Oil Supply_001

1	Tank cap
2	Oil gauge

2. Tighten the tank cap securely.

- 3. Start the engine, raise and lower the mower decks, and turn the steering wheel left and right.
 - Move forward and reverse repeatedly several times.
- 4. Lower the mower decks and maintain that position on a level surface, and then check to see if the oil level is at the middle of the oil gauge. If necessary, supply oil.
- 5. Check underneath the machine for oil leakage.
- 6. Attach the left tank cover.

Hydraulic Hoses

Inspection of Hydraulic Hoses and Pipes



When checking the hydraulic circuit for pinhole leaks or oil leakage from nozzles, do not use your hands. Use items such as paper or corrugated cardboard to find leakage points.

Be extremely careful with high-pressure oil as it may pierce your skin, resulting in personal accidents.

If fluid is injected into the skin it must be surgically removed within a few hours by a doctor familiar with this form of injury or gangrene may result.

- Make sure that there is no wear, deterioration or damage in the hydraulic hoses and pipes.
- 2. Make sure that there is no looseness in the connecting portion of the hydraulic hoses and pipes.
- 3. Check underneath the machine for hydraulic oil leakage.

Air Cleaner

Inspection of Air Cleaner

Liners and piston rings so that the engine will always operate smoothly.


A contaminated air cleaner element may cause malfunction of the engine.

Clean or replace the air cleaner element as necessary.

- 1. Make sure that there is no damage to the air cleaner.
- 2. Make sure that the air cleaner element is not contaminated.

Check the air cleaner contamination by using the vacuum indicator.

If the air cleaner element is contaminated, the vacuum indicator will display a red ring.



Inspection of Air Cleaner_001

1	Air cleaner
2	Vacuum indicator

Cleaning of Air Cleaner Element

A contaminated air cleaner element may cause malfunction of the engine.

To maximize the life of the engine, clean the air cleaner properly.


Important

The inner element cannot be cleaned.

- 1. Follow the steps below to clean the outer element.
 - [1] Remove the clips, and remove the air cleaner cap, and then remove the outer element.

- [2] While paying close attention not to damage the outer element, tap a solid portion of the outer element or blow compressed air from its inside to remove dust and dirt.


 If the outer element is extremely
 - If the outer element is extremely contaminated, replace it with a new one.
- [3] Attach the outer element to the air cleaner body.
- [4] Replace the air cleaner cap, and then fix it securely using the clips.



Cleaning of Air Cleaner Element_001

1	Outer element
2	Inner element
3	Clip
4	Air cleaner cap
5	Air cleaner body
6	Vacuum indicator

2. Press the reset button for the vacuum indicator.



Cleaning of Air Cleaner Element_002

1	Reset button
2	Vacuum indicator

Battery

Inspection of Battery

♠ Danger

Keep away from fire while inspecting or charging the battery.

The battery may explode.

▲ Warning

Do not clean the battery with a dry cloth. Cleaning the battery with a dry cloth may cause it to catch fire or explode due to static electricity.

▲ Warning

Implement after the engine and DPF etc. have well cooled down.

Otherwise, you may get burned.

Important

Be sure to stop the engine before inspecting or charging the battery.

Battery inspection items are described below.

- 1. Inspecting the exterior
 - Visually inspect the exterior of the battery, and check that there are no cracks, splits, missing sections, or abnormal deformation in the battery case, and that there is no electrolyte leaking.
 - If abnormalities are found, immediately replace the battery.
- 2. Cleaning the exterior
 - Use a wet cloth for cleaning.

Inspect the vent plugs or vent holes on the side of the battery, and if they are blocked by dirt wash them with water to remove the blockage.

Continuing to use the battery with the vent holes blocked may cause the battery to rupture from increased internal pressure due to gases generated inside the battery.

- Inspecting the mounting bracket
 Inspect whether the battery is secured firmly with the mounting bracket.

 If the bracket is loose, tighten the mounting bracket nuts until the battery is secured firmly.
 - An improperly mounted battery may cause damage to the battery case or electrolyte leaks due to the battery moving with vibrations while traveling.
- 4. Inspecting the cable terminals If the connection between the battery terminals and vehicle's cable terminals are loose, tighten the nuts until the cable terminals are secured firmly. Insufficiently tightened terminals may result in poor battery charging, damage to the terminals due to poor contacts, or an explosion.

If the terminals are corroded, rub them clean with a wire brush or fine grit sandpaper, and lightly apply anti-rust grease.

5. Inspecting the electrolyte level and refilling



Do not allow the battery fluid level to become lower than the LOWER LEVEL (minimum fluid level line).

The battery may explode if it is used or charged while the battery fluid level is at the LOWER LEVEL (minimum fluid level line).

▲ Warning


When refilling, do not fill purified water above the UPPER LEVEL line.

Doing so may result in electrolyte leaks.

Clean the areas around the battery fluid level lines using a cloth damped with water to check the electrolyte level from the side of the battery.

Make sure that the battery fluid level is between the UPPER LEVEL (maximum fluid level line) and the LOWER LEVEL (minimum fluid level line).

Refill with purified water up to the UPPER LEVEL line if the level is lower than halfway between the UPPER LEVEL and LOWER LEVEL lines.



Inspection of Battery_001

1	UPPER LEVEL line
2	LOWER LEVEL line

Supply of Battery Fluid

▲ Danger

Be careful not to let your skin, eyes or clothes, etc., come into contact with the battery fluid or accidentally swallow the fluid.

Should your skin or clothes come into contact with the battery fluid, immediately wash them away with water.

♠ Danger

When you supply battery fluid, wear protective garments and safety glasses, etc.

▲ Warning

Do not allow the battery fluid level to become lower than the LOWER LEVEL (minimum fluid level line).

The battery may explode if it is used or charged while the battery fluid level is at the LOWER LEVEL (minimum fluid level line).

▲ Warning

When refilling, do not fill purified water above the UPPER LEVEL (maximum fluid level line). Doing so may result in electrolyte leaks.


▲ Caution

Implement after the engine and muffler etc. have well cooled down.

Otherwise you may get burned.

If the battery fluid level is lower than halfway between the UPPER LEVEL (maximum fluid level line) and LOWER LEVEL (minimum fluid level line), add purified water.

- 1. Loosen the vent plug and remove it.
- Add purified water up to the UPPER LEVEL (maximum fluid level line)
- 3. Tighten the vent plug securely.



Supply of Battery Fluid_001

1	Maximum fluid level line
2	Minimum fluid level line

Electrical Wiring

Inspection of Electrical Wiring

Important

Electrical short circuit will cause fire, electrical leakage and malfunction of electrical equipments.

- 1. Make sure that there is no defacement in wires and terminals.
- 2. Make sure that there is no deterioration or damage in wires and terminals.
- 3. Make sure that there is no looseness in wiring connections.
- 4. Make sure that there is no poor terminal connection.

Tire

Inspection of Tires

- 1. Check the pneumatic pressure of the tires.
- 2. Make sure that there are no cracks, damage or abnormal wear.

Tire size	Pneumatic pressure	
Front wheel (29 x 14.00 - 15)	150 kPa (1.5 kgf/cm²)	22 psi
Rear wheel (20 x 12.00 - 10)	140 kPa (1.4 kgf/cm²)	20 psi

Brake

Inspection of Brake

- When depressing the brake pedal fully, make sure that there is appropriate clearance between the floorboard and the pedal or pedal reserve distance.
- 2. When depressing the brake pedal fully, make sure that the pedal reaction is not spongy and that there is no noise.
- When depressing the brake pedal during traveling, make sure that the machine stops smoothly and the braking is sufficiently effective.

Inspection of Parking Brake

- 1. Make sure that the parking brake is applied after depressing the brake pedal and pulling the parking brake lever.
- Make sure that the parking brake is not applied even slightly after depressing the brake pedal to release the parking brake lever.

Belt

Inspection of Belt



The engine must be stopped when the belt is inspected.

Important

A slacking or damaged belt or damaged fan may cause overheating or lack of a battery charge.

- 1. Check the belt tension.
- 2. Make sure that there are no cracks and damage on the belt.
- 3. Make sure that there is no abnormal wear on the belt.

Wire

Inspection of Wire

- 1. Make sure that the wire is not cracked or damaged.
- 2. Make sure that the wire is not worn.
- 3. Make sure that the wire is not crushed.
- 4. Make sure that the wire is not bent.

Make sure that the wire is not corroded or rusted.

Safety Device

Inspection of Safety Device

Make sure that the safety device operates correctly.

"Safety Mechanisms" (Page 4-9) Repair the machine before operation whenever there is any abnormality.

Around The Engine

Inspection of Engine/DPF-Associated Parts



Implement after the engine and DPF etc. have well cooled down.

Otherwise, you may suffer burns.

- 1. Check for damages and dirt.
- 2. Check the mount for looseness and cracks.
- 3. Check for liquid leakage.
- 4. Check on and around the DPF for grass clippings and flammable materials.

Cleaning Engine/DPF-Associated Parts



Implement after the engine and DPF etc. have well cooled down.

Otherwise, you may suffer burns.

- Clean clippings and remove dirt.
 Remove clippings and dust in a gap
 thoroughly due to the intricately shaped
 engine.
- 2. Blow compressed air to clean any grass or flammable materials that may be attached on or around the DPF.


Engine Oil

Inspection of Engine Oil

Important

Securely tighten the oil level gauge and oil filler cap.


 Stop the engine, wait for 10 to 20 minutes for the engine to cool down, and then check the oil level. 2. Position the machine so that the engine will be level, and then insert the oil level gauge all the way to check the oil level.



Inspection of Engine Oil 001

1 Oil gauge	1	Oil gauge
-------------	---	-----------

3. The appropriate oil level should be between the upper and lower limit lines on the gauge.



Inspection of Engine Oil_002

1	Oil level gauge
2	Upper limit
3	Lower limit

Supply of Engine Oil

Important

Do not supply too much engine oil. Otherwise, the engine may be damaged.

Important

Do not mix different types of engine oil.


Important

Be sure to use engine oil that is classified as JASO DH-2 or API Service Grade CJ-4, with SAE viscosity that is appropriate for the operating environment (ambient temperature).

Important

Securely tighten the oil level gauge and oil filler cap.

- If the engine oil level is lower than the lower limit line on the oil level gauge, supply engine oil through the oil filling port.
 Remove the oil filler cap, and then supply new engine oil until the oil reaches a level in between the upper and lower limit lines on the oil level gauge.
- 2. Replace the oil filler cap.



Supply of Engine Oil_001


1 Oil filler cap

 It will take a while for the supplied engine oil to descend into the oil pan.
 Check the oil level again 10 to 20 minutes after supplying the oil.

Fuel

Inspection of Fuel Quantity

With the machine on a level surface, observe the fuel level in the monitor to check the fuel level.



Inspection of Fuel Quantity_001

1	Monitor
2	Fuel level

Fuel Supply



Do not supply additional fuel after the fuel level indicates 100%.

If you supply too much fuel, it might overflow from the fuel cap when you travel or work on a slope.



Keep fire away while refueling. Do not smoke.

Important

Use ultra-low sulfur diesel fuel (sulfur-free diesel fuel).


Important

In case of lack of fuel, DPF regeneration can not be performed.

If the monitor displays the warning message "FUEL LEVEL LOW", immediately stop operation, and then supply fuel (diesel). The fuel tank capacity is approximately 51.0 dm³ (51.0 L).

Note:

The factory default low fuel level is 10%. The level can be changed optionally.



Fuel Supply 001


1	Monitor
2	Fuel level

Air Bleeding of Fuel System

- 1. Open the hood.
- 2. Set the key switch to the "ON" position and then start the electromagnetic pump.
- 3. A priming pump is installed on the feed pump.

Repeatedly press the top of the priming pump with your finger until resistance is felt, to bleed air.

- 4. Set the key switch to the "OFF" position.
- 5. Close the hood.



Air Bleeding of Fuel System_001

1	Feed pump
2	Priming pump

Water Separator

Inspection of Water Separator


Important

If water contaminates the fuel, the supply pump and injector will seize due to heat.

The water separator removes water from the fuel.

1. Make sure that debris and water have not accumulated in the cup.

With the float raised, water incorporation is confirmed.



Inspection of Water Separator_001

1	Float
2	Cup
3	Water drain plug
4	Element
5	Air-bleeding bolt

Draining of Water Separator

Important


If water contaminates the fuel, the supply pump and injector will seize due to heat.

Drain the water in accordance with the Maintenance Schedule.

However, when the float is raised by water, drain the water even before the schedule.

- 1. Follow the steps below to drain the water.
 - [1] Stop the engine, and then turn the key switch to the "OFF" position.
 - [2] Place a container under the water separator.

[3] Loosen the water drain plug and airbleeding bolt to drain the water into the container.



Draining of Water Separator 001

1	Float
2	Cup
3	Water drain plug
4	Element
5	Air-bleeding bolt

- [4] Tighten the water drain plug and airbleeding bolt.
- [5] Bleed air from the fuel system.

Cleaning of Water Separator

Important

If water contaminates the fuel, the supply pump and injector will seize due to heat.


Clean the water separator in accordance with the Maintenance Schedule.

However, when debris has accumulated in the cup, clean it even before the schedule.

- 1. Follow the steps below to clean the water separator.
 - [1] Stop the engine, and then turn the key switch to the "OFF" position.
 - [2] Place a container under the water separator.

[3] Remove and clean the cup, element and float.

Replace the element with a new one when replacement needed.



Cleaning of Water Separator_001

1	Float
2	Cup
3	Water drain plug
4	Element
5	Air-bleeding bolt

- [4] Install the cup, element and float in their original positions.
- [5] Bleed air from the fuel system.

Fuel Filter

Inspection of Fuel Filter

- 1. Make sure that there is no fuel leakage.
- 2. Make sure that the filter is not damaged.
- 3. Make sure that the filter is not contaminated.

Liquid Leakage

Inspection of Liquid Leakage



A Caution

When performing maintenance on the hydraulic system, lower the mower decks.

Important

After approximately 50 hours of operation, some tightened portions may be loosened and liquid such as oil may leak.

Be sure to retighten the parts.

- 1. Check the bottom of the machine for leakage of liquid such as oil, water, fuel,
- 2. Locate the leakage and identify the type of liquid.

Ignoring leakage will cause further trouble.

Bolts and Nuts

Inspection of Bolts and Nuts

Important

The bolts and nuts may be loosened at the earlier stage of the use.

Be sure to retighten or replace before operating the machine whenever there is any abnormality.

- 1. Check the bolts and nuts for looseness and coming off.
- 2. Check the bolts and nuts for cracks and damages.
- Check the bolts and nuts for rust.
- 4. Check around the bolts and nuts for traces of rust fluid.
- 5. Check for unequal bolt length.
- 6. Check the bolts and nuts for stripped threads and abrasion.

Inspection of Wheel Mounting Bolt

Important

Tighten the wheel mounting bolts on the specified torque by using a torque wrench.

1. Check the wheel mounting bolts and wheel nuts for looseness and coming off.

- 2. Check the wheel mounting bolts and wheel nuts for cracks and damages.
- 3. Check the wheel mounting bolts and wheel nuts for rust.
- 4. Check around the wheel mounting bolts and wheel nuts for traces of rust fluid.
- 5. Check the wheel mounting bolts for unequal bolt length.
- 6. Check the wheel mounting bolts and wheel nuts for stripped threads and abrasion.

Mower Deck

Cleaning of Mower Deck

Be sure to clean the mower deck after use.

- 1. Stop the engine, and then remove the key.
- 2. Carefully clean the front and back of the mower deck with water or compressed air.
- 3. Remove any grass wrapped around the rotary knife.

Adjustment before Work

Adjustment of Steering Wheel Position



Since it is dangerous, do not adjust the steering wheel while traveling.

▲ Caution


Be sure the steering wheel position is securely locked.

It may result in an unexpected accident if it becomes loose while traveling.

The steering wheel position can be adjusted up or down.

Adjust the position according to the operator's body size.

Shift the tilt lever to the "FREE" position, move the steering wheel to the position that suits your work requirements, and then shift the tilt lever to the "LOCK" position to secure the steering wheel in place.



Adjustment of Steering Wheel Position_001

1	Steering wheel
2	Tilt lever
Α	FREE (released)
В	LOCK (locked)

Adjustment of Seat Position




Do not make an adjustment while traveling since it is dangerous.

Use the adjustment levers to adjust the seat position.

Adjust the position to fit the operator.

- 1. Use the forward/backward adjustment lever to adjust the seat back and forth.
- 2. Use the tilt adjustment lever to adjust the angle of the backrest.
- Turn the suspension adjustment handle to adjust the firmness of the seat suspension. Refer to the suspension indicator while making adjustments. [45 to 130 kg (99.2 to 286.6 lb)]
- 4. Turn the armrest adjustment knob to adjust the angle of the armrests.
- 5. Turn the seat height adjustment knob to adjust the height of the seat steplessly. [0 to 60 mm (0 to 2.36 in)]

Adjust the height of the seat while sitting in it.



Adjustment of Seat Position 001


.,	<u> </u>
1	Forward/backward adjustment lever
2	Tilt adjustment lever
3	Suspension adjustment handle
4	Suspension indicator
5	Armrest adjustment knob
6	Seat height adjustment knob

Adjustment before Work Page 5-17

Adjustment of Cutting Height

Cutting Height Table

The adjustment range for the cutting height is 20.0 - 91.5 mm (0.79 - 3.60 in).



Cutting Height Table_001

1	Adjusting plate position 1
2	Adjusting plate position 2
3	Adjusting plate position 3
4	Adjusting plate position 4

Adjusting Plate Position	1	2	3	4	
Adjusting Collars					
Inserted Under					
Cutting Height	Cutting Height				
Adjusting Plate					
(Qty)					
0	20.0 mm	30.0 mm	45.5 mm	55.5 mm	
O O	(0.79 in)	(1.18 in)	(1.79 in)	(2.19 in)	
1	26.0 mm	36.0 mm	51.5 mm	61.5 mm	
ľ	(1.02 in)	(1.42 in)	(2.03 in)	(2.42 in)	
2	32.0 mm	42.0 mm	57.5 mm	67.5 mm	
2	(1.26 in)	(1.65 in)	(2.26 in)	(2.66 in)	
3	38.0 mm	48.0 mm	63.5 mm	73.5 mm	
3	(1.50 in)	(1.89 in)	(2.50 in)	(2.89 in)	
4	44.0 mm	54.0 mm	69.5 mm	79.5 mm	
4	(1.73 in)	(2.13 in)	(2.74 in)	(3.13 in)	
5	50.0 mm	60.0 mm	75.5 mm	85.5 mm	
3	(1.97 in)	(2.36 in)	(2.97 in)	(3.67 in)	
6	56.0 mm	66.0 mm	81.5 mm	91.5 mm	
0	(2.20 in)	(2.60 in)	(3.21 in)	(3.60 in)	

Note:

The factory default cutting height is 48.0 mm (1.89 in).

Adjustment With Adjusting Collars

Adjusting collars are installed at three locations on each mower deck.


Important

The length of grass cut off at any one time must be no more than 30.0 mm (1.18 in).

Important

Do not cut off more than 1/3 of the grass height.

- 1. Apply the parking brake, and then lower all mower decks.
- 2. Stop the engine, and then remove the key.
- 3. Loosen the nuts securing the adjusting collars at the three locations.




Adjustment With Adjusting Collars_001


- 4. Refer to the Cutting Height Table, and then adjust the number of adjusting collars at the three locations.
 - [1] To increase cutting height:

 Remove an upper adjusting collar and insert it below.

[2] To decrease cutting height: Remove a lower adjusting collar and insert it above.




Adjustment With Adjusting Collars 002



Adjustment With Adjusting Collars_003

1 Adjusting collar

5. After adjusting the adjusting collars at the three locations, firmly tighten all nuts.



Adjustment With Adjusting Collars_004

1 Nut

Adjustment With Cutting Height Adjusting Plates

Cutting height adjusting plates are installed at three locations on each mower deck.


Important

The length of grass cut off at any one time must be no more than 30.0 mm (1.18 in).

Important

Do not cut off more than 1/3 of the grass height.

- 1. Apply the parking brake, and then lower all mower decks.
- 2. Stop the engine, and then remove the key.
- 3. Loosen the six bolts securing the cutting height adjusting plates at the three locations on the mower deck.




Adjustment With Cutting Height Adjusting Plates_001

1	Bolt
2	mower deck
3	Cutting height adjusting plate

- 4. Refer to the Cutting Height Table, and then change the hole positions.
 - [1] To increase cutting height:
 - a. While lifting the handle at each location on the mower deck, remove the two bolts.
 - b. Raise the mower deck to change the hole positions, and then temporarily secure it with the two bolts.
 - [2] To decrease cutting height:
 - a. While lifting the handle at each location on the mower deck, remove the two bolts.


b. Lower the mower deck to change the hole positions, and then temporarily secure it with the two bolts.



Adjustment With Cutting Height Adjusting Plates 002

1	Handle
2	Bolt

5. After making adjustments at the three locations, firmly tighten all bolts.



Adjustment With Cutting Height Adjusting Plates_003

1	Bolt	
2	mower deck	
3	Cutting height adjusting plate	

Start/Stop of Engine

Procedure to Start Engine



Before starting the engine, make sure that there are no other people or obstacles around the machine.

Important


When restarting the engine after it has been turned off, wait until the electromagnetic pump has fully stopped before restarting the engine. The electromagnetic pump will stop approximately 7 seconds after the key switch is turned to the "OFF" position.

Important

Starter operation must take 15 seconds or less.

If the engine does not start, stop using the battery for 30 to 60 seconds to avoid exhausting the battery.

- 1. Sit on the seat.
- 2. Make sure that the parking brake is applied.
- 3. Make sure that the knife rotation switch is in the "Stop" position.
- 4. Make sure that the traveling pedal is in the neutral position.
- Move the throttle knob halfway from the "Low speed" position toward the "High speed" position.
- Switch the ignition key to the "ON (GLOW)" position.



Procedure to Start Engine_001

1	OFF
2	ON (GLOW)
3	START


Page 5-20 Start/Stop of Engine

Important

When the ignition key is switched to the "ON" position, "Warming up" may appear in the monitor display.

Do not start the engine until the message disappears.

7. Make sure that the glow plug is generating heat, the "BARONESS" logo or "Warming up" message appears in the monitor display, and the yellow and red LEDs are lit.



Procedure to Start Engine_002

1	Monitor display
2	Yellow LED
3	Red LED

Important

Quickly returning the ignition key from the "START" position to the "ON" position may result in damage to the machine.

- 8. After the "BARONESS" logo and the yellow and red LEDs go off and the parameters (items and values such as the rotation speed) appear, immediately set the ignition key to the "START" position.
- 9. When the starter starts rotating and the engine starts, slowly return the ignition key to the "ON" position.

Important

Be sure to warm up the engine. Otherwise, a hydraulic system malfunction will occur.

 Move the throttle knob to the "Low speed" position, and then warm up the engine so that the engine coolant temperature exceeds 50 °C.

Procedure to Stop Engine

- 1. Set the traveling pedal to the neutral position.
- 2. Apply the parking brake.
- 3. Set the knife rotation switch to the "Stop" position.
- 4. Raise the mower decks.
- 5. Shift the throttle knob to the "Low speed" position, and then idle the machine for 1-2 minutes
- 6. Switch the ignition key to the "OFF" position.
- 7. Make sure that the engine has stopped.

Parking and Stopping

Leaving the machine



If the brakes are not sufficiently effective, use the wheel stoppers to secure the machine.



Never park the machine on a slope.

- 1. Park the machine on level ground.
- 2. Apply the parking brake.
- 3. Stop the engine.
- 4. Remove the ignition key.
- 5. Install the rubber cap to the key switch.
- 6. Hook the mower lock levers (latches) for the mower decks #4 and #5.
- 7. Leave the driver's seat.

Parking and Stopping Page 5-21

Move

Traveling Procedure



A Caution

Under any circumstances drive the machine at such a speed that you can stop it immediately for emergencies.



A Caution

When traveling, be sure to stop the rotary knives and raise the mower decks.

Important

Do NOT start to move or stop the machine abruptly.

It will damage the hydraulic system or result in oil leakage.

- 1. Start the engine.
- 2. Make sure that all the mower decks are raised and that the mower lock levers (latches) for mower decks #4 and #5 are hooked.
- 3. Gradually move the throttle lever toward the "High speed" position.
- 4. Depress the brake pedal to release the parking brake.
- 5. Release the brake pedal.
- 6. Slowly depress the traveling pedal.
- 7. The machine starts traveling.
- 8. The machine stops slowly when the traveling pedal released.

Cutting Work

Cutting Operation



Caution

Cutting work must be performed at an appropriate speed for the site and location. When cutting bumpy surfaces, keep the engine rpm steady, and slow down the cutting speed.

▲ Caution

Please note that if you stop operating the mower deck up/down lever before the mower decks are raised completely, knife rotation may not stop.

Knife rotation will be turned on or off based on the sensor-detected position of the mower decks.

Caution

Be sure that people around the machine keep a safe distance away.

Important

Do NOT start to move or stop the machine abruptly.

It will damage the hydraulic system or result in oil leakage.

- 1. Release the mower lock levers for mower decks #4 and #5 just before cutting operation.
- 2. Start the engine. "Procedure to Start Engine" (Page 5-20)
- 3. Depress the brake pedal to release the parking brake.
- 4. Shift the throttle knob to rev the engine up to the maximum rpm.
- 5. Shift the mower deck up/down lever to the "Lower" position to lower the mower decks.
- 6. Set the knife rotation switch to the "Rotation" position to rotate the rotary knives of all mower decks.
- 7. Depress the traveling pedal to start cutting work.

Note:

During the work, the rotary knives will rotate or stop in sync with the up and down motion of the mower decks.

Page 5-22 Move

Transporting

Transporting Procedure

When loading the machine into a trailer or a truck to transport it, drive the machine forward. When unloading, drive the machine in reverse. If the roof is installed on the machine, remove it

The roof may be damaged by wind pressure.

Transporting Page 5-23

Page 5-24 Transporting

Precautions for MaintenancePage 6-2				
Jacking Up The Machine	Page 6-2			
About Jacking Up The Machine Jack-Up Points	_			
Greasing	Page 6-3			
About Greasing Greasing Points	_			
Lubrication	Page 6-6			
About LubricationLubricating Points	Page 6-6			
Adjustment and Replacement	Page 6-7			
Swiveling Mower Decks #2 and #3 Change of Rotary Knife	Page 6-8 Page 6-11 Page 6-13 Page 6-13 Page 6-14 Page 6-15 Page 6-17 Page 6-18 Page 6-20 Page 6-20 Page 6-21			
Storage Page 6-22				
Long-Term Storage	Page 6-22			

Maintenance

Precautions for Maintenance



The chapter "Maintenance" in this manual describes practical measures which should be performed by a mechanic with expertise.

The owner should instruct the mechanic with expertise to perform maintenance service for this machine.



First, learn well the operations you plan to perform.

Important

Use tools appropriate for each operation.

Important

Use Baroness genuine parts for replacement and accessories.

Our product warranty may be void if you use non-genuine parts for replacement or accessories.

Jacking Up The Machine

About Jacking Up The Machine



When replacing a tire or beginning any other maintenance or repairs, be sure to chock the wheels to prevent the machine from moving. Before jacking up the machine, park it on a hard, flat surface such as a concrete floor and remove any obstacles that could prevent you from performing the work safely.

When necessary, use an appropriate chain block, hoist, or jack.

Support the machine securely with jack stands or appropriate blocks.

Failure to do so may cause the machine to move or fall, resulting in injury or death.


Important

Only place a jack under the jack-up points specified.

Placing a jack at any other point will result in damage to the frame or other parts.

Use the jack-up points identified in this manual when jacking up the machine.


Jack-Up Points



Jack-Up Points 001


	Jack-up points
1	Front right frame
2	Front left frame
3	Center of pivot
4	Below rear wheel motors

1. Front right frame




Jack-Up Points_002

2. Front left frame




Jack-Up Points_003

3. Center of pivot



Jack-Up Points_004

4. Below rear wheel motors Two locations



Jack-Up Points_005

Greasing

About Greasing

Since there may be adhesion or damage due to lack of grease on moving parts, they must be greased.

Add urea-based No. 2 grease in accordance with the Maintenance Schedule.


Other locations where the specified grease or lubricant is used are indicated in "Greasing Points"

Add grease using the specified grease or lubricant.

Greasing Points

Grease nipples are installed in the following locations.

Add grease every 50 hours of operation.



Greasing Points_001

Greasing Page 6-3


Maintenance

	Portion	No. of Greasing
		Points
1	Mower arm fulcrum	5
2	Lift arm fulcrum	5
3	Lift arm cylinder fulcrum	12
4	Pivot	3
5	Neutral position area	2
6	Traveling pedal shaft fulcrum	2
7	Foot brake	3
8	Pin for swiveling rear mower deck	2

1. Mower arm fulcrum


There is one greasing point on the arm connected to each mower deck. Grease mower decks #2 and #3 in the swiveled position.

Mower decks #1, #4 and #5



Greasing Points_002

Mower decks #2 and #3




Greasing Points_003

2. Lift arm fulcrum


There is one greasing point on the arm connected to each mower deck. Lower the mower decks before greasing the lift arm fulcrums.

Mower decks #1 and #4




Greasing Points_004

Mower decks #2 and #3



Greasing Points_005

Mower deck #5




Greasing Points_006

Page 6-4 Greasing

3. Lift arm cylinder fulcrum

This is on each cylinder of the arms connected to each mower deck.


Mower decks #1, #4 and #5 There are two greasing points on each cylinder.



Greasing Points_007

1 Grease nipple (2 locations)

Mower decks #2 and #3 There are three greasing points on each cylinder.




Greasing Points_008

1 Grease nipple (3 locations)


4. Pivot

Middle between the rear wheels




Greasing Points_009

Rear left wheel



Greasing Points_010


Rear right wheel



Greasing Points_011

5. Neutral position area

There are two locations.




Greasing Points_012

Greasing Page 6-5


Maintenance

6. Traveling pedal shaft fulcrum There are two locations.




Greasing Points_013

7. Foot brake There are three locations.



Greasing Points_014

8. Pin for swiveling rear mower deck There is one greasing point each on the mower decks #2 and #3.



Greasing Points_015

Lubrication


About Lubrication

It is necessary to lubricate moving parts so that they will not become stuck or damaged. The locations where lubricant is used are indicated in "Lubricating Points".

Apply the lubricant.

Lubricating Points


Apply lubricant at the following locations every 50 hours of operation.



Lubricating Points_001

	Location	No. of lubricating points
1	Steering cylinder spherical bearing	2

1. Steering cylinder spherical bearing There are two locations.



Lubricating Points_002

Page 6-6 Lubrication

Adjustment and Replacement

Swiveling Mower Decks #2 and #3



A Caution


The rotary knife is an edged tool. Take extra care in handling since they could cut your hands or legs.



Be careful not to inhale exhaust gas while swiveling the mower decks.

Maintenance can be performed more easily with mower decks #2 and #3 swiveled.


- 1. Lower the mower decks, and then stop the engine.
- 2. Remove the clip pin, and then remove the grip pin.



Swiveling Mower Decks #2 and #3_001

1	Mower arm
2	Clip pin
3	Grip pin


3. Swivel the mower deck toward the outside of the main vehicle.



Swiveling Mower Decks #2 and #3_002

Mower deck


4. Fully insert the grip pin into the locking hole for maintenance, and then install the clip pin in the grip pin.



Swiveling Mower Decks #2 and #3 003

1	Grip pin
2	Clip pin

5. Start the engine, and then raise the mower decks.



Swiveling Mower Decks #2 and #3_004

6. After the maintenance is completed, reverse the procedure to return the machine to its original condition.

Change of Rotary Knife



▲ Caution

The rotary knife is an edged tool. Take extra care in handling since they could cut your hands or legs.



If the rotary knife becomes worn or damaged, a crack or tear between the sail and flat part will result.

Take extra care since a broken piece of the rotary knife may fly off while it is rotating.




A Caution

When touching edged tools, wear gloves, since they could cut your hands.

Important

The rotary knife has a specific installation direction.

Do not install it facing the wrong direction.



Change of Rotary Knife_001

1	Rotary knife top side
2	Rotary knife bottom side


Important

Before installing the rotary knife, make sure that it is balanced.

If the edge of the rotary knife becomes chipped or thin, replace it with a new one.

The criteria for replacing the rotary knife are described below.


1. When the narrowest part of the rotary knife has a width of less than 2/3 of the width of a new knife



Change of Rotary Knife_002

1	Total width
2	Blade edge
3	Blade base
4	Sail
Α	less than 2/3
В	30 - 40°
С	0.5 - 1.0 mm (0.02 - 0.04 in)

2. When the thinnest part of the rotary knife has a thickness of less than 1/3 of the thickness of a new knife




Change of Rotary Knife 003

	<u> </u>
1	Thickness
Α	less than 1/3

Mower Deck #1


- 1. Start the engine, and then raise the mower decks.
- 2. Stop the engine, and then remove the key.
- 3. Lift the mower deck at the front.



Mower Deck #1_001

1 Mower deck


4. Remove the cotter pin and hardened roundhead pin inserted at a, and then insert them at b.



Mower Deck #1_002

1	Cotter pin
2	Hardened roundhead pin

- 5. Follow the steps below to remove the rotary knife.
 - [1] Use the square pipe from the included tools to secure the rotary knife so that it does not turn.
 - [2] Remove the two bolts, spring washers and washers used to install the rotary knife.
 - [3] Remove the knife guide.
 - [4] Remove the rotary knife.



Mower Deck #1_003

1	Square pipe
2	Rotary knife
3	Bolt
4	Spring washer
5	Washer
6	Knife guide


Important

The tightening torque for the knife mounting bolt is 104 - 134 N-m (1,060.49 - 1,366.40 kgf-cm).

Install the rotary knife.For installing the rotary knife, reverse the removing procedure.

Mower Decks #2/#3


- 1. Swivel the mower deck.
- 2. Start the engine, and then raise the mower decks.
- 3. Stop the engine, and then remove the key.
- 4. Lift the mower deck at the front.



Mower Decks #2/#3_001

Mower deck


5. Remove the cotter pin and hardened roundhead pin inserted at a, and then insert them at b.



Mower Decks #2/#3 002

1	Cotter pin
2	Hardened roundhead pin

- 6. Follow the steps below to remove the rotary knife.
 - [1] Use the square pipe from the included tools to secure the rotary knife so that it does not turn.
 - [2] Remove the two bolts, spring washers and washers used to install the rotary knife.
 - [3] Remove the knife guide.
 - [4] Remove the rotary knife.



Mower Decks #2/#3_003

1	Square pipe
2	Rotary knife
3	Bolt
4	Spring washer
5	Washer
6	Knife guide


Important

The tightening torque for the knife mounting bolt is 104 - 134 N-m (1,060.49 - 1,366.40 kgf-cm).

7. Install the rotary knife.
For installing the rotary knife, reverse the removing procedure.

Mower Decks #4/#5


1. Start the engine, and then raise the mower decks.



Mower Decks #4/#5_001

Mower deck

- 2. Stop the engine, and then remove the key.
- 3. Remove the cotter pin and hardened roundhead pin inserted at a, and then insert them at c.




Mower Decks #4/#5_002

1	Cotter pin
2	Hardened roundhead pin

4. Follow the steps below to remove the rotary knife.

- [1] Use the square pipe from the included tools to secure the rotary knife so that it does not turn.
- [2] Remove the two bolts, spring washers and washers used to install the rotary
- [3] Remove the knife guide.
- [4] Remove the rotary knife.



Mower Decks #4/#5_003

1	Square pipe
2	Rotary knife
3	Bolt
4	Spring washer
5	Washer
6	Knife guide

Important

The tightening torque for the knife mounting bolt is 104 - 134 N-m (1,060.49 - 1,366.40 kgfcm).

5. Install the rotary knife. For installing the rotary knife, reverse the removing procedure.

Grinding of Rotary Knife



A Caution

The rotary knife is an edged tool. Take extra care in handling since they could cut your hands or legs.



Wear gloves when touching edged tools to avoid cutting your hands.



If the rotary knife becomes worn or damaged, a crack or tear between the sail and flat part will result.

Take extra care since a broken piece of the rotary knife may fly off while it is rotating.



When grinding the rotary knife, be sure to wear safety glasses and gloves.


Important

Using an imbalanced rotary knife will cause vibrations, resulting in damage to the machine.

When the edge of the rotary knife becomes rounded and no longer cuts well, sharpen the worn cutting edge with a grinder or sander. If the edge of the rotary knife becomes chipped or thin, replace it with a new one. The criteria for grinding the rotary knife is described below.

1. When, after grinding, the width of the rotary knife to the blade edge is 2/3 or more of the total width of a new knife


2. When, after grinding, the blade base of the rotary knife does not reach the sail



Grinding of Rotary Knife_001

Total width
Blade edge
Blade base
Sail
2/3 or more
30 - 40°
0.5 - 1.0 mm (0.02 - 0.04 in)

When the thinnest part of the rotary knife has a thickness of 1/3 or more of the thickness of a new knife



Grinding of Rotary Knife_002

1	Thickness
Α	1/3 or more

Follow the steps below to grind the rotary knife.


1. Remove the rotary knife from the mower deck.

"Change of Rotary Knife" (Page 6-8)

Important

Grind only the top surface of the edge, and be sure to maintain the original angle. By equally grinding the left and right ends of the rotary knife, it can be sharpened without becoming imbalanced.

2. Grind the cutting edge of the rotary knife.
Grind so that the edge angle is 30 - 40
degrees, the point thickness is 0.5 - 1.0 mm
(0.02 - 0.04 in), and the blade base does not reach the sail.



Grinding of Rotary Knife_003

1	Total width
2	Blade edge
3	Blade base
4	Sail
Α	2/3 or more
В	30 - 40°
С	0.5 - 1.0 mm (0.02 - 0.04 in)

- Balance the rotary knife.
 "Balancing of Rotary Knife" (Page 6-13)
- 4. If it is not balanced, repeat steps 2. 3.

Balancing of Rotary Knife



A Caution

The rotary knife is an edged tool. Take extra care in handling since they could cut your hands or legs.



Caution

When touching edged tools, wear gloves, since they could cut your hands.


Important

Using an imbalanced rotary knife will cause vibrations, resulting in damage to the machine.

When the rotary knife is worn asymmetrically, causing vibrations, or when it becomes dull or worn, remove the rotary knife from the mower deck and balance it.

Follow the steps below to balance the rotary knife.

- 1. Remove the rotary knife from the mower deck.
 - "Change of Rotary Knife" (Page 6-8)
- 2. Install the balancer equipment in an appropriate location.
- 3. Fit the hole at the center of the rotary knife onto the balancer equipment, and then balance the left and right ends so that the rotary knife is level.




Balancing of Rotary Knife_001

1	Balancer equipment
2	Rotary knife
Α	Level

Replacement of Tires

Replacement of Front Tires

- 1. Removing front tires Follow the steps below to remove the front
 - [1] Loosen the bolts.



Replacement of Front Tires_001

1	Front tire
2	Bolt

- [2] Securely place the jack beneath the jackup point of the front left/right frame area, and then raise it until the tire lifts off the ground.
 - "Jack-Up Points" (Page 6-2)
- [3] Remove the bolts.
- [4] Remove the tire from the wheel mounting seat.
- 2. Installing front tires

Important

Tighten the bolts in the tightening order (crosswise).

Important


Tighten the wheel mounting bolts on the specified torque by using a torque wrench.

> For installing the front tires, reverse the removing procedure.

Replacement of Rear Tire

 Removing rear tires
 Follow the steps below to remove the rear
 tire.

[1] Loosen the bolts.



Replacement of Rear Tire_001

1	Rear tire
2	Bolt

[2] Securely place the jack beneath the jackup point below the rear wheel motor, and then raise it until the tire lifts off the ground.

"Jack-Up Points" (Page 6-2)

- [3] Remove the bolts.
- [4] Remove the tire from the wheel mounting base.
- 2. Installing rear tires

Important

Tighten the bolts in the tightening order (diagonally).

Important

Tighten the wheel mounting bolts on the specified torque by using a torque wrench.

For installing the rear tire, reverse the removing procedure.

Adjustment of Belt Tension



Be sure to stop the engine before adjusting the belts.

Important

For the specified value of belt tension, refer to Adjusted Values.

Before making sure of belt tension, rotate the belt several times.

Adjustment of Fan Belt



Be sure to stop the engine before inspecting or adjusting the fan belt.

▲ Warning

If a cover is removed due to inspection or adjustment, be sure to reinstall it in its original location.

Important


A slacking or damaged fan belt will cause overheating or lack of battery charge. Adjust or replace the belt.

For fan belt adjustment, follow either of the methods below.

- Adjustment on the basis of belt slack deviation when applying a specified load to a specified place
 - [1] Press the middle of the belt with your finger to check the belt tension.

 The belt tension is appropriate when the belt slacks by approximately 10.0 12.0 mm (0.39 0.47 in) when you apply a force of 98 N (10 kgf) to the belt at the middle point between the pulleys.
 - [2] If the belt tension is inappropriate, loosen bolts A and B for securing the alternator, and then move the alternator to adjust the tension.

[3] Be sure to tighten the bolts A and B securely after adjustment.



Adjustment of Fan Belt_001

1	Fan belt
2	Blade
3	Alternator
4	Bolt A
5	Bolt B
Α	10.0 - 12.0 mm (0.39 - 0.47 in)

2. Adjustment to suitable belt tension force by using sonic type tension meters at a specified point

Important

Perform correct measurement in accordance with the operations manual of the equipment being used for tension measurement.

Important

Perform measurement immediately after mounting the belt, when the pulley is not rotating.


[1] Measure belt tension force by using a sonic type tension meter.

For measurement position and distance between pulleys, see diagram below. Here is the suitable belt tension force.

Adjustment	237 - 403 N	
Replacement	460 - 680 N	

[2] If the belt tension is inappropriate, loosen bolts A and B for securing the alternator, and then move the alternator to adjust the tension.

[3] Be sure to tighten the bolts A and B securely after adjustment.



Adjustment of Fan Belt_002

1	Fan belt
2	Blade
3	Alternator
4	Bolt A
5	Bolt B
Α	Measurement position
В	Distance between pulleys

Change of Coolant



A Caution

Do not touch the radiator or coolant during engine operation or immediately after the engine has been turned off. Otherwise, you may get burned.



Change coolant after the engine has well cooled down.



The radiator cap is pressurized.

If you remove the radiator cap while the engine is overheated, hot steam will burst out, possibly resulting in burns.

Make sure that the water temperature and pressure are reduced, and then grab the cap with a thick cloth and gradually open the cap.

Important

When changing the coolant, be sure to drain it into a container and discard it in accordance with local laws and regulations.

Important

When changing the coolant, be sure to mix clean water and antifreeze (long-life coolant), and then pour it into the radiator and reserve tank.

Important

Tightly close the radiator cap.


If the cap is loose or incorrectly installed, the engine will be overheated due to water leakage, resulting in engine damage.

When mixing antifreeze and clean water, refer to "Relationship between concentration of long-life coolant (LLC) and freezing temperature" below for the mixing ratio.

Relationship between concentration of long-life coolant (LLC) and freezing temperature

Freezing temperature	LLC concentration (volume %)
Down to -10 °C (14 °F)	20 %
Down to -15 °C (5 °F)	30 %
Down to -20 °C (-4 °F)	35 %
Down to -25 °C (-13 °F)	40 %


- 1. Stop the engine, and then allow the radiator to cool.
- Open the hood.
- 3. Follow the steps below to drain the coolant.
- [1] Position a container to drain the coolant into.
- [2] Remove the drain plug from the radiator.



Change of Coolant_001

1 Radiator drain plug


[3] Remove the radiator cap.



Change of Coolant_002

1 Radiator cap

[4] Remove the reserve tank.



Change of Coolant_003

1	Reserve tank
2	Reserve tank cap

- [5] Open the reserve tank cap, and then drain the coolant.
- 4. Install the reserve tank.
- 5. Clean the radiator with clean water to remove any debris or rust.
- 6. Drain all water from the radiator.
- 7. Follow the steps below to fill with coolant. The coolant quantity, including the reserve tank, is 12.0 dm³ (12.0 L).
 - [1] Install the drain plug.
 - [2] Supply clean water and antifreeze into the radiator up to the radiator cap opening.
 - [3] Close the radiator cap.
 - [4] Supply clean water and antifreeze into the reserve tank up to the "FULL" mark.
 - [5] Close the reserve tank cap.
- 8. Start the engine, and then idle for several minutes to bleed air from the system.
- 9. Stop the engine, and then allow the radiator to cool.
- 10. Check if the coolant level in the reserve tank is between "FULL" and "LOW", and then supply coolant if necessary.
- 11. Close the hood.

Change of Hydraulic Oil



Be careful with hot oil, which could cause burns if it contacts your skin.

Important

When you change the hydraulic oil, be sure to drain it into a bowl and discard it in accordance with local laws and regulations.

Important

If the oil emulsifies or if it becomes even slightly less transparent, change the oil immediately.

Important

Use Shell Tellus S2M46 (or equivalent) as hydraulic oil.

In case of an equivalent, consult Characteristics of Hydraulic Oil and use hydraulic oil whose characteristics are superior to those of the specific hydraulic oil. Especially regarding kinematic viscosity and viscosity index, use of hydraulic oil whose figures are less than those of the specified hydraulic oil will cause a malfunction in the hydraulic circuit.


Note:

Characteristics of Hydraulic Oil

Specified Hydraulic Oil		Shell Tellus S2M46
ISO Viscosity Grade		ISO VG46
David	15 °C (59 °F)	0.873 g/cm ³
Density		(0.0315 lb/in ³)
API Gravity	API Gravity	
Flash Point (Open Cup)		230 °C (446 °F)
Pour Point	Pour Point	
Kinematic	40 °C (104 °F)	46 mm ² /s (46 cSt)
Viscosity	100 °C (212 °F)	7 mm ² /s (7 cSt)
Viscosity Index		109

- 1. Follow the steps below to remove the old oil.
 - [1] Start and run the engine to warm up the oil.
 - [2] On a level surface, lower the mower decks, and then stop the engine.
 - [3] Remove the drain plug of the hydraulic tank, and then drain the old oil into a container.


[4] Wind new sealing tape on the drain plug, and then attach it to the hydraulic tank.



Change of Hydraulic Oil_001

1	Hydraulic tank
2	Drain plug

- Remove the left tank cover.
- 3. Open the tank cap, and then pour new oil from the fill port until the oil level reaches the middle of the oil gauge on the hydraulic tank. The hydraulic tank capacity is approximately 44.0 dm3 (44.0 L).



Change of Hydraulic Oil_002

1	Tank cap
2	Oil gauge

- 4. Tighten the tank cap securely.
- 5. Start the engine, raise and lower the mower decks, and turn the steering wheel left and
 - Move forward and reverse repeatedly several times.
- 6. Lower the mower decks and maintain that position on a level surface, and then check to see if the oil level is at the middle of the oil gauge. If necessary, supply oil.
- 7. Check underneath the machine for oil leakage.
- 8. Attach the left tank cover.

Change of Hydraulic Oil Filter

Change of Hydraulic Oil Line Filter



A Caution

Be careful with hot oil, which could cause burns if it contacts your skin.

Important

When replacing the hydraulic oil filter, be sure to drain the oil into a container and discard it in accordance with local laws and regulations.


Important

If the hydraulic oil emulsifies or if it becomes even slightly less transparent, change the oil immediately.

Important

Use Shell Tellus S2M46 (or equivalent) as hydraulic oil.

- 1. On a level surface, lower the mower decks, and then stop the engine.
- Remove the filter protection plate.




Change of Hydraulic Oil Line Filter_001

1	Filter cartridge
2	Filter protection plate
3	Bolt

- Loosen the old filter cartridge by hand and remove it.
- 4. Lightly coat the packing of the new filter cartridge with hydraulic oil, and then install the cartridge.

5. Firmly tighten the filter cartridge by hand until the packing contacts the mounting surface.

And then tighten it with a half more turn.



Change of Hydraulic Oil Line Filter_002

Filter cartridge

- 6. Supply hydraulic oil until it reaches the specified level.
 - "Hydraulic Oil Supply" (Page 5-7)
- 7. Start the engine and stop it after hydraulic oil warmed.
- 8. Check underneath the machine for hydraulic oil leakage.
- 9. Install the filter protection plate.

Change of Hydraulic Oil Suction Filter



Be careful with hot oil, which could cause burns if it contacts your skin.

Important

When replacing the hydraulic oil filter, be sure to drain the oil into a container and discard it in accordance with local laws and regulations.

Important

If the hydraulic oil emulsifies or if it becomes even slightly less transparent, change the oil immediately.


Important

Use Shell Tellus S2M46 (or equivalent) as hydraulic oil.

Important

Replace the intake port packing with a new one.

- 1. On a level surface, lower the mower decks, and then stop the engine.
- 2. Remove the left tank cover.
- 3. Remove bolts, spring washers and washers, and then remove the intake hose joint fitting.
- 4. Remove the old suction filter and intake port packing.
- 5. Remove all of the old liquid gasket from the hydraulic tank.
- 6. Remove all of the old liquid gasket and the intake port packing from the intake hose joint fitting.
- 7. Wash and clean the intake hose joint fitting.
- 8. Apply liquid gasket to the new intake port packing and then install it to the intake hose joint fitting.
- 9. Install the new suction filter to the intake hose joint fitting.
- 10. Install the intake hose joint fitting to the hydraulic tank.



Change of Hydraulic Oil Suction Filter_001

-	_
1	Suction filter
2	Intake hose joint fitting
3	Bolt
4	Spring washer
5	Washer
6	Intake port packing
7	Hydraulic tank

- 11. Supply hydraulic oil until it reaches the specified level.
 - "Hydraulic Oil Supply" (Page 5-7)
- 12. Start the engine and stop it after hydraulic oil warmed.

- 13. Check underneath the machine for hydraulic oil leakage.
- 14. Install the left tank cover.

Change of Air Cleaner Element

Important

A contaminated air cleaner element may cause malfunction of the engine.

- 1. The timing for replacing the air cleaner element is described below.
 - [1] Replace the air cleaner element in accordance with the Maintenance
 - [2] If it is significantly contaminated, replace it, even if the hours of operation do not exceed the specified time.
- 2. Replace the air cleaner element by following the same steps as for cleaning the air cleaner.
 - "Cleaning of Air Cleaner Element" (Page 5-8)

Change of Engine Oil



A Caution

Be careful with hot oil, which could cause burns if it contacts your skin.

Important

When you change the engine oil, be sure to drain it into a bowl and discard it in accordance with local laws and regulations.

Important


Be sure to use engine oil that is classified as JASO DH-2 or API Service Grade CJ-4, with SAE viscosity that is appropriate for the operating environment (ambient temperature).

Important

Securely screw in the oil level gauge and oil filler cap.

Change the engine oil more frequently if the engine oil is contaminated, or if you use the machine in dusty areas or operate the engine at high loads or in high temperatures.


- 1. Move the machine onto a level surface, stop the engine, remove the drain plug while the engine oil is warm, and then drain the oil into a bowl.
- Replace the drain plug in the engine.



Change of Engine Oil_001

Drain plug

- 3. Through the oil filling port, supply new engine oil until the oil reaches a level in between the upper and lower limit lines on the oil level gauge. Engine oil quantity is approximately 9.7 dm³ (9.7 L).
- 4. Replace the oil filler cap.



Change of Engine Oil_002

Oil filler cap

- 5. It will take a while for the supplied engine oil to descend into the oil pan. Check the oil level again 10 to 20 minutes after supplying the oil.
- 6. Check underneath the machine for oil leakage.

Replacement of Engine Oil Filter



Caution

Be careful with hot oil, which could cause burns if it contacts your skin.

Important

When replacing the engine oil filter, be sure to drain the engine oil into a container and discard it in accordance with local laws and regulations.


Important

Be sure to use engine oil that is classified as JASO DH-2 or API Service Grade CJ-4, with SAE Viscosity that is appropriate for the operating environment (ambient temperature).

Important

Securely tighten the oil level gauge and oil filler cap.

1. With the filter wrench, remove the old filter cartridge.



Replacement of Engine Oil Filter_001

Filter cartridge

- 2. Lightly coat the packing of the new filter cartridge with engine oil.
- 3. Hand-tighten the filter cartridge until the packing contacts the sealing surface, and then firmly hand-tighten (without using a filter wrench).
- 4. Supply engine oil until it reaches the specified level.
 - "Supply of Engine Oil" (Page 5-13)
- 5. Start the engine, and then stop it after 10 to 20 minutes.

- 6. Make sure that there is no oil leakage at the sealing surface of the filter cartridge.
- 7. Check the engine oil level. If it is low, supply engine oil until it reaches the specified level.

Replacement of Fuel Filter

Important


During installation, prevent contamination with dirt or dust.

If the fuel is contaminated with dirt, dust, etc., the fuel injection pump and injection nozzle will become worn.

Since the fuel filter is a cartridge, it cannot be disassembled or cleaned.

If dust or dirt accumulates in the fuel filter, the fuel flow will become insufficient.

Replace the fuel filter at the appropriate times.




Replacement of Fuel Filter_001

Fuel filter

- 1. Follow the steps below to replace the fuel
 - [1] Using a filter wrench, remove the fuel filter cartridge.

[2] Lightly coat the packing of the new cartridge with fuel, and then firmly hand-tighten the cartridge, without using the filter wrench.



Replacement of Fuel Filter_002

	_
1	Cartridge
2	Packing
3	Cover
4	Air-bleeding plug
5	O-ring

2. Remove air after replacement.

Storage

Long-Term Storage

Follow the instructions below for long-term storage of the machine.

- 1. Cleaning
 - Remove dirt, grass clippings, oil stains etc. completely from the main vehicle and engine.
- 2. Replacing oil
 - Inspect and replace the engine oil, hydraulic oil and element.
- 3. Greasing and lubricating
 - Supply oil and apply grease to appropriate parts.
- 4. Battery
 - · Remove the negative battery wire.
- 5. Fuel
 - · Remove the fuel from the fuel tank.
- 6. Tire pneumatic pressure
 - Set the tire air pressure slightly higher than normal, and then place the machine on a board to avoid humidity.
- 7. Mower decks
 - When storing this machine, lower all the mower decks unless a positive mechanical lock is provided.

8. Storage location

· Cover the machine and store it in a dry place where it will not be exposed to rain.

Page 6-22 Storage

Precautions for RepairPage 7-			
Adjustment and Replacement	Page 7-2		
Adjustment of Brake	Page 7-2		
Adjusting the Neutral Position of the Piston Pump	Page 7-4		
Change of Fuse	Page 7-4		
Towing	Page 7-5		
Towing The Machine in An Emergency	Page 7-5		

Repair

Precautions for Repair



The chapter "Repair" in this manual describes practical measures which should be performed by a mechanic with expertise. The owner should instruct the mechanic with expertise to perform repair service for this machine.



First, learn well the operations you plan to perform.

Important

Use tools appropriate for each operation.

Important

Use Baroness genuine parts for replacement and accessories.

Our product warranty may be void if you use non-genuine parts for replacement or accessories.

Adjustment and Replacement

Adjustment of Brake



Make sure that the brake wire is not cracked or damaged.

Important


If the brake is not sufficiently effective due to a larger clearance between the brake disc and the pad, adjust the clearance.

The wire is used for fine adjustments.

Important

Adjust the brake with the brake pads.

The brake pad wear limit is 3.0 mm (0.12 in).




Adjustment of Brake_001

1	Brake disc
2	Brake pad

Important

Make sure that the lever is maintained in the open position (neutral).


1. For each wheel, fully tighten the adjustment bolt on the brake disc side.



Adjustment of Brake_002

1	Adjustment bolt (on brake disc side)
2	Lever
Α	Open (neutral)

 Reduce the clearance by loosening the lock nut, then tightening the adjustment nut.
 Tighten the adjustment nut until the friction material contacts the friction surface of the disc.




Adjustment of Brake_003

1	Brake disc
2	Wire
3	Adjustment nut
4	Lock nut

▲ Warning

A clearance between the brake disc and the pad that is too small may result in heat generation or fire.

- 3. Loosen the adjustment nut to adjust the clearance between the brake disc and the pad to about 0.2 mm (0.0079 in).
- 4. Securely place the jack beneath the jack-up point of the front left/right frame area, and then raise it until both tires lift off the ground.
- 5. Check that the disc rotates freely.
- 6. Tighten the lock nut, and then fully tighten it while holding the adjustment nut in place.
- 7. With the brake pedal released, obtain a play of 1.0 mm (0.039 in) at the connection of the inner wire.



Adjustment of Brake_004


1	Inner wire	
2	Adjustment bolt	
3	Lock nut	
4	Connection	
Α	1.0 mm (0.039 in)	

- 8. Use a wrench to loosen the lock nut and tighten it after making the adjustment with the adjustment bolt.
- 9. Drive, and then check the following.
 - Make sure that heat is not generated in the brake area.
 - Make sure that the left and right brakes are equally effective.

▲ Caution

It may result in an unexpected accident if the left and right brakes are not equally effective.

10. If the left and right brakes are not equally effective, make fine adjustments with the adjustment bolt on the brake wire.



Adjustment of Brake_005

Adjustment bolt (on brake disc side)

Break-In of Brakes

If the brake shoes or brake pads are worn, replace them with new ones.

Immediately after replacement, drive to break in the brakes if the effectiveness of the brakes is low.

While driving, lightly operate the brakes to break in the contact areas.

Repair

Adjusting the Neutral Position of the Piston Pump



Make sure not to touch rotating tires.




When adjusting the neutral position, pay close attention to abrupt start of the machine. Place the jacks beneath the jack-up points, and then lift the machine until all the tires get off the ground.

If the machine moves forward or backward while the traveling pedals are released, they are not set to the neutral position.

Follow the steps below to make adjustments.

- 1. Stop the engine.
- 2. Place the jacks beneath the jack-up points, and then lift the machine off the ground.
- 3. Make sure that no tires come into contact with the jack stand.
- Open the underseat cover.
 "Opening and Closing of Underseat Cover" (Page 5-3)
- Start the engine, and rev it up to the maximum rpm.
- 6. Set the 2WD/4WD selector switch to the "2WD" position.
- 7. Adjust the neutral position.
 - [1] If the front tires rotate forward, loosen the lock nuts, and then turn the neutral adjustment rod to shorten it.
 - [2] If the front tires rotate in reverse, loosen the lock nuts, and then turn the neutral adjustment rod to extend it.



Adjusting the Neutral Position of the Piston Pump_002

1	Lock nut A (Left-hand thread)
2	Neutral adjustment rod
3	Lock nut B (Right-hand thread)

8. Find the position where the front wheels stop, and then tighten the lock nuts.

Change of Fuse

Important

When performing maintenance on the electrical system, be sure to remove the negative battery wire.

Important

If a fuse blows, a short may have occurred within the electrical circuit.


Check for the cause, such as faulty terminal connections, damaged wiring or terminals, or incorrect wiring.

Important

For fuse replacement, clean the fuse mounting area with use of compressed air before mounting the fuse.

Fuse Box


The fuse box includes spare fuses and tools.



Fuse Box_001

The machine uses a mini fuse for automobiles.

Replace an old fuse with a new fuse of the specified capacity.




Fuse Box 002

		Fuse Box_002
Α	5 A	ECU_KeySwitch_ON
В	5 A	Alternator
С	5 A	Display
D	45.0	Relay box 1(differential lock switch, assist
D	15 A	switch)
E	15 A	Relay box 2 (2WD/4WD selector switch, #4/#5
	15 A	proximity switches)
F	-	-
G	5 A	ECU_KeySwitch_Start
Н	5 A	ECU_Parked Regeneration Switch/Auto
Н		Regeneration Inhibit Switch
I	5 A	Operating oil buzzer
J	5 A	Water temperature buzzer
K	5 A	
L	5 A	San area
M	15 A	Spare
N	15 A	
0	Fuse	removal tool

Fusible Link

Fuse capacities of the fusible links are 30 A and 50 A.



Fusible Link_001

1	Fusible link (50 A)
2	Fusible link (30 A)

Towing

Towing The Machine in An Emergency

If the machine does not travel due to engine problems, etc., you can move it by towing it.



Before towing, check the brake is applied effectively.

▲ Caution

Before starting the engine, be sure to close the unload valves.

Important

Do not touch the unload valve except when towing the machine.

Important

When towing the machine, obey the following restrictions.

- · Speed: Do not travel at a speed more than 3.0 km/h.
- Time: Do not tow the machine for more than 3 minutes.

When towing the machine for more than 3 minutes, start the engine and circulate the hydraulic oil in the hydraulic circuit.

Therefore, do not tow the machine until restart the engine after completed repairs.


Obey the speed and the time restrictions to prevent damaging the pump or motor.

- 1. Stop the engine."Procedure to Stop Engine" (Page 5-21)
- 2. Apply the parking brake.
- 3. Chock the wheels.

Towing Page 7-5


Repair

4. Secure the machine with ropes. Front left side




Towing The Machine in An Emergency_001

Front right side



Towing The Machine in An Emergency_002


Rear side



Towing The Machine in An Emergency_003

- 5. Set the 2WD/4WD selector switch to the "2WD" position.
- Open the underseat cover.
 "Opening and Closing of Underseat Cover" (Page 5-3)

7. Turn the needle valve 90 degrees (so that it is vertical) located beside the hydraulic pump, to open the unload valve.



Towing The Machine in An Emergency 004

1 Needle valve

- 8. Close the underseat cover.
- 9. Remove the wheel stopper.
- 10. Depress the brake pedal to release the parking brake.



While towing, always keep your foot on the brake pedal and depress the brake pedal to stop at any time.

11. Tow the machine slowly.

Page 7-6 Towing

Tightening Torques	Page 8-2
Standard Tightening Torques Principal Tightening Torques	· ·
Maintenance Schedule	Page 8-7
Maintenance ScheduleList of Adjusted Value	· ·

Tightening Torques

Important

Refer to the Tightening Torque table. Note that the Baroness product warranty may not apply to defects caused by incorrect or overtorque tightening, etc.

Standard Tightening Torques

Bolts and Nuts

Important

A number of bolts are used in each part of this machine.

Be sure to re-tighten the bolts and nuts, because they may be loosened at the earlier stage of the use.

· As to the bolts and nuts without any special instruction, tighten them in appropriate tightening torque with proper tool.

Too much tightening may cause the looseness or damage of the screw.

• The strength of tightening is determined by types of screws, strength, the friction of thread face or base face and others.

The table below is for the galvanized or parkerized bolts.

In case that the strength of internal thread is weak, it is not applied.

· Do not use rusty or sand attached "screw."

Otherwise, it may cause insufficient tightening even if you apply the specified tightening torque. The friction of the screw face becomes higher and the tightening torque is canceled out by the friction, therefore sufficient tightening cannot be applied.

• If "screw" is wet by water or oil, do not tighten it with normal tightening torque.

If the screw is wet, the torque coefficient will get smaller and it may result in too much tightening.

Too much tightening may cause looseness by the screw stretched or result in damage.

Do not use a bolt experienced too much burden.

Using the impact wrench requires the skill.
 Do exercise as much as possible for steady tightening.

Page 8-2 Tightening Torques

	General bolt													
		Strength classification	n 4.8											
Nominal diameter		M 4 T												
	N-m	kgf-cm	lb-in											
M5	3 - 5	30.59 - 50.99	26.55 - 44.26											
M6	7 - 9	71.38 - 91.77	61.96 - 79.66											
M8	14 - 19													
M10	29 - 38	295.71 - 387.49	256.68 - 336.34											
M12	52 - 67	530.24 - 683.20	460.25 - 593.02											
M14	70 - 94	713.79 - 958.52	619.57 - 831.99											
M16	88 - 112	897.34 - 1142.06	778.89 - 991.31											
M18	116 - 144	1,182.85 - 1,468.37	1,026.72 - 1,274.54											
M20	147 - 183	1,498.96 - 1,866.05	1,301.10 - 1,619.73											
M22	295	295 3,008.12 2,611.05												
M24	370	3,772.89	3,274.87											
M27	550	5,608.35	4,868.05											
M30	740 7,545.78 6,549.74													

	Heat-treated bolt												
		Strength classificatio	n 8.8		Strength classificatio	n 10.9							
Nominal diameter		(8) (8T) (8.8 tib3yb-002	11 (11T) (10.9) tib3yb-003									
	N-m	kgf-cm	lb-in	N-m	kgf-cm	lb-in							
M5	5 - 7	50.99 - 71.38	44.26 - 61.96	7 - 10	71.38 - 101.97	61.96 - 88.51							
M6	8 - 11	81.58 - 112.17	70.81 - 97.36	14 - 18	142.76 - 183.55	123.91 - 159.32							
M8	23 - 29	234.53 - 295.71	203.57 - 256.68	28 - 38	285.52 - 387.49	247.83 - 336.34							
M10	45 - 57	458.87 - 581.23	398.30 - 504.51	58 - 76	591.43 - 774.97	513.36 - 672.68							
M12	67 - 85	683.20 - 866.75	593.02 - 752.34	104 - 134	1,060.49 - 1,366.40	920.50 - 1186.03							
M14	106 - 134	1,080.88 - 1,366.40	938.21 - 1,186.03	140 - 188	1,427.58 - 1,917.04	1,239.14 - 1,663.99							
M16	152 - 188	1,549.94 - 1,917.04	1,345.35 - 1,663.99	210 - 260	2,141.37 - 2,651.22	1,858.71 - 2,301.26							
M18	200 - 240	2,039.40 - 2,447.28	1,770.20 - 2,124.24	280 - 340	2,855.16 - 3,466.98	2,478.28 - 3,009.34							
M20	245 - 295	2,498.27 - 3,008.12	2,168.50 - 2,611.05	370 - 450	3,772.89 - 4,588.65	3,274.87 - 3,982.95							
M22	-	-	-	530	5,404.41	4,691.03							
M24	-	-	-	670	6,831.99	5,930.17							
M27	-	-	-	1,000	10,197.00	8,851.00							
M30	-	-	-	1,340 14,628.78 11,860.34									

Note:

The same values are applied to "fine screw thread."

Tightening Torques Page 8-3

Hydraulic Hose

The tightening torques for union joints and union adaptors with parallel pipe threads (G, PF) are shown in the table below.

A union joint or adaptor will not become loose or leak as long as it is tightened by the specified torque.

If fluid leaks from the sealed portion, do not attempt to tighten the union joint or adaptor forcibly. Examine whether any foreign matter or scratches are present on the seat surface.

Tightening a union joint or adaptor forcibly could damage the connection of the joints.

When tightening a union joint or adaptor, use a torque wrench where possible and firmly tighten it by an appropriate torque.

Nominal diameter of	Nominal diameter of	Ti	ghtening torq	ue
the hose size	the parallel pipe threads (G, PF)	N-m	kgf-cm	lb-in
6	1/4	24.50	250	221.28
9	3/8	49.03	500	564.91
12	1/2	58.84	600	677.89
15	3/4	117.68	1200	1,355.78
19	3/4	117.68	1200	1,355.78
25	1	137.30	1400	1,581.74
32	1-1/4	166.72	1700	1,920.69
38	1-1/2	205.94	2100	2,372.61
50	2	245.17	2500	2,824.54

Fittings with Parallel Threads (O-Ring Seal Type)

The tightening torques for fittings with parallel threads (O-ring seal method) are shown in the table below.

Tightening the fitting forcibly with a spanner or other such tool to secure it to a set position could damage the fitting, its washers, and other parts. Be sure to tighten the fitting to the torque appropriate to its size.

Nominal diameter		Tightening torque	е
of thread	N-m	kgf-cm	lb-in.
1/4	34.32 - 49.03	350 - 500	309.79 - 442.55
3/8	68.65 - 78.45	700 - 800	619.57 - 708.08
1/2	98.07 - 117.68	1000 - 1200	885.10 - 1,062.12
3/4	147.10 - 176.52	1500 - 1800	1,327.65 - 1,593.18
1	245.17 - 274.59	2500 - 2800	2,212.75 - 2,478.28
1-1/4	294.20	3000	2,655.30
1-1/2	294.20	3000	2,655.30
2	392.27	4000	3,540.40

Page 8-4 Tightening Torques

Principal Tightening Torques

Tightening Torque by Model

GM2810A

Tighten the following bolts and nuts at the torque specified in the table.

For thread locking adhesive, apply a middle strength thread locker (ThreeBond 1322 or equivalent anaerobic sealant).

Location Code Pa			Part name	Т	ightening to	Thread locking	
	LUCALIUII	Code	rait liaille	N-m	kgf-cm	lb-in	adhesive
	Motor housing	K0014160402	Bolt, heat-treated M16-40P1.5	152 - 188	1549.94 - 1917.04	1345.35 - 1663.99	_
	Motor	K0013140502	Bolt, heat-treated M14-50	100	1019.7	885.1	_
Front wheel	Wheel mounting base	1 1/4-18UNF	Slotted nut (Hydraulic motor)	400 - 430	4078.80 - 4384.71	3540.40 - 3805.93	_
Fro	Disc brake	K001A080401	Bolt, w/hexagon hole, M8-40	28 - 38	285.52 - 387.49	247.83 - 336.34	_
	Wheel	K0014120652	Bolt, heat-treated M12-65P1.5	110	1121.69	973.61	_
Rear wheel	Wheel mounting base	K0138240002	24 slotted nut high P1.5	180 - 200	1835.46 - 2039.40	1593.18 - 1770.20	_
Real	Wheel	K0014120652	Bolt, heat-treated M12-65P1.5	110	1121.69	973.61	_
Fror	nt axle	K0015200702	Bolt, heat-treated M20-70P1.5	370 - 450	3772.89 - 4588.65	3274.87 - 3982.95	_
Brak	ke ass'y	K1720000260 K1720000270	M12 nut (accessories)	50 - 70	509.85 - 713.79	442.55 - 619.57	0
		K0012120352	Bolt, heat-treated M12-35P1.25	67 - 85	683.20 - 866.75	593.02 - 752.34	_
		K0015120552	Bolt, heat-treated M12-55P1.25	67 - 85	683.20 - 866.75	593.02 - 752.34	_
Eng	ine	K0011100502	Bolt, heat-treated M10-50P1.25	58 - 76	591.43 - 774.97	513.36 - 672.68	_
		K0013121102	Bolt, heat-treated M12-110	67 - 85	683.20 - 866.75	593.02 - 752.34	_
		K3680000030	M3.5 Screw (accessories)	0.78 - 1.18	7.95 - 12.03	6.90 - 10.44	_
Ela-	trio	-	Starter B terminal (M8)	5.9 - 11.7	60.16 - 119.30	52.22 - 103.56	_
Elec com engi	ponents for	-	Alternator B terminal (M6)	5.9 - 9.8	60.16 - 99.93	52.22 - 86.74	_
crigi		-	Glow plug connection terminal nut (M4)	1.0 - 1.8	10.20 - 18.35	8.85 - 15.93	_
Elsa:	shool adapter	K0011100302	Bolt, heat-treated M10-30P1.25	58 - 76	591.43 - 774.97	513.36 - 672.68	_
Flywheel adapter K0010100352 Bolt, heat-treated M10-35				45 - 76	458.87 - 774.97	398.30 - 672.68	_

Tightening Torques Page 8-5

Location	Code	Dort name	Т	ightening to	rque	Thread locking
Location	Code	Part name	N-m	kgf-cm	lb-in	adhesive
la int	K001A100401	Bolt, w/hexagon hole, M10-40	80	815.76	708.08	0
Joint	K0013100352	Bolt, heat-treated M10-35	45 - 76	458.87 - 774.97	398.30 - 672.68	_
Kingpin stopper	K0010120502	Bolt, heat-treated M12-50	52 - 67	530.24 - 683.20	460.25 - 593.02	_
T:d	K1610000020	Slotted nut of tie rod end RH	45	458.87	398.30	_
Tie rod	K1611000020	Slotted nut of tie rod end LH	45	458.87	398.30	_
Piston pump	K0010120502	Bolt, heat-treated M12-50	67 - 134	683.20 - 1366.40	593.02 - 1186.03	_
Tandem gear pump	K0069000251	Bolt, 3/8-16 UNC 31.8	29 - 38	295.71 - 387.49	256.68 - 336.34	_
Pedal stopper	K0013101202	Bolt, heat-treated M10-120	29 - 38	295.71 - 387.49	256.68 - 336.34	_
Diff-lock valve	K001A100151	Bolt, w/hexagon hole, M10-15	29 - 38	295.71 - 387.49	256.68 - 336.34	_
Knife and knife guide	K0010120302	Bolt, heat-treated M12-30	104 - 134	1060.49 - 1366.40	920.50 - 1186.03	_
Shoulder bolt	GM2800-0207Z2	Shoulder bolt	67 - 134	683.20 - 1366.40	593.02 - 1186.03	_
Bumper	K0010120302	Bolt, heat-treated M12-30	67 - 134	683.20 - 1366.40	593.02 - 1186.03	_
Cover mounting bracket	K0000080202	Bolt, M8-20	9 - 14	91.77 - 142.76	61.96 - 123.91	
ROPS	K0013121102	Bolt, heat-treated M12-110	104 - 134	1060.49 - 1366.40	920.50 - 1186.03	_

Page 8-6 Tightening Torques

Maintenance Schedule

GM2810A

• · · Inspect, adjust, supply, clean (first time)

O - - Inspect, adjust, supply, clean

▲ · · · Replace (first time)

 $\triangle \cdot \cdot \cdot$ Replace

	Teplace																	
	Maintenance Item	Before Work	After Work	Every Week	Every 50 hrs.	Every 100 hrs.	Every 250 hrs.	Every 400 hrs.	Every 500 hrs.	Every 800 hrs.	Every 1500 hrs.	Every 3000 hrs.	Every month	Every year	Every 2 years	Every 4 years	When Required	Remarks
*4	Check engine oil level and contamination	0																
*4	Check fuel level	0																
*4	Check coolant level	0																
*4	Check fan belt	0																
	Check hydraulic oil	0																
	Check tire	0																
	Check rotary knife	0																
	Check roller	0																
	Check interlock system safety function	0																
	Check liquid leakage	0																
	Check cover	0																
	Check damaged parts	0																
	Check bolts and nuts	0																
	Check brake function	0																
	Check hydraulic hoses	0																
	Clean machine exterior		0															
	Clean engine area		0															
	Open air cleaner evacuator valve to remove dust		0	0														Open valve every week or daily in dusty conditions
	Clean radiator core		0															
	Clean oil cooler core		0															
*4	Check fuel hoses and clamp bands				0													
*4	Draining of water separator				0													
	Grease and Lubricate				0													
	Grease rear mower deck swing out pins				0													
	Check and Adjust brakes				0													
	Check wheel mounting bolts				•	0												

Maintenance Schedule Page 8-7

	Maintenance Item	Before Work	After Work	Every Week	Every 50 hrs.	Every 100 hrs.	Every 250 hrs.	Every 400 hrs.	Every 500 hrs.	Every 800 hrs.	Every 1500 hrs.	Every 3000 hrs.	Every month	Every year	Every 2 years	Every 4 years	When Required	Remarks
*4	Clean air cleaner outer element (Replace the element after 6-time cleaning)					0								Δ				Replace every 6 cleanings or every year whichever comes earlier Air cleaner should be cleaned more often in dusty
																		conditions than in normal conditions
	Replace hydraulic oil								Δ									
	Replace hydraulic oil filter					A			Δ									
*5	Check exterior of battery					0							0					Every 100 hours or every month whichever comes earlier
*5	Clean exterior of battery					0							0					Every 100 hours or every month whichever comes earlier
*5	Check mounting bracket of battery					0							0					Every 100 hours or every month whichever comes earlier
*5	Check looseness and corrosion of battery terminals					0							0					Every 100 hours or every month whichever comes earlier
*5	Check battery fluid level					0							0					Every 100 hours or every month whichever comes earlier
*4	Adjust fan belt tension					0												
*4	Check radiator hoses and clamp bands						0											
*4	Check intake air line (air cleaner hose)						0							0				Every 250 hours or every year whichever comes earlier
*4	Replace engine oil				A			Δ						Δ				Initial 50 hours, thereafter every 400 hours or every year whichever comes earlier

Page 8-8 Maintenance Schedule

	Maintenance Item	Before Work	After Work	Every Week	Every 50 hrs.	Every 100 hrs.	Every 250 hrs.	Every 400 hrs.	Every 500 hrs.	Every 800 hrs.	Every 1500 hrs.	Every 3000 hrs.	Every month	Every year	Every 2 years	Every 4 years	When Required	Remarks
*4	Replace oil filter cartridge				•			Δ						Δ				Initial 50 hours, thereafter every 400 hours or every year whichever comes earlier
*1.*4	Replace fuel filter cartridge							Δ										
*4	Clean water separator								0									
*2.*4	Clean fuel tank interior								0									
*2.*4	Clean water jacket and radiator interior								0									
*2.*4	Replace fan belt								Δ						Δ			Every 500 hours or 2 years whichever comes earlier
	Replace hydraulic suction filter								Δ									
*2.*4	Check valve clearance									0								
*2.*3.* 4	Check injector										0							
*2.*3.* 4	Check EGR cooler										0							
*3.*4	Replace oil separator element										Δ							
*2.*3.* 4	Check PCV (Positive Crankcase Ventilation) Valve in the oil separator body										0							
*2.*3.* 4	Check turbocharger											0						
*2.*3.* 4	Replace DPF filters											Δ						
*2.*3.* 4	Check EGR system											0						
	Check electrical wiring													0				
*2.*4	Replace air cleaner inner element													Δ				The secondary (inner) element should be removed only if it is to be replaced.
*2.*4	Check DPF differential pressure pipes and hoses													0				
*2.*4	Check EGR piping													0				

Maintenance Schedule Page 8-9

	Maintenance Item	Before Work	After Work	Every Week	Every 50 hrs.	Every 100 hrs.	Every 250 hrs.	Every 400 hrs.	Every 500 hrs.	Every 800 hrs.	Every 1500 hrs.	Every 3000 hrs.	Every month	Every year	Every 2 years	Every 4 years	When Required	Remarks
*4	Check exhaust manifold (Crack, gas leakage and mounting screw)													0				
*2.*4	Replace oil separator rubber hose														Δ			
*2.*4	Replace rubber hose of DPF differential pressure sensor														Δ			
*2.*4	Replace intake hose (After air flow sensor) and inter cooler hose														Δ			
*2.*4	Replace rubber hose of boost pressure sensor														Δ			
*2.*4	Replace EGR cooler hose														Δ			
*2.*4	Replace water hose														Δ			
*2.*4	Replace lubricant hose														Δ			
*4	Replace radiator coolant (L.L.C.)														Δ			
*2.*4	Replace radiator hoses and clamp bands														Δ			
*1.*2.* 4	Replace fuel hoses and clamps														Δ			
*2.*4	Replace intake air line (air cleaner hose)														Δ			
	Replace hydraulic hoses (Moving part)														Δ			
*6	Replace hydraulic hoses (Moving part) relating to steering														Δ			
	Replace hydraulic hoses (Fixed part)															Δ		
	Replace brake pads																Δ	
	Replace brake cables																Δ	
	Sharpen and balance rotary knife																0	Sharpen/Balance/ Replace rotary knife if needed.
*5	Replace battery																Δ	

^{• *1:} When biodiesel fuel is used, replace the fuel filter cartridge, fuel hose and clamp bands with new ones at intervals half of the usual ones.

Page 8-10 Maintenance Schedule

^{· *2:} Consult your local Baroness Dealer or local KUBOTA Dealer for this service.

• The items above (*3 marked) are registered as emission related critical parts by KUBOTA in the U.S. EPA nonroad emission regulation.

As the engine owner, you are responsible for the performance of the required maintenance on the engine according to the above instruction.

Please see the Engine's Warranty Statement in detail.

- · *4: Refer to the Engine's Owner's Manual.
- · *5: Refer to the Battery's Owner's Manual.
- · The values for consumables are not guaranteed.
- *6: Be sure to replace hydraulic hoses for steering cylinder and hydraulic hoses for hydraulic motor of wheel relating to steering every two years.

List of Adjusted Value

E. Luli	10.0 - 12.0 mm (0.39 - 0.47 in)	Slack when applying 98 N (10 kgf) force to the belt at the middle point
Fan belt	Adjustment: 237 - 403 N Replacement: 460 - 680 N	Measurement of belt tension by using a sonic type tension meter
Brake	0.2 mm (0.0079 in)	Clearance between the brake disc and the pad
	1.0 mm (0.039 in)	Play at the connection of the inner wire

List of Adjusted Value Page 8-11

List of Fault Codes

(03series Stage V)

Important

When the fault code appears in the monitor display, refer to "Kubota DIAGNOSIS MANUAL COMMON RAIL SYSTEM" or contact your dealer.

The fault codes (DTC) and corresponding information that appear in the monitor display are listed below.

No	DTC name	Corrective action	ISO 14229	J1939	-73	Datastian item	Behavior During	DPF recovery from
No.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	Malfunction	error
1	NE-G phase shift	See Service Manual	P0016	636	7	Large phase shift between NE pulse and G pulse	(Invalid G signal) • Engine hesitates at start-up	Diagnostic counter=zero (returns when error is resolved) or Key switch turn OFF
2	Pressure limiter emergency open	See Service Manual	P0087	633	7	Pressure limiter emergency open	Insufficient outputWorsening exhaust gas performance	Key switch turn OFF
3	High rail pressure	See Service Manual	P0088	157	0	Actual pressure exceeds the command pressure	Insufficient outputWorsening exhaust gas performance	Key switch turn OFF
4	SCV stuck	See Service Manual	P0089	1347	7	SCV stuck at open position (Actual rail pressure continuously exceeds the command rail pressure)	 Insufficient output Worsening exhaust gas performance Engine stops in some case 	Key switch turn OFF
5	Fuel leak (in high pressured fuel system)	Stop ENG See Service Manual	P0093	1239	1	Lack of fuel (This error occurs when the engine stalls due to lack of fuel and air gets mixed in the fuel line) Fuel leak from high pressured fuel system (Fuel consumption is calculated from the difference of fuel pressure of before and after the injection, and the error will be detected when excess fuel consumption is found)	Insufficient output Worsening exhaust gas performance Engine stops in some case	Key switch turn OFF
6	Intake air temp. error: Low	See Service Manual	P0112	172	4	Ground short circuit of sensor/harness	Amount of white smoke increases at low temperatures	Diagnostic counter = zero

Page 8-12 List of Fault Codes

NI.	DTC name	Corrective action	ISO 14229	J1939	-73	Dotostion it	Behavior During	DPF recovery from
No.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	Malfunction	error
7	Intake air temp. error: High	See Service Manual	P0113	172	3	Open circuit or +B short circuit of sensor/ harness	Amount of white smoke increases at low temperatures	Diagnostic counter = zero
8	Coolant temperature sensor Abnormality: Low	See Service Manual	P0117	110	4	Ground short circuit of sensor/harness	Amount of white smoke increases at low temperatures Insufficient output Worsening exhaust gas performance	Key switch turn OFF
9	Coolant temperature sensor Abnormality: High	See Service Manual	P0118	110	3	Open circuit or +B short circuit of sensor/ harness	Amount of white smoke increases at low temperatures Insufficient output Worsening exhaust gas performance	Key switch turn OFF
10	Rail pressure sensor Abnormality: Low	Stop ENG See Service Manual	P0192	157	4	Ground short circuit of sensor/harness Failure of sensor	Insufficient output Worsening exhaust gas performance Worsening running noise Increase in white smoke Engine stops	Key switch turn OFF
11	Rail pressure sensor Abnormality: High	Stop ENG See Service Manual	P0193	157	3	Open circuit or +B short circuit of sensor/ harness. Failure of sensor	Insufficient output Worsening exhaust gas performance Worsening running noise Increase in white smoke Engine stops	Key switch turn OFF
12	Injector charge voltage Abnormality: High	Stop ENG See Service Manual	P0200	523535	0	Injector charge voltage: High	Insufficient output Worsening exhaust gas performance Engine stops	Key switch turn OFF
13	Open circuit of harness or coil in 1st cylinder injector	See Service Manual	P0201	651	3	Open circuit of harness Open circuit of injector coil	Insufficient output Large vibration Worsening exhaust gas performance	Key switch turn OFF
14	Open circuit of harness or coil in 3rd cylinder injector	See Service Manual	P0202	653	3	Open circuit of harness	Insufficient outputLarge vibrationWorsening exhaust gas performance	Key switch turn OFF
15	Open circuit of harness or coil in 4th cylinder injector	See Service Manual	P0203	654	3	Open circuit of injector coil	Insufficient output Large vibration Worsening exhaust gas performance	Key switch turn OFF

List of Fault Codes Page 8-13

No.	DTC name	Corrective action	ISO 14229	J1939		Detection item	Behavior During	DPF recovery from
16	Text 1 Open circuit of harness or coil in 2nd cylinder injector	Text 2 See Service Manual	P-Code P0204	SPN 652	3	Open circuit of harness	Malfunction Insufficient output Large vibration Worsening exhaust gas performance	error Key switch turn OFF
17	Engine overheat	Stop mowing!!	P0217	110	0	Overheat of engine coolant temperature	Insufficient output Overheat	Diagnostic counter = zero
18	Engine overrun	See Service Manual	P0219	190	0	Engine speed exceeds threshold speed	Overrun	Diagnostic counter = zero
19	Boost pressure sensor Abnormality: Low	See Service Manual	P0237	102	4	Ground short circuit of sensor/harness Failure of sensor	Insufficient output	Key switch turn OFF
20	Boost pressure sensor Abnormality: High	See Service Manual	P0238	102	3	Open circuit or +B short circuit of sensor/ harness Failure of sensor	Insufficient output	Key switch turn OFF
21	No input of NE sensor pulse	See Service Manual	P0335	636	8	Open circuit or short circuit of sensor/ harness Failure of sensor	(Running only with G signal) Faulty starting Vibration is slightly large Insufficient output	Diagnostic counter = zero
22	NE sensor pulse number error	See Service Manual	P0336	636	2	Open circuit or short circuit of sensor/ harness Failure of sensor	(Running only with G signal) Faulty starting Vibration is slightly large Insufficient output	Diagnostic counter = zero
23	No input of G sensor pulse	See Service Manual	P0340	723	8	Open circuit or short circuit of sensor/ harness Failure of sensor	(Invalid G signal) • Engine hesitates at start-up	Diagnostic counter = zero
24	G-sensor pulse number error	See Service Manual	P0341	723	2	Open circuit or short circuit of sensor/ harness Failure of sensor	(Invalid G signal) • Engine hesitates at start-up	Diagnostic counter = zero
25	Open circuit of glow relay driving circuit	See Service Manual	P0380	676	5	Open circuit of air glow relay	(At low temperature) • Faulty starting • Increase in white Smoke	Key switch turn OFF
26	+B short of glow relay driving circuit	See Service Manual	P0380	523544	3	+B short of glow relay driving circut	(At low temperature) • Faulty starting • Increase in white smoke	Key switch turn OFF

Page 8-14 List of Fault Codes

No.	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior During	DPF recovery from
140.	Text 1	Text 2	P-Code	SPN	FMI	Detection tem	Malfunction	error
27	Ground short of glow relay driving circuit	See Service Manual	P0380	523544	4	Ground short of air glow relay driving circuit	(At low temperature) • Faulty starting • Increase in white smoke	Key switch turn OFF
28	Glow heater relay driving circuit overheat	See Service Manual	P0381	676	0	Overheat of glow plug driving circuit	(At low temperature) • Faulty starting • Increase in white smoke	Key switch turn OFF
29	Oil pressure error	Stop ENG See Service Manual	P0524	100	1	Oil pressure switch	• Engine stops	Key switch turn OFF
30	Battery voltage Abnormality: Low	Stop ENG See Service Manual	P0562	168	4	Open circuit, short circuit or damage of harness Failure of battery	 Faulty starting Insufficient output Worsening exhaust gas performance Engine stops in some case 	Diagnostic counter = zero
31	Battery voltage Abnormality: High	See Service Manual	P0563	168	3	Open circuit, short circuit or damage of harness Failure of battery	Faulty startingInsufficient outputWorsening exhaust gas performance	Key switch turn OFF
32	QR (IQA) data error	Contact dealer	P0602	523538	2	QR data read error	Insufficient output	Diagnostic counter = zero Key switch turn OFF
33	No QR (IQA) data	Contact dealer	P0602	523538	7	QR data is unwritten	Insufficient output	Diagnostic counter = zero Key switch turn OFF
34	ECU FLASH ROM error	Stop ENG See Service Manual	P0605	628	2	FLASH ROM error	Engine stops	Key switch turn OFF
35	ECU CPU (Main IC) error	Stop ENG See Service Manual	P0606	1077	2	Failure of CPF and/or	Engine stops	Key switch turn OFF
36	ECU CPU (Monitoring IC) error	Stop ENG See Service Manual	P0606	523527	2	Failure of monitoring IC of CPU	Engine stops	Key switch turn OFF
37	Injector charge voltage Abnormality: Low	Stop ENG See Service Manual	P0611	523525	1	Injector charge voltage: Low Failure of charge circuit of ECU	Insufficient outputWorsening exhaust gas performanceEngine stops	Key switch turn OFF
38	Open circuit of SCV	Stop ENG See Service Manual	P0627	1347	5	Open circuit of SCV	Insufficient outputWorsening exhaust gas performance	Key switch turn OFF
39	SCV (MPROP) drive system error	Stop ENG See Service Manual	P0628	1347	4	Open circuit or ground short circuit of SCV	Insufficient outputWorsening exhaust gas performance	Key switch turn OFF

List of Fault Codes Page 8-15

No.	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior During	DPF recovery from
140.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	Malfunction	error
40	+B short circuit of SCV (MPROP)	Stop ENG See Service Manual	P0629	1347	3	+B short circuit of SCV	Insufficient outputWorsening exhaust gas performance	Key switch turn OFF
41	Injector drive IC error or Open circuit	Stop ENG See Service Manual	P062B	1077	12	Injector drive IC error or Open circuit of No.1 and 4 cylinder injector or Open circuit of No.2 and 3 cylinder injector	• Engine Stop	Key switch turn OFF
42	Internal injector drive circuit short	See Service Manual	P062D	523605	6	Short circuit in injector driver IC	 Insufficient output Large vibration Worsening exhaust gas performance Engine stops in some case 	Key switch turn OFF
43	Sensor supply voltage 1 Abnormality: Low	See Service Manual	P0642	3509	4	Sensor supply voltage 1 error or recognition error	Faulty startingInsufficient outputWorsening exhaust gas performanceEngine stops in some case	Key switch turn OFF
44	Sensor supply voltage 1 Abnormality: High	See Service Manual	P0643	3509	3	Sensor supply voltage 1 error or recognition error	 Faulty starting Insufficient output Worsening exhaust gas performance Engine stops in some case 	Key switch turn OFF
45	Sensor supply voltage 2 Abnormality: Low	See Service Manual	P0652	3510	4	Sensor supply voltage 2 error or recognition error	Faulty startingInsufficient outputWorsening exhaust gas performance	Key switch turn OFF
46	Sensor supply voltage 2 Abnormality: High	See Service Manual	P0653	3510	3	Sensor supply voltage 2 error or recognition error	Faulty startingInsufficient outputWorsening exhaust gas performance	Key switch turn OFF
47	Sensor supply voltage 3 Abnormality: Low	See Service Manual	P0662	3511	4	Sensor supply voltage 3 error or recognition error	Faulty starting	Key switch turn OFF
48	Sensor supply voltage 3 Abnormality: High	See Service Manual	P0663	3511	3	Sensor supply voltage 3 error or recognition error	Faulty starting	Key switch turn OFF
49	Main relay is locked in closed position	See Service Manual	P0687	1485	2	Failure of main relay	Dead battery	Key switch turn OFF
50	GND short of Starter relay driving circuit	See Service Manual	P081A	677	4	Ground short of starter relay driving circuit	• Faulty starting	Key switch turn OFF

Page 8-16 List of Fault Codes

No.	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior During	DPF recovery from
INO.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	Malfunction	error
51	Accelerator position sensor 1 Abnormality: Low	See Service Manual	P2122	91	4	Ground short circuit or open circuit of sensor/ harness	Insufficient output	Diagnostic counter = zero
52	Accelerator position sensor Abnormality1: High	See Service Manual	P2123	91	3	Battery short circuit out of sensor/harness	Insufficient output	Diagnostic counter = zero
53	Accelerator position sensor 2 Abnormality: Low	See Service Manual	P2127	29	4	Ground short circuit or open circuit of sensor/ harness	Insufficient output	Diagnostic counter = zero
54	Accelerator position sensor 2 Abnormality: High	See Service Manual	P2128	29	3	Battery short circuit out of sensor/harness	Insufficient output	Diagnostic counter = zero
55	Accelerator Position Sensor Error (CAN)	See Service Manual	P2131	523543	2	Accelerator position sensor signal error (sensor/harness open circuit, ground short circuit etc)	Insufficient output	Diagnostic counter = zero (CAN signal recovers)
56	No. 1 & 4 cylinder injector short to +B or GND	Stop ENG See Service Manual	P2148	523523	3	Wiring harness short to +B or Wiring harness short to ground	 Insufficient output Large vibration Worsening exhaust gas performance Engine stops in some case 	Key switch turn OFF
57	No. 2 & 3 cylinder injector short to +B or GND	Stop ENG See Service Manual	P2151	523524	3	Wiring harness short to +B or Wiring harness short to ground	 Insufficient output Large vibration Worsening exhaust gas performance Engine stops in some case 	Key switch turn OFF
58	Barometric pressure sensor error: Low	See Service Manual	P2228	108	4	Sensor/ECU internal circuit short to ground	Insufficient output	Diagnostic counter = zero
59	Barometric pressure sensor error: High	See Service Manual	P2229	108	3	Sensor/ECU internal circuit short to +B	Insufficient output	Diagnostic counter = zero
60	Pressure limiter not open	Stop ENG See Service Manual	P2293	679	7	Rail pressure value is sticking or too low engine power not to open PL valve forcibility	• Engine stop	Key switch turn OFF
61	Rail Pressure Sensor Abnormality After P/L Open	Stop ENG See Service Manual	P2293	679	16	Rail pressure value is too high or low despite the existence of response that the pressure limiter opened	• Engine stop	Key switch turn OFF

List of Fault Codes Page 8-17

No.	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior During	DPF recovery from
INO.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	Malfunction	error
62	CAN1 Bus off	See Service Manual	U0077	523604	2	CAN1 +B/GND short circuit or high traffic error	Insufficient outputTransmitted data is invalid	Key switch turn OFF
63	CAN2 Bus off	See Service Manual	U0075	523547	2	CAN2 +B/GND short circuit or high traffic error	Insufficient output Transmitted data is invalid	Key switch turn OFF
64	CAN-KBT Frame error	See Service Manual	U0081	523548	2	CAN-KBT original frame open circuit error	Insufficient output	Key switch turn OFF
65	Intake air temp. built-in MAF sensor Abnormality: Low	See Service Manual	P0072	171	4	Ground short circuit of sensor/harness	None	Diagnostic counter = zero
66	Intake air temp. built-in MAF sensor Abnormality: High	See Service Manual	P0073	171	3	Open circuit or +B short circuit of sensor/ harness	None	Diagnostic counter = zero
67	Intake air volume: Low	See Service Manual	P0101	132	1	Engine inlet air mass flow rate lacking (Disconnect turbo blower intake hose)	Insufficient output	Key switch turn OFF
68	MAF sensor: High	See Service Manual	P0103	132	3	+B short circuit of sensor/harness	Insufficient outputWorsening exhaust gas performance	Key switch turn OFF
69	EGR actuator open circuit	See Service Manual	P0403	523574	3	EGR actuator open circuit	Insufficient outputWorsening exhaust gas performance	Key switch turn OFF
70	EGR actuator coil short	See Service Manual	P0404	523574	4	EGR actuator coil short	Insufficient outputWorsening exhaust gas performance	Key switch turn OFF
71	EGR position sensor failure	See Service Manual	P0409	523572	4	EGR position sensor failure	Insufficient outputWorsening exhaust gas performance	Key switch turn OFF
72	Exhaust gas temperature sensor 1: Low	See Service Manual	P0543	3242	4	Ground short circuit of sensor/harness	None	Key switch turn OFF
73	Exhaust gas temperature sensor 1 Abnormality: High	See Service Manual	P0544	3242	3	Open circuit or +B short circuit of sensor/ harness	None	Key switch turn OFF
74	Exhaust gas temperature sensor 0 Abnormality: Low	See Service Manual	P0546	4765	4	Ground short circuit of sensor/harness	None	Key switch turn OFF

Page 8-18 List of Fault Codes

No.	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior During	DPF recovery from
	Text 1	Text 2	P-Code	SPN	FMI	Botodion item	Malfunction	error
75	Exhaust gas temperature sensor 0 Abnormality: High	See Service Manual	P0547	4765	3	Open circuit or +B short circuit of sensor/ harness	None	Key switch turn OFF
76	EEPROM check sum error	See Service Manual	P1990	523700	13	KBT-EEPROM check sum error	None	Key switch turn OFF
77	Intake throttle feedback error	See Service Manual	P2108	523580	2	Intake throttle feedback error	None	Key switch turn OFF
78	Accelerator position sensor correlation error	See Service Manual	P2135	91	2	Deviation from designed correlation in two sensors	Insufficient output	Diagnostic counter = zero
79	EGR actuator valve stuck	See Service Manual	P2413	523575	7	EGR actuator valve stuck	Insufficient outputWorsening exhaust gas performance	Key switch turn OFF
80	EGR (DC motor) overheat	See Service Manual	P2414	523576	2	EGR (DC motor) overheat	Insufficient outputWorsening exhaust gas performance	Key switch turn OFF
81	EGR (DC motor) temp. sensor failure	See Service Manual	P2415	523577	2	EGR (DC motor) temperature sensor failure	Insufficient outputWorsening exhaust gas performance	Key switch turn OFF
82	Exhaust gas temperature sensor 2 Abnormality: Low	See Service Manual	P242C	3246	4	Ground short circuit of sensor/harness	None	Key switch turn OFF
83	Exhaust gas temperature sensor 2 Abnormality: High	See Service Manual	P242D	3246	3	Open circuit or +B short circuit of sensor/ harness	None	Key switch turn OFF
84	Differential pressure sensor 1 Abnormality: Low	See Service Manual	P2454	3251	4	Ground short circuit of sensor/harness	None	Key switch turn OFF
85	Intake throttle lift sensor Abnormality: Low	See Service Manual	P2621	523582	4	Intake throttle lift sensor low	None	Key switch turn OFF
86	Intake throttle lift sensor Abnormality: High	See Service Manual	P2622	523582	3	Intake throttle lift sensor high	None	Key switch turn OFF
87	Emission deterioration	See Service Manual	P3001	3252	0	DOC is heated up due to unburned fuel	Insufficient output	Key switch turn OFF
88	Emergency Exhaust gas temperature sensor 0 Emergency: High	Stop ENG See Service Manual	P3002	4765	0	DOC inlet temperature (T0) high	• Engine stops • Inhibit cranking until down to 300 °C (572 °F)	Under 300 °C (572 °F) & key switch turn OFF

List of Fault Codes Page 8-19

No	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior During	DPF recovery from
No.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	Malfunction	error
89	Emergency Exhaust gas temperature sensor 1 Emergency: High	Stop ENG See Service Manual	P3003	3242	0	DPF inlet temperature (T1) high	• Engine stops • Inhibit cranking until down to 300 °C (572 °F)	Under 300 °C (572 °F) & key switch turn OFF
90	Emergency Exhaust gas temperature sensor 2 Emergency: High	Stop ENG See Service Manual	P3004	3246	0	DPF outlet temperature (T2) high	• Engine stops • Inhibit cranking until down to 300 °C (572 °F)	Under 300 °C (572 °F) & key switch turn OFF
91	Excessive PM3	Start DPF Parked Regeneration immediately	P3006	3701	15	PM accumulation level3	Insufficient output	Diagnostic counter = zero
92	Excessive PM4	Stop engine!! Contact dealer immediately	P3007	3701	16	PM accumulation level4	Insufficient output	Diagnostic counter = zero
93	Excessive PM5	Stop engine!! Contact dealer immediately	P3008	3701	0	PM accumulation level5	Insufficient output	Key switch turn OFF (Reset by Service tool)
94	Boost pressure: Low	See Service Manual	P3011	132	15	Disconnect the hose between the turbo blower out and intake flange Boost pressure sensor error	Insufficient output	Key switch turn OFF
95	Low coolant temp. in parked regeneration	See Service Manual	P3012	523589	17	During regeneration mode, engine warm- up condition is not satisfied (coolant temperature is low)	None	Diagnostic counter = zero (Leaving from parked active regeneration status)
96	Parked regeneration time out	See Service Manual	P3013	523590	16	Time out error: regeneration incomplete due to low temperature of DPF	None	Diagnostic counter = zero (Leaving from parked active regeneration status)
97	All exhaust temp. sensor failure	See Service Manual	P3018	523599	0	All exhaust gas temperature sensor failure simultaneously	None	Diagnostic counter = zero
98	High exhaust gas temp. after emergency high temp. DTC	Stop ENG See Service Manual	P3023	523601	0	Exhaust gas temperature sensor 0, 1, 2 output	None	Diagnostic counter = zero
99	High frequency of regeneration	See Service Manual	P3024	523602	0	Time interval from the end time to the start time of the regeneration	Worsening exhaust gas performance (NOx)	Key switch turn OFF (Reset by Service tool)

Page 8-20 List of Fault Codes

Na	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior During	DPF recovery from
No.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	Malfunction	error
100	Over heat pre- caution	Stop mowing!!	P3025	523603	15	Coolant temperature	Worsening exhaust gas performance (NOx)	Diagnostic counter = zero
101	No communication with EGR	See Service Manual	U0076	523578	2	No communication with EGR	Insufficient outputWorsening exhaust gas performance	Key switch turn OFF
102	CAN CCVS (Parking SW and Vehicle speed) frame error	See Service Manual	U0082	523591	2	CAN_CCVS communication stopping	None	Key switch turn OFF
103	CAN CM1 (Regen SW) frame error	See Service Manual	U0083	523592	2	CAN_CM1 communication stopping	None	Key switch turn OFF
104	CAN ETC5 frame error	See Service Manual	U0086	523595	2	CAN_ETC5 communication stopping	None	Key switch turn OFF
105	CAN TSC1 frame error	See Service Manual	U0087	523596	2	CAN_TSC1 communication stopping	None	Diagnostic counter = zero
106	CAN EBC1 frame error	See Service Manual	U0089	523598	2	CAN_EBC1 communication stopping	None	Diagnostic counter = zero
107	FUEL LEVEL LOW	Refuel	None	96	17	Remaining fuel volume at specified value or less (factory default setting=10%) Can be adjusted between 10% and 80%	None	Supply fuel until remaining fuel volume reaches the specified value or above
108	Open Circuit of Differential Pressure Sensor and Exhaust Gas Temp. Sensor	See Service Manual	P1A28	3936	7	Removal of DPF	-	-
109	Loss of DPF Function	See Service Manual	P3015	3936	2	Loss of function of DPF (PCD)	-	-
110	Open Circuit of Differential pressure sensor	See Service Manual	P2455	3251	3	Open circuit or +B short circuit of sensor/ harness	None	Diagnostic counter = zero
111	Open Circuit of ENG CAN Line	See Service Manual	U0076	523578	2	No communication with EGR	Insufficient outputWorsening exhaust gas emissions	Diagnostic counter = zero
112	Open Circuit of MAF Sensor	See Service Manual	P0102	132	4	Open circuit or ground short circuit of sensor/harness	Insufficient outputWorsening exhaust gas emissions	Diagnostic counter = zero

List of Fault Codes Page 8-21

Page 8-22 List of Fault Codes



